


SPINNING REEL

GS-60 & GS-60SC



KEY NO. 2 ~ 10
 6-733-1402

SPOOL ASSEMBLY

KEY NO. 56 ~ 59
 6-747-2002

HANDLE ASSEMBLY

SPECIAL PART FOR GS-60SC
 6-280-7112

RATCHET

Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	6-000-8241	Drag knob	31	6-270-7111	Click gear
2	6-170-4511	Drag washer retainer	32	6-050-5101	Ball bearing ret. washer
3	6-372-7812	Drag D washer	33	6-635-5001	Ball bearing
4	6-372-9011	Disc washer	34	6-403-0801	Pinion gear
5	6-375-5401	Drag A washer	35	6-351-6601	Ball bearing ret. washer screw
6	6-372-7701	Drag washer A	36	6-144-0321	Anti-reverse cam spring
7	6-733-1502	Spool	37	6-363-3601	Anti-reverse claw screw
8	6-807-8201	Spool click claw	38	6-375-5200	Anti-reverse claw washer
9	6-363-8401	Spool click claw retainer	39	6-770-0931	Anti-reverse claw
10	6-145-2101	Spool click claw spring	40	6-461-5102	Anti-reverse cam
11	6-376-1701	Spool washer	41	6-701-1101	Body
12	6-710-2214	Main shaft	42	6-373-2700	Anti-reverse lever washer
13	6-481-1011	Oscillating slider	43	6-541-6101	Anti-reverse lever
14	6-351-8901	Oscillating slider screw	44	6-352-2501	Anti-reverse lever screw
15	6-340-8301	Rotor nut	45	6-374-5400	Oscillating gear washer
16	6-201-7603	Rotor	46	6-412-3612	Oscillating gear
17	6-144-2201	Bail spring	47	6-636-6011	Ball bearing
18	6-633-0701	Bail spring cover	48	6-414-0101	Drive gear
19	6-351-1801	Bail spring cover screw	49	6-371-2800	Drive gear washer
20	6-363-3111	Bail screw	50	6-636-6011	Ball bearing
21	6-375-1101	Bail washer	51	6-706-7801	Body cover
22	6-231-1901	Arm lever	52	6-351-6401	Body cover screw
23	6-130-3201	Bail holder cap	53	6-501-8401	Handle screw holder
24	6-363-1901	Arm lever screw	54	6-363-8611	Handle screw
25	6-501-2001	Roller collar	55	6-363-4702	Handle screw cap
26	6-250-4321	Line roller	56	6-747-2411	Handle arm
27	6-351-6401	Bail holder screw	57	6-747-2501	Handle stand
28	6-725-1220	Bail	58	6-342-3101	Handle arm ret. nut
30	6-280-5401	Ratchet	59	6-353-9101	Handle arm ret. nut screw
			60	6-375-7701	Rotor washer