


**SWEEPFIRE 3500 / 4000**



Key No.	Parts No.	Parts Name
1	W33-5806	DRAG KNOB ASSY
9	W33-5901	DRAG WASHER RET
10	W33-6002	KEY WASHER
11	W33-6102	EARED WASHER
12	W33-6202	DRAG WASHER
13	W30-1901	CLICK PAWL
15	W30-2101	CLICK SPRING
16	W33-7202	CLICK PAWL SCREW
17	W33-7302	LINE HOLDER
18	W33-7402	LINE HOLDER SCREW
9-18	W33-7704	SPOOL
19	W33-9001	BAIL HOLDER SCREW
20	W33-7912	BAIL
21	W34-5202	LINE ROLLER BUSHING
22	W33-8104	LINE ROLLER
23	W33-8202	LINE ROLLER COLLAR
24	W33-8301	LINE ROLLER SCREW
25	W33-8401	BAIL ARM SCREW
26	W33-8604	BAIL ARM
27	W33-8702	BAIL SPRING SHAFT
28	W33-8802	BAIL SPRING
29	W33-8901	BAIL SPRING HOLDER
30	W33-9203	MAIN SHAFT
31	W33-9302	MAIN SHAFT WASHER
32	W33-9402	CLICK GEAR
33	W33-9102	ROTOR NUT HOLD PLT SCREW
34	W33-9501	ROTOR NUT HOLD PLT
35	W33-9601	ROTOR NUT
36	W34-0112	ROTOR
37	W34-0201	BAIL HOLDER NUT
38	W34-0309	BAIL SPRING COVER
39	W34-0401	BAIL SPRING COVER SCREW
40	W34-0501	BAIL TRIP LEVER SPRING
41	W34-0602	BAIL TRIP LEVER
42	W34-0703	BAIL TRIP LEVER SCREW
43	W34-0801	BEARING RET SCREW

Key No.	Parts No.	Parts Name
44	W34-0901	BEARING RET A
45	W34-1001	BALL BEARING
46	W34-1101	BEARING RET B
47	W34-5601	SPACING SLEEVE
48	W34-1804	PINION GEAR
49	W34-1901	A/R CAM SPRING A
50	W34-2003	A/R CAM
51	W34-2102	A/R CAM SCREW
52	W34-2206	REAR COVER A
53	W34-2309	REAR COVER B
54	W34-2403	A/R LEVER
55	W34-2501	A/R LEVER SCREW
56	W34-2602	REAR COVER SCREW
57	W34-2703	OSC GEAR
58	W34-2803	OSC SLIDER
59	W34-2901	OSC SLIDER SCREW
60	W34-3008	HANDLE
61	W34-3101	SIDE COVER SCREW A
62	W34-3201	SIDE COVER SCREW B
63	W34-3504	SIDE COVER
64	W34-5502	SIDE COVER BUSHING
65	W34-3701	DRIVE GEAR WASHER
66	W34-3802	DRIVE GEAR
67	W34-3902	A/R PAWL SPRING
68	W34-5302	DRIVE GEAR BUSHING
69	W34-4001	A/R PAWL SPRING
70	W34-4302	A/R PAWL SCREW
71	W34-4202	A/R PAWL
72	W34-4101	A/R PAWL COLLAR
73	W34-4702	HANDLE COLLAR
74	W34-4806	HANDLE SCREW
75	W34-5104	BODY

**SPECIAL PART FOR SW4000**

Key No.	Parts No.	Parts Name
9-18	W33-7804	SPOOL