

	1 2	6J716301 6E167101	BRAKE DIAL SCREW BRAKE DIAL SPRING
		6E167101	BRAKE DIAL SPRINC
	- '		DRAKE DIAL SPRING
	3	6J694901	BRAKE DIAL
	4	6B339801	BRAKE DIAL RETAINER(A)
	5	6F637701	BRAKE DIAL COLLAR
	6	6H663401	BRAKE DIAL LEAF SPRING
	7	6J694701	LS PLATE
	8	6H915501	BRAKE DIAL RETAINER(B)
	9	6G939301	BRAKE DIAL RETAINER(B)SCREW
	}		MAGNET HOLDER
	••••••		LS BEARING WASHER(A)(0.1MM)
			LS BEARING WASHER(B)
••••••	••••••	••••••	LS BEARING WASHER(C)
	~~~~~		LS BALL BEARING
	•••••••		LS BEARING RETEAINER
			SPOOL UNIT (16-24)
	~~~~~		FRAME
	26	6J694601	FRONT COVER
	27	6H531508	FRONT COVER SCREW
	28	6J693301	CLUTCH LEVER
	29	6J692701	CLUTCH LEVER PLATE (R)
	30	6J692801	CLUTCH LEVER PLATE (L)
	31	6J281902	OSCILLATING POST
	32	6H704101	OSCILLATING POST RETAINER
	33	6J693401	CLUTCH CAM PLATE PIN SPRING COLLAR
	34	6H928801	CLUTCH CAM PLATE PIN SPRING
			CLUTCH CAM PLATE PIN
			CLUTCH CAM BALL BEARING
			KICK LEVER PLATE (A)
		,	KICK LEVER PLATE (A) SCREW
••••••			
	•••••••		
	~~~~~~	~~~~~	
	~~~~~		CLUTCH CAM
			CLUTCH CAM SCREW WASHER
		63522501	CLUTCH CAM SCREW
	44	6H659101	KICK LEVER PLATE (B)
	45	6B032904	KICK LEVER PLATE (B) SCREW
	46	6H929001	CLUTCH PLATE
	47	6J313901	CLUTCH SPRING
	48	6J695602	PINION GEAR
	49	6H180501	PINON RETAINER
	50	6G431102	PINION BALL BEARING
	51	6J692203	RS PLATE
	52	6B055201	MECHANICAL BRAKE O-RING
			MECHANICAL BRAKE WASHER (A)
••••••			MECHANICAL BRAKE WASHER (B)
••••••		••••••	ZERO ADJUSTE KNOB(MCNICL.BR.KNOB)
			RS PLATE SCREW (A)
	~~~~~		***
	~~~~~	·····	WORM SHAFT RETAINER
			WORM SHAFT WASHER(0.1MM)
			WORM SHAFT COLLAR
			LEVEL WIND
			PAWL
	62	63731300	PAWL WASHER(0.1MM)
	63	6F402801	PAWL HOLDER NUT
	64	6J694001	WORM SHIELD
	65	6J243601	WORM SHAFT
	66	6G720001	WORM SHAFT COLLAR
	67	6J693901	WORM SHAFT GEAR
		10 11 12 13 14 15 16-24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64	10 6J695001 11 63757404 12 63757411 13 6G185101 14 6G511503 15 6F032201 16-24 6Z024117 25 6J692601 26 6J694601 27 6H531508 28 6J693301 29 6J692701 30 6J692801 31 6J281902 32 6H704101 33 6J693401 34 6H928801 35 6J055201 36 6B861704 37 6J692201 38 6H531508 39 6J407701 40 6J622901 41 6J692901 42 6H159201 43 63522501 44 6H659101 45 6B032904 46 6H929001 47 6J313901 48 6J695602 49

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
18 TATULA 100XS		69	6G099800	GEAR SHAFT WASHER(0.1MM)
18 TATULA 100XS		70	63208002	GEAR SHAFT RETAINER
18 TATULA 100XS		71	6G466202	GEAR SHAFT BALL BEARING
18 TATULA 100XS		72	6J693701	GEAR SHAFT PLATE
18 TATULA 100XS		73	6E134509	GEAR SHAFT PLATE SCREW
18 TATULA 100XS		74	6J693601	WORM GEAR
18 TATULA 100XS		75	6J693501	GEAR SHAFT
18 TATULA 100XS		76	6H660901	RATCHET
18 TATULA 100XS		77	6J085101	DRIVE GEAR WASHER
18 TATULA 100XS		78	6J695702	
18 TATULA 100XS		70 79	6H359002	
18 TATULA 100XS		80	6J694401	
}		·}·····		DRAG DISC WASHER
18 TATULA 100XS		81	6J377801	DRAG COLLAR
18 TATULA 100XS		82	6J540401	ONEWAY CLUTCH
18 TATULA 100XS		83	6B861704	CLUTCH CAM BALL BEARING
18 TATULA 100XS		84	6B553801	HANDLE BALL BEARING WASHER
18 TATULA 100XS		85	6F028203	DRAG HOLDER
18 TATULA 100XS		86	6F032401	DRAG HOLDER LEAF SPRING
18 TATULA 100XS		87	61508901	DRAG SPRING WASHER
18 TATULA 100XS		88	6H929501	STAR DRAG WASHER
18 TATULA 100XS		89	6H912001	DRAG NUT
18 TATULA 100XS		90	6J011901	DRAG NUT SPRING
18 TATULA 100XS		91	6H911901	STAR DRAG
18 TATULA 100XS		92	6F576601	HANDLE WAHSER
18 TATULA 100XS		93	6J728801	HANDLE ASSEMBLY
18 TATULA 100XS		94	6G793301	HANDLE NUT
18 TATULA 100XS		95	6H834507	HANDLE LOCK PLATE
18 TATULA 100XS		96	63538301	HANDLE LOCK PLATE SC
······································				
5				
		<u> </u>		
		<u> </u>		
		<u>.</u>		
		ļ		
		ļ		
		ļ		
		Į		
		Į		
		<u>.</u>		
		Į		<u>.</u>
		{]
		{		
		[
		<u> </u>		
		t		1
		<u>}</u>		
	۱	٤		