


DAWA BAITCASTING REEL

TATU100L_HL_XHL

*Please order by parts number, not key number.



Key No	Part No	Description
1	J71-6301	BRAKE DIAL SCREW
2	E16-7101	BRAKE DIAL SPRING
3	J69-4908	BRAKE DIAL
4	B33-9801	BRAKE DIAL RETAINER (A)
5	F63-7701	BRAKE DIAL COLLAR
6	J88-6201	BRAKE DIAL LEAF SPRING
7	M46-7801	RIGHT SIDE PLATE
8	J84-3301	BRAKE DIAL RETAINER (B)
9	G93-9301	BRAKE DIAL RETAINER SCREW
10	J69-5001	MAGNET HOLDER
11	375-7404	RS SPOOL ADJUST WASHER (A)
12	375-7411	RS SPOOL ADJUST WASHER (B)
13	G18-5101	RS SPOOL ADJUST WASHER (C)
14	G51-1503	RS BALL BEARING
15	F03-2201	RS BEARING RETAINER
16-24, 97	Z02-7226	SPOOL ASSEMBLY (16 24)
25	M46-7301	FRAME
26	M45-4401	FRONT COVER
27	H53-1508	FRONT COVER SCREW
28	M45-3801	CLUTCH LEVER
29	M45-3401	CLUTCH LEVER PLATE (L)
30	M45-3301	CLUTCH LEVER PLATE (R)
31	M04-1101	STABILIZER BAR
32	B86-1705	PINION BALL BEARING (A)
33	M46-7601	CLUTCH CAM PLATE (A)
34	M06-0601	CLUTCH TRIP LEVER SPRING
35	J63-8601	CLUTCH TRIP LEVER
36	M46-7401	CLUTCH CAM
37	M46-7501	CLUTCH BAR
38	M07-0001	CLUTCH BAR SCREW WASHER
39	B36-0406	CLUTCH BAR SCREW
40	M45-3701	CLUTCH CAM PLATE (B)
41	M15-7501	YOKE
42	B03-2904	CLUTCH CAM PLATE SCREW
43	J31-3901	YOKE SPRING
45 77	Z02-7414	PINION DRIVE GEAR SET
46	M53-1101	LEFT SIDE PLATE
47	G43-1102	PINION BALL BEARING (B)
48	E21-9701	PINION BEARING RETAINER
49	B05-5201	MECHANICAL BRAKE O RING
50	J21-3101	MECHANICAL BRAKE WASHER (A)
51	B17-5503	MECHANICAL BRAKE WASHER (B)
52	J69-2502	ZERO ADJUSTER KNOB
53	G04-0831	LEFT SIDE PLATE SCREW (A)
54	G04-0830	LEFT SIDE PLATE SCREW (B)
55	320-5901	WORM SHAFT RETAINER (A)
56	B41-1702	WORM SHAFT WASHER
57	G72-0001	WORM SHAFT COLLAR (A)
58	M05-4201	LEVELWIND
59	J74-0201	LINE GUIDE PAWL PIN

Key No	Part No	Description
60	M45-4101	LINE GUIDE PAWL
61	M16-1301	LINE GUIDE PAWL WASHER
62	G25-2202	LINE GUIDE PAWL
63	M04-8901	WORM SHIELD
64	J24-3601	WORM SHAFT
65	G72-0001	WORM SHAFT COLLAR (B)
66	J69-3901	WORM SHAFT GEAR
67	B33-9801	WORM SHAFT GEAR RETAINER
68	G09-9801	DRIVE SHAFT WASHER
69	320-8002	GEAR SHAFT RETAINER
70	G46-6202	DRIVE SHAFT BALL BEARING (A)
71	M45-4001	DRIVE SHAFT PLATE
72	E13-4509	DRIVE SHAFT PLATE SCREW
73	G29-7002	WORM GEAR
74	M45-3902	DRIVE SHAFT
75	H66-0901	CLUTCH TRIP WHEEL
76	J08-5101	DRIVE GEAR WASHER
45 77	Z02-7414	PINION DRIVE GEAR SET
78	H35-9002	DRAG WASHER
79	J69-4401	KEY WASHER
80	J37-7801	CLUTCH RING
81	J54-0401	ONEWAY CLUTCH
82	B86-1705	DRIVE BALL BEARING (B)
83	B55-3801	DRIVE BEARING WASHER
84	F02-8203	CLICK SPRING HOLDER
85	F03-2401	CLICK LEAF SPRING
86	150-8901	DRAG SPRING WASHER
87	H92-9501	STAR DRAG WASHER
88	H91-2002	STAR DRAG METAL
89	J01-1901	STAR DRAG SPRING
90	H91-1901	STAR DRAG
91	F57-6601	HANDLE COLLAR
92	M54-2701	HANDLE ASSEMBLY
93	H72-3702	HANDLE NUT
94	J21-3503	HANDLE LOCK PLATE
95	G04-0803	HANDLE LOCK PLATE SCREW
96	B55-3805	ONEWAY CLUTCH WASHER
98	M04-7801	FRONT COVER COLLAR

TATU100HL Special parts

Key No	Part No	Description
16-24, 97	Z02-7412	PINION DRIVE GEAR SET
46	M53-0801	LEFT SIDE PLATE

TATU100XHL Special Parts

Key No	Part No	Description
45 77	Z02-7256	PINION DRIVE GEAR SET
46	M46-7101	LEFT SIDE PLATE