




21 TD SOL MQ 2000S

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



21 TD SOL MQ 2000S	2500S
2500D	3000D
4000D-C	

S51214D
S51414D
S51415D
S51614D
S51714D

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 TD SOL MQ 2000S	S51214D	1	6Q775801	DRAG KNOB
21 TD SOL MQ 2000S	S51214D	2	6Q346101	DRAG WASHER RETAINER
21 TD SOL MQ 2000S	S51214D	3	6Q621901	KEY WASHER
21 TD SOL MQ 2000S	S51214D	4	6J678901	DRAG WASHER
21 TD SOL MQ 2000S	S51214D	5	-----	-----
21 TD SOL MQ 2000S	S51214D	6	-----	-----
21 TD SOL MQ 2000S	S51214D	7	6B358701	BEARING RETAINER
21 TD SOL MQ 2000S	S51214D	8	6G212503	SPOOL BALL BEARING
21 TD SOL MQ 2000S	S51214D	2 12	6Q775501	SPOOL ASSY
21 TD SOL MQ 2000S	S51214D	10	6Q376701	LINE STOPPER PLATE
21 TD SOL MQ 2000S	S51214D	11	6Q345501	LINE STOPPER
21 TD SOL MQ 2000S	S51214D	12	6Q345701	LINE STOPPER SPRING
21 TD SOL MQ 2000S	S51214D	13	6J546304	SPOOL WASHER (A)
21 TD SOL MQ 2000S	S51214D	14	6J558201	SPOOL METAL SCREW
21 TD SOL MQ 2000S	S51214D	15	6J564101	SPOOL METAL
21 TD SOL MQ 2000S	S51214D	16	6H624801	SPOOL COLLAR
21 TD SOL MQ 2000S	S51214D	17	6J602201	SPOOL WASHER (B)
21 TD SOL MQ 2000S	S51214D	18	6Q798201	CLICK SPRING HOLDER
21 TD SOL MQ 2000S	S51214D	19	6Q797701	CLICK LEAF SPRING
21 TD SOL MQ 2000S	S51214D	20	6H986901	ROTOR NUT PACKING
21 TD SOL MQ 2000S	S51214D	21	6Q748401	ROTOR NUT
21 TD SOL MQ 2000S	S51214D	22	6J808501	ROTOR NUT COLLAR
21 TD SOL MQ 2000S	S51214D	23	63727609	ROTOR NUT WASHER
21 TD SOL MQ 2000S	S51214D	24	-----	-----
21 TD SOL MQ 2000S	S51214D	25	6J287401	ROTOR COVER
21 TD SOL MQ 2000S	S51214D	26	6H022701	ROTOR COVER SCREW
21 TD SOL MQ 2000S	S51214D	27	6J286712	ROTOR
21 TD SOL MQ 2000S	S51214D	28	6J435101	BAIL TRIP LEVER SPRING
21 TD SOL MQ 2000S	S51214D	29	6J339502	BAIL TRIP LEVER WASHER
21 TD SOL MQ 2000S	S51214D	30	6J304701	BAIL TRIP LEVER
21 TD SOL MQ 2000S	S51214D	31	6H417701	BAIL TRIP LEVER SCREW
21 TD SOL MQ 2000S	S51214D	32	6J254601	ARM LEVER SHAFT
21 TD SOL MQ 2000S	S51214D	33	6J254701	ARM LEVER SHAFT HOLDER
21 TD SOL MQ 2000S	S51214D	34	6F306402	ARM LEVER COVER WASHER
21 TD SOL MQ 2000S	S51214D	35	6J287003	ARM LEVER COVER
21 TD SOL MQ 2000S	S51214D	36	6J255201	ARM LEVER COVER SCREW
21 TD SOL MQ 2000S	S51214D	37	6J254814	ARM LEVER
21 TD SOL MQ 2000S	S51214D	38	6J254901	ARM LEVER COLLAR
21 TD SOL MQ 2000S	S51214D	39	6J255001	ARM LEVER SCREW
21 TD SOL MQ 2000S	S51214D	40	6J257001	ROLLER SCREW
21 TD SOL MQ 2000S	S51214D	41	6J538001	ROLLER COLLAR (A)
21 TD SOL MQ 2000S	S51214D	42	6J538401	MAGSEALED PLATE (A)
21 TD SOL MQ 2000S	S51214D	43	6J256702	ROLLER BALL BEARING
21 TD SOL MQ 2000S	S51214D	44	6J256601	ROLLER COLLAR (B)
21 TD SOL MQ 2000S	S51214D	45	6J256301	ROLLER COLLAR (C)
21 TD SOL MQ 2000S	S51214D	46	6J256501	LINE ROLLER
21 TD SOL MQ 2000S	S51214D	47	6J256401	ROLLER COLLAR (D)
21 TD SOL MQ 2000S	S51214D	48	6J537801	MAGSEALED PLATE (B)
21 TD SOL MQ 2000S	S51214D	49	6J908801	BAIL
21 TD SOL MQ 2000S	S51214D	50	6J254901	BAIL HOLDER SCREW COLLAR
21 TD SOL MQ 2000S	S51214D	51	6J255001	BAIL HOLDER SCREW
21 TD SOL MQ 2000S	S51214D	52	6G471803	BAIL SPRING SHAFT
21 TD SOL MQ 2000S	S51214D	53	6G685401	BAIL SPRING WASHER
21 TD SOL MQ 2000S	S51214D	54	6J304801	BAIL SPRING

21 TD SOL MQ 2000S	S51214D	55	6G471601	BAIL SPRING HOLDER
21 TD SOL MQ 2000S	S51214D	56	6J287303	BAIL HOLDER COVER
21 TD SOL MQ 2000S	S51214D	57	6J255201	BAIL HOLDER COVER SCREW
21 TD SOL MQ 2000S	S51214D	58	6G837101	MAGSEALED PLATE SCREW
21 TD SOL MQ 2000S	S51214D	59	63754102	MAGSEALED PLATE SCREW WASHER
21 TD SOL MQ 2000S	S51214D	60	6J675201	MAGSEALED PLATE
REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 TD SOL MQ 2000S	S51214D	61	6J354801	MADSEALED CAP O RING
21 TD SOL MQ 2000S	S51214D	62	6Q609601	MADSEALED CAP
21 TD SOL MQ 2000S	S51214D	63	6J639901	ONEWAY CLUTCH WASHER
21 TD SOL MQ 2000S	S51214D	64	6J388402	ONEWAY CLUTCH
21 TD SOL MQ 2000S	S51214D	65	6J536102	CLUTCH RING
21 TD SOL MQ 2000S	S51214D	66	6Q609001	CLUTCH RING COLLAR
21 TD SOL MQ 2000S	S51214D	67	6Q195701	BEARING PLATE SCREW
21 TD SOL MQ 2000S	S51214D	68	6Q621201	BEARING PLATE
21 TD SOL MQ 2000S	S51214D	69	6G467302	PINION BALL BEARING (A)
21 TD SOL MQ 2000S	S51214D	70	63758502	PINION BEARING WASHER
21 TD SOL MQ 2000S	S51214D	71	6Z700650	PINION DRIVE GEAR SET
21 TD SOL MQ 2000S	S51214D	72	6H931701	PINION SPRING WASHER
21 TD SOL MQ 2000S	S51214D	73	6H959601	PINON BALL BEARING (B)
21 TD SOL MQ 2000S	S51214D	74	6G466103	PINON BEARING WASHER (B)
21 TD SOL MQ 2000S	S51214D	75	6J387701	PINION BEARING COLLAR
21 TD SOL MQ 2000S	S51214D	76	6Q621301	REAR COVER SCREW (A)
21 TD SOL MQ 2000S	S51214D	77	6Q775401	BODY
21 TD SOL MQ 2000S	S51214D	78	6Q643901	REAR COVER PACKING
21 TD SOL MQ 2000S	S51214D	79	6Q644001	REAR COVER
21 TD SOL MQ 2000S	S51214D	80	6Q621101	REAR COVER SCREW (B)
21 TD SOL MQ 2000S	S51214D	81	6Q609201	OSCILLATING POST COLLAR
21 TD SOL MQ 2000S	S51214D	82	6Q609302	OSCILLATING POST
21 TD SOL MQ 2000S	S51214D	83	6Q643201	MAIN SHAFT
21 TD SOL MQ 2000S	S51214D	84	6H607901	OSCILLATING GEAR WASHER
21 TD SOL MQ 2000S	S51214D	85	6Q643101	OSCILLATING GEAR
21 TD SOL MQ 2000S	S51214D	86	6G683301	OSCILLATING GEAR O RING
21 TD SOL MQ 2000S	S51214D	87	6H129201	OSCILLATING BEARING WASHER
21 TD SOL MQ 2000S	S51214D	88	6G469005	OSCILLATING GEAR BALL BEARING
21 TD SOL MQ 2000S	S51214D	89	6Q126101	OSCILLATING GEAR SCREW
21 TD SOL MQ 2000S	S51214D	90	6G670501	DRIVE O RING
21 TD SOL MQ 2000S	S51214D	91	63758502	DRIVE BEARING WASHER
21 TD SOL MQ 2000S	S51214D	92	6G522705	DRIVE BALL BEARING (A)
21 TD SOL MQ 2000S	S51214D	93	6J588801	BODY COVER O RING
21 TD SOL MQ 2000S	S51214D	94	6Q643807	BODY COVER
21 TD SOL MQ 2000S	S51214D	95	6G162401	HANDLE CAP O RING
21 TD SOL MQ 2000S	S51214D	96	6Q345101	HANDLE CAP
21 TD SOL MQ 2000S	S51214D	97	6G522705	DRIVE BALL BEARING (B)
21 TD SOL MQ 2000S	S51214D	98	6Q642903	SET PLATE
21 TD SOL MQ 2000S	S51214D	99	6H816401	SET PLATE O RING
21 TD SOL MQ 2000S	S51214D	100	6G472401	DRIVE BEARING RETAINER
21 TD SOL MQ 2000S	S51214D	101	6H617001	DRIVE BEARING O RING
21 TD SOL MQ 2000S	S51214D	102	6Q608906	DRIVE BEARING COVER
21 TD SOL MQ 2000S	S51214D	103	6J130201	BEARING COVER PACKING
21 TD SOL MQ 2000S	S51214D	104	6Q775901	HANDLE ASSY
21 TD SOL MQ 2000S	S51214D	200	6B411703	HANDLE KNOB WASHER
21 TD SOL MQ 2000S	S51214D	201	6G720001	HANDLE KNOB BUSHING
21 TD SOL MQ 2000S	S51214D	202	6Q281801	HANDLE KNOB

