




21 TD SOL MQ 3000D

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



21 TD SOL MQ 2000S 2500S
2500D 3000D 4000D-C

S51214D
S51414D
S51415D
S51614D
S51714D

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 TD SOL MQ 3000D	S51614D	1	6Q776501	DRAG KNOB
21 TD SOL MQ 3000D	S51614D	2	6Q346101	DRAG WASHER RETAINER
21 TD SOL MQ 3000D	S51614D	3	6Q621901	KEY WASHER (A)
21 TD SOL MQ 3000D	S51614D	4	6J546803	DRAG WASHER
21 TD SOL MQ 3000D	S51614D	5	6J546902	EARED WASHER
21 TD SOL MQ 3000D	S51614D	6	6J549001	KEY WASHER (B)
21 TD SOL MQ 3000D	S51614D	7	-----	-----
21 TD SOL MQ 3000D	S51614D	8	6G212503	SPOOL BALL BEARING
21 TD SOL MQ 3000D	S51614D	2 12	6Q797801	SPOOL ASSY
21 TD SOL MQ 3000D	S51614D	10	6Q345601	LINE STOPPER PLATE
21 TD SOL MQ 3000D	S51614D	11	6Q345501	LINE STOPPER
21 TD SOL MQ 3000D	S51614D	12	6Q345701	LINE STOPPER SPRING
21 TD SOL MQ 3000D	S51614D	13	6J546304	SPOOL WASHER (A)
21 TD SOL MQ 3000D	S51614D	14	6J558201	SPOOL METAL SCREW
21 TD SOL MQ 3000D	S51614D	15	6J549501	SPOOL METAL
21 TD SOL MQ 3000D	S51614D	16	6H624801	SPOOL COLLAR
21 TD SOL MQ 3000D	S51614D	17	6J602201	SPOOL WASHER (B)
21 TD SOL MQ 3000D	S51614D	18	6Q798201	CLICK SPRING HOLDER
21 TD SOL MQ 3000D	S51614D	19	6Q797701	CLICK LEAF SPRING
21 TD SOL MQ 3000D	S51614D	20	6H986901	ROTOR NUT PACKING
21 TD SOL MQ 3000D	S51614D	21	6Q735801	ROTOR NUT
21 TD SOL MQ 3000D	S51614D	22	6J808501	ROTOR NUT COLLAR
21 TD SOL MQ 3000D	S51614D	23	63727602	ROTOR NUT WASHER
21 TD SOL MQ 3000D	S51614D	24	6H022701	ROTOR NUT SCREW
21 TD SOL MQ 3000D	S51614D	25	6J257101	ROTOR COVER
21 TD SOL MQ 3000D	S51614D	26	6H022701	ROTOR COVER SCREW
21 TD SOL MQ 3000D	S51614D	27	6J254310	ROTOR
21 TD SOL MQ 3000D	S51614D	28	6J435201	BAIL TRIP LEVER SPRING
21 TD SOL MQ 3000D	S51614D	29	6J339502	BAIL TRIP LEVER WASHER
21 TD SOL MQ 3000D	S51614D	30	6J254401	BAIL TRIP LEVER
21 TD SOL MQ 3000D	S51614D	31	6H417701	BAIL TRIP LEVER SCREW
21 TD SOL MQ 3000D	S51614D	32	6J254601	ARM LEVER SHAFT
21 TD SOL MQ 3000D	S51614D	33	6J254701	ARM LEVER SHAFT HOLDER
21 TD SOL MQ 3000D	S51614D	34	-----	-----
21 TD SOL MQ 3000D	S51614D	35	6J255103	ARM LEVER COVER
21 TD SOL MQ 3000D	S51614D	36	6J255201	ARM LEVER COVER SCREW
21 TD SOL MQ 3000D	S51614D	37	6J254814	ARM LEVER
21 TD SOL MQ 3000D	S51614D	38	6J254901	ARM LEVER COLLAR
21 TD SOL MQ 3000D	S51614D	39	6J255001	ARM LEVER SCREW
21 TD SOL MQ 3000D	S51614D	40	6J257001	ROLLER SCREW
21 TD SOL MQ 3000D	S51614D	41	6J538001	ROLLER COLLAR (A)
21 TD SOL MQ 3000D	S51614D	42	6J538401	MAGSEALED PLATE (A)
21 TD SOL MQ 3000D	S51614D	43	6J256702	ROLLER BALL BEARING
21 TD SOL MQ 3000D	S51614D	44	6J256601	ROLLER COLLAR (B)
21 TD SOL MQ 3000D	S51614D	45	6J256301	ROLLER COLLAR (C)
21 TD SOL MQ 3000D	S51614D	46	6J256501	LINE ROLLER
21 TD SOL MQ 3000D	S51614D	47	6J256401	ROLLER COLLAR (D)
21 TD SOL MQ 3000D	S51614D	48	6J537801	MAGSEALED PLATE (B)
21 TD SOL MQ 3000D	S51614D	49	6J891101	BAIL
21 TD SOL MQ 3000D	S51614D	50	6J254901	BAIL HOLDER SCREW COLLAR
21 TD SOL MQ 3000D	S51614D	51	6J255001	BAIL HOLDER SCREW
21 TD SOL MQ 3000D	S51614D	52	6G471803	BAIL SPRING SHAFT
21 TD SOL MQ 3000D	S51614D	53	6G685401	BAIL SPRING WASHER
21 TD SOL MQ 3000D	S51614D	54	6J255301	BAIL SPRING

21 TD SOL MQ 3000D	S51614D	55	6G471602	BAIL SPRING HOLDER
21 TD SOL MQ 3000D	S51614D	56	6J255903	BAIL HOLDER COVER
21 TD SOL MQ 3000D	S51614D	57	6J255201	BAIL HOLDER COVER SCREW
21 TD SOL MQ 3000D	S51614D	58	6G837101	MAGSEALED PLATE SCREW
21 TD SOL MQ 3000D	S51614D	59	63754102	MAGSEALED PLATE SCREW WASHER
21 TD SOL MQ 3000D	S51614D	60	6J675201	MAGSEALED PLATE
REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 TD SOL MQ 3000D	S51614D	61	6J354801	MADSEALED CAP O RING
21 TD SOL MQ 3000D	S51614D	62	6Q609601	MADSEALED CAP
21 TD SOL MQ 3000D	S51614D	63	6J639901	ONEWAY CLUTCH WASHER
21 TD SOL MQ 3000D	S51614D	64	6J388402	ONEWAY CLUTCH
21 TD SOL MQ 3000D	S51614D	65	6J536102	CLUTCH RING
21 TD SOL MQ 3000D	S51614D	66	6Q609001	CLUTCH RING COLLAR
21 TD SOL MQ 3000D	S51614D	67	6Q195701	BEARING PLATE SCREW
21 TD SOL MQ 3000D	S51614D	68	6Q621201	BEARING PLATE
21 TD SOL MQ 3000D	S51614D	69	6G467302	PINION BALL BEARING (A)
21 TD SOL MQ 3000D	S51614D	70	63758502	PINION BEARING WASHER
21 TD SOL MQ 3000D	S51614D	71	6Z700685	PINION DRIVE GEAR SET
21 TD SOL MQ 3000D	S51614D	72	6H931701	PINION SPRING WASHER
21 TD SOL MQ 3000D	S51614D	73	6G466202	PINON BALL BEARING (B)
21 TD SOL MQ 3000D	S51614D	74	6G466103	PINON BEARING WASHER (B)
21 TD SOL MQ 3000D	S51614D	75	6J387701	PINION BEARING COLLAR
21 TD SOL MQ 3000D	S51614D	76	6Q621301	REAR COVER SCREW (A)
21 TD SOL MQ 3000D	S51614D	77	6Q779401	BODY
21 TD SOL MQ 3000D	S51614D	78	6Q667101	REAR COVER PACKING
21 TD SOL MQ 3000D	S51614D	79	6Q667201	REAR COVER
21 TD SOL MQ 3000D	S51614D	80	6Q621101	REAR COVER SCREW (B)
21 TD SOL MQ 3000D	S51614D	81	6Q609201	OSCILLATING POST COLLAR
21 TD SOL MQ 3000D	S51614D	82	6Q126305	OSCILLATING POST
21 TD SOL MQ 3000D	S51614D	83	6Q666201	MAIN SHAFT
21 TD SOL MQ 3000D	S51614D	84	6J644701	OSCILLATING GEAR WASHER
21 TD SOL MQ 3000D	S51614D	85	6Q666101	OSCILLATING GEAR
21 TD SOL MQ 3000D	S51614D	86	6G466001	OSCILLATING GEAR O RING
21 TD SOL MQ 3000D	S51614D	87	6H129201	OSCILLATING BEARING WASHER
21 TD SOL MQ 3000D	S51614D	88	6G469005	OSCILLATING GEAR BALL BEARING
21 TD SOL MQ 3000D	S51614D	89	6Q126101	OSCILLATING GEAR SCREW
21 TD SOL MQ 3000D	S51614D	90	6G670501	DRIVE O RING
21 TD SOL MQ 3000D	S51614D	91	63758502	DRIVE BEARING WASHER
21 TD SOL MQ 3000D	S51614D	92	6G467305	DRIVE BALL BEARING (A)
21 TD SOL MQ 3000D	S51614D	93	6J571501	BODY COVER O RING
21 TD SOL MQ 3000D	S51614D	94	6Q666907	BODY COVER
21 TD SOL MQ 3000D	S51614D	95	6G162401	HANDLE CAP O RING
21 TD SOL MQ 3000D	S51614D	96	6Q345101	HANDLE CAP
21 TD SOL MQ 3000D	S51614D	97	6G522705	DRIVE BALL BEARING (B)
21 TD SOL MQ 3000D	S51614D	98	6Q665903	SET PLATE
21 TD SOL MQ 3000D	S51614D	99	6Q666001	SET PLATE O RING
21 TD SOL MQ 3000D	S51614D	100	6G472401	DRIVE BEARING RETAINER
21 TD SOL MQ 3000D	S51614D	101	6H617001	DRIVE BEARING O RING
21 TD SOL MQ 3000D	S51614D	102	6Q608906	DRIVE BEARING COVER
21 TD SOL MQ 3000D	S51614D	103	6J130201	BEARING COVER PACKING
21 TD SOL MQ 3000D	S51614D	104	6Q779801	HANDLE ASSY
21 TD SOL MQ 3000D	S51614D	200	6B411703	HANDLE KNOB WASHER
21 TD SOL MQ 3000D	S51614D	201	6G720001	HANDLE KNOB BUSHING
21 TD SOL MQ 3000D	S51614D	202	6H088709	HANDLE KNOB

