




21 TD SOL MQ 4000D-C

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



21 TD SOL MQ 2000S 2500S
2500D 3000D 4000D-C

S51214D
S51414D
S51415D
S51614D
S51714D

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 TD SOL MQ 4000D-C	S51714D	1	6Q779701	DRAG KNOB
21 TD SOL MQ 4000D-C	S51714D	2	6Q346101	DRAG WASHER RETAINER
21 TD SOL MQ 4000D-C	S51714D	3	6Q621901	KEY WASHER (A)
21 TD SOL MQ 4000D-C	S51714D	4	6J546803	DRAG WASHER
21 TD SOL MQ 4000D-C	S51714D	5	6J546902	EARED WASHER
21 TD SOL MQ 4000D-C	S51714D	6	6J549001	KEY WASHER (B)
21 TD SOL MQ 4000D-C	S51714D	7	-----	-----
21 TD SOL MQ 4000D-C	S51714D	8	6G212503	SPOOL BALL BEARING
21 TD SOL MQ 4000D-C	S51714D	2 12	6Q779501	SPOOL ASSY
21 TD SOL MQ 4000D-C	S51714D	10	6Q353501	LINE STOPPER PLATE
21 TD SOL MQ 4000D-C	S51714D	11	6Q345501	LINE STOPPER
21 TD SOL MQ 4000D-C	S51714D	12	6Q345701	LINE STOPPER SPRING
21 TD SOL MQ 4000D-C	S51714D	13	6J546304	SPOOL WASHER (A)
21 TD SOL MQ 4000D-C	S51714D	14	6J558201	SPOOL METAL SCREW
21 TD SOL MQ 4000D-C	S51714D	15	6J549501	SPOOL METAL
21 TD SOL MQ 4000D-C	S51714D	16	6H624801	SPOOL COLLAR
21 TD SOL MQ 4000D-C	S51714D	17	6J602201	SPOOL WASHER (B)
21 TD SOL MQ 4000D-C	S51714D	18	6Q798201	CLICK SPRING HOLDER
21 TD SOL MQ 4000D-C	S51714D	19	6Q797701	CLICK LEAF SPRING
21 TD SOL MQ 4000D-C	S51714D	20	6H986901	ROTOR NUT PACKING
21 TD SOL MQ 4000D-C	S51714D	21	6Q735801	ROTOR NUT
21 TD SOL MQ 4000D-C	S51714D	22	6J808501	ROTOR NUT COLLAR
21 TD SOL MQ 4000D-C	S51714D	23	63727602	ROTOR NUT WASHER
21 TD SOL MQ 4000D-C	S51714D	24	6H022701	ROTOR NUT SCREW
21 TD SOL MQ 4000D-C	S51714D	25	6J284001	ROTOR COVER
21 TD SOL MQ 4000D-C	S51714D	26	6H022701	ROTOR COVER SCREW
21 TD SOL MQ 4000D-C	S51714D	27	6J571906	ROTOR
21 TD SOL MQ 4000D-C	S51714D	28	6J435201	BAIL TRIP LEVER SPRING
21 TD SOL MQ 4000D-C	S51714D	29	6J339502	BAIL TRIP LEVER WASHER
21 TD SOL MQ 4000D-C	S51714D	30	6J572001	BAIL TRIP LEVER
21 TD SOL MQ 4000D-C	S51714D	31	6H417701	BAIL TRIP LEVER SCREW
21 TD SOL MQ 4000D-C	S51714D	32	6J262601	ARM LEVER SHAFT
21 TD SOL MQ 4000D-C	S51714D	33	6J262701	ARM LEVER SHAFT HOLDER
21 TD SOL MQ 4000D-C	S51714D	34	-----	-----
21 TD SOL MQ 4000D-C	S51714D	35	6J572201	ARM LEVER COVER
21 TD SOL MQ 4000D-C	S51714D	36	6J255201	ARM LEVER COVER SCREW
21 TD SOL MQ 4000D-C	S51714D	37	6J254814	ARM LEVER
21 TD SOL MQ 4000D-C	S51714D	38	6J254901	ARM LEVER COLLAR
21 TD SOL MQ 4000D-C	S51714D	39	6J255001	ARM LEVER SCREW
21 TD SOL MQ 4000D-C	S51714D	40	6J257001	ROLLER SCREW
21 TD SOL MQ 4000D-C	S51714D	41	6J538001	ROLLER COLLAR (A)
21 TD SOL MQ 4000D-C	S51714D	42	6J538401	MAGSEALED PLATE (A)
21 TD SOL MQ 4000D-C	S51714D	43	6J256702	ROLLER BALL BEARING
21 TD SOL MQ 4000D-C	S51714D	44	6J256601	ROLLER COLLAR (B)
21 TD SOL MQ 4000D-C	S51714D	45	6J256301	ROLLER COLLAR (C)
21 TD SOL MQ 4000D-C	S51714D	46	6J256501	LINE ROLLER
21 TD SOL MQ 4000D-C	S51714D	47	6J256401	ROLLER COLLAR (D)
21 TD SOL MQ 4000D-C	S51714D	48	6J537801	MAGSEALED PLATE (B)
21 TD SOL MQ 4000D-C	S51714D	49	6J903401	BAIL
21 TD SOL MQ 4000D-C	S51714D	50	6J254901	BAIL HOLDER SCREW COLLAR
21 TD SOL MQ 4000D-C	S51714D	51	6J255001	BAIL HOLDER SCREW
21 TD SOL MQ 4000D-C	S51714D	52	6G298201	BAIL SPRING SHAFT
21 TD SOL MQ 4000D-C	S51714D	53	6G685401	BAIL SPRING WASHER
21 TD SOL MQ 4000D-C	S51714D	54	6G944501	BAIL SPRING

21 TD SOL MQ 4000D-C	S51714D	55	6G471602	BAIL SPRING HOLDER
21 TD SOL MQ 4000D-C	S51714D	56	6J572701	BAIL HOLDER COVER
21 TD SOL MQ 4000D-C	S51714D	57	6J255201	BAIL HOLDER COVER SCREW
21 TD SOL MQ 4000D-C	S51714D	58	6G837101	MAGSEALED PLATE SCREW
21 TD SOL MQ 4000D-C	S51714D	59	63754102	MAGSEALED PLATE SCREW WASHER
21 TD SOL MQ 4000D-C	S51714D	60	6J675201	MAGSEALED PLATE
REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 TD SOL MQ 4000D-C	S51714D	61	6J354801	MADSEALED CAP O RING
21 TD SOL MQ 4000D-C	S51714D	62	6Q609601	MADSEALED CAP
21 TD SOL MQ 4000D-C	S51714D	63	6J639901	ONEWAY CLUTCH WASHER
21 TD SOL MQ 4000D-C	S51714D	64	6J388402	ONEWAY CLUTCH
21 TD SOL MQ 4000D-C	S51714D	65	6J536102	CLUTCH RING
21 TD SOL MQ 4000D-C	S51714D	66	6Q609001	CLUTCH RING COLLAR
21 TD SOL MQ 4000D-C	S51714D	67	6Q195701	BEARING PLATE SCREW
21 TD SOL MQ 4000D-C	S51714D	68	6Q621201	BEARING PLATE
21 TD SOL MQ 4000D-C	S51714D	69	6G467302	PINION BALL BEARING (A)
21 TD SOL MQ 4000D-C	S51714D	70	63758502	PINION BEARING WASHER
21 TD SOL MQ 4000D-C	S51714D	71	6Z700685	PINION DRIVE GEAR SET
21 TD SOL MQ 4000D-C	S51714D	72	6H931701	PINION SPRING WASHER
21 TD SOL MQ 4000D-C	S51714D	73	6G466202	PINON BALL BEARING (B)
21 TD SOL MQ 4000D-C	S51714D	74	6G466103	PINON BEARING WASHER (B)
21 TD SOL MQ 4000D-C	S51714D	75	6J387701	PINION BEARING COLLAR
21 TD SOL MQ 4000D-C	S51714D	76	6Q621301	REAR COVER SCREW (A)
21 TD SOL MQ 4000D-C	S51714D	77	6Q779401	BODY
21 TD SOL MQ 4000D-C	S51714D	78	6Q667101	REAR COVER PACKING
21 TD SOL MQ 4000D-C	S51714D	79	6Q667201	REAR COVER
21 TD SOL MQ 4000D-C	S51714D	80	6Q621101	REAR COVER SCREW (B)
21 TD SOL MQ 4000D-C	S51714D	81	6Q609201	OSCILLATING POST COLLAR
21 TD SOL MQ 4000D-C	S51714D	82	6Q126305	OSCILLATING POST
21 TD SOL MQ 4000D-C	S51714D	83	6Q703801	MAIN SHAFT
21 TD SOL MQ 4000D-C	S51714D	84	6J644701	OSCILLATING GEAR WASHER
21 TD SOL MQ 4000D-C	S51714D	85	6Q703701	OSCILLATING GEAR
21 TD SOL MQ 4000D-C	S51714D	86	6G466001	OSCILLATING GEAR O RING
21 TD SOL MQ 4000D-C	S51714D	87	6H129201	OSCILLATING BEARING WASHER
21 TD SOL MQ 4000D-C	S51714D	88	6G469005	OSCILLATING GEAR BALL BEARING
21 TD SOL MQ 4000D-C	S51714D	89	6Q126101	OSCILLATING GEAR SCREW
21 TD SOL MQ 4000D-C	S51714D	90	6G670501	DRIVE O RING
21 TD SOL MQ 4000D-C	S51714D	91	63758502	DRIVE BEARING WASHER
21 TD SOL MQ 4000D-C	S51714D	92	6G467305	DRIVE BALL BEARING (A)
21 TD SOL MQ 4000D-C	S51714D	93	6J571501	BODY COVER O RING
21 TD SOL MQ 4000D-C	S51714D	94	6Q666907	BODY COVER
21 TD SOL MQ 4000D-C	S51714D	95	6G162401	HANDLE CAP O RING
21 TD SOL MQ 4000D-C	S51714D	96	6Q345101	HANDLE CAP
21 TD SOL MQ 4000D-C	S51714D	97	6G522705	DRIVE BALL BEARING (B)
21 TD SOL MQ 4000D-C	S51714D	98	6Q665903	SET PLATE
21 TD SOL MQ 4000D-C	S51714D	99	6Q666001	SET PLATE O RING
21 TD SOL MQ 4000D-C	S51714D	100	6G472401	DRIVE BEARING RETAINER
21 TD SOL MQ 4000D-C	S51714D	101	6H617001	DRIVE BEARING O RING
21 TD SOL MQ 4000D-C	S51714D	102	6Q608906	DRIVE BEARING COVER
21 TD SOL MQ 4000D-C	S51714D	103	6J130201	BEARING COVER PACKING
21 TD SOL MQ 4000D-C	S51714D	104	6Q779801	HANDLE ASSY
21 TD SOL MQ 4000D-C	S51714D	200	6B411703	HANDLE KNOB WASHER
21 TD SOL MQ 4000D-C	S51714D	201	6G720001	HANDLE KNOB BUSHING
21 TD SOL MQ 4000D-C	S51714D	202	6H088709	HANDLE KNOB

