




TD SOL II
SPINNING REEL

TD SOL II 2004/2508/3000H/4000H



Key No.	TD SOL II 2004 Parts No.	Parts Name	TD SOL II 2508 Parts No.	TD SOL II 3000H Parts No.	TD SOL II 4000H Parts No.
1	6H887901	Drag Knob	6H887301	6H887301	6H889101
2	6F742501	Drag Washer Retainer	6F710001	6F710001	6F710001
3	6F908701	Drag Knob Click Plate	6F895301	6F895301	6F895302
4	6F731901	Drag Washer	6F691001	6F691001	6F627101
5	—	Eared Washer	6F755701	6F755701	6F755701
6	—	Key Washer	6H609601	6H609601	6H714001
7	6E306801	Ball Bearing (A)	6E306801	6E306801	—
2-8	6H887601	Spool Assembly	6H887001	6H899301	6H888601
9	6G472401	Bearing Retainer (A)	6G472401	6G472401	6G525101
10	6E306801	Ball Bearing (B)	6E306801	6E306801	6B861704
11	6F625501	Washer (A)	6F625501	6F625501	6G903902
12	6H416001	Click Leaf Spring Holder	6H416001	6H416001	6G694001
13	6H883701	Spool Click Leaf Spring	6H883701	6H883701	6F709002
14	6H601301	Spool Metal	6H601301	6H615001	6H641501
15	6G375001	Pin	6G375001	6G375001	6G224101
16	6H415801	Bearing Retainer (B)	6H415801	6H415801	6H107301
17	6H415701	Packing (A)	6H415701	6H461201	6H505001
18	6G466103	Washer (B)	6G466103	6G466103	—
19	6G466202	Ball Bearing (C)	6G466202	6G466202	6G467102
20	6H444501	Rotor Nut	6H705201	6H705201	6H730901
21	6H806001	Collar (A)	6H806001	6H806101	6H821201
22	6H022701	Screw (A)	6H022701	6H022701	6H022701
23	6H802107	Rotor	6H802008	6H802206	6H640207
24	6H413601	Ball Trip Lever Spring	6H413601	6H413601	6H413601
25	6H443401	Ball Trip Lever	6H413701	6H460301	6H640401
26	6H417701	Screw (B)	6H417701	6H417701	6H417701
27	6H443601	Ball Spring Shaft	6H414101	6H572001	6H640601
28	6H576101	Ball Spring Plate	6H576101	6H576101	6H576101
29	6H442401	Ball Spring	6H545701	6H414201	6H640701
30	6H414301	Ball Spring Holder	6H414301	6H414301	6H414301
31	6H443708	Cover (C)	6H414012	6H460508	6H640806
32	6H443801	Cover (A)	6H414601	6H460601	6H640902
33	6G270801	Screw (C)	6G270801	6G270801	6E248101
34	6H768703	Ball Arm	6H768703	6H728903	6H728903
35	6G205001	Screw (D)	6G205001	6G205001	6B842102
36	6G195602	Screw (E)	6G195602	6G195602	6G195602
37	6F897101	Washer (C)	6F897101	6F897101	6F897101
38	6G281601	Ball Bearing (D)	6G281601	6G281601	6G281601
39	6F921601	Line Roller	6F921601	6F921601	6F921601
40	6G047601	Collar (B)	6G047601	6G047601	6G047601
41	6H768802	Ball Assembly	6H728202	6H883901	6H773702
42	6G205001	Screw (F)	6G205001	6G205001	6B842102
43	6H444301	Cover (B)	6H415101	6H461001	6H641302
44	6G270801	Screw (G)	6G270801	6G270801	6E248101
46	6H532602	Magent Assembly	6H532602	6H532602	6H730701
47	6H413201	Screw (H)	6H413201	6H413201	6H413201
48	6H413001	"O" Ring	6H413001	6H413001	6H639901
50	6H609310	Cover (D)	6H609310	6H609310	6H642502
51	—	Clutch Cam Retainer	—	—	6H665001
52	—	Clutch Cam	—	—	6F641401
53	6H615501	Spacing Sleeve	6H615501	6H615501	6H782301
54	6H412601	Roller Clutch	6H412601	6H412601	6G314501
55	6H442201	Bearing Retainer (C)	6H442201	6H411501	6H509101
56	6E134509	Screw (I)	6E134509	6E134509	6G557101
57	6G467301	Ball Bearing (E)	6G467301	6G535101	6G522801
58	6H596401	Collar (D)	6H596401	6H614401	6H649001
59	6H479101	Collar (E)	6H479101	6H737801	6H775701
60	6H455401	Screw (J)	6H455401	6H455401	6H455401
61	6H886501	Body	6H886501	6H898801	6H888001
62	6H768501	Main Shaft	6H732701	6H614001	6H773301
63	6H596301	Stabilizer Bar	6H596301	6H614301	6H639301
64	6H595501	Anti-Reverse Cam	6H595501	6H595501	6H639001
65	6H595401	Anti-Reverse Lever	6H595401	6H595401	6H595401
66	6H697801	Anti-Reverse Cam Spring	6H697801	6H697801	6H697801
67	6H757202	Rear Cover	6H757202	6H883301	6H773602
68	6G332704	Screw (K)	6G332704	6G332704	6G332704
69	6H595701	Washer (F)	6H595701	6H595701	6G644201
70	6H629101	Oscillating Gear	6H595801	6H613901	6H545301
71	6H770601	"O" Ring (A)	6H770601	6G466001	6B853101
72	6H129200	Washer (G)	6H129200	6H129200	6G522100
73	6G469002	Ball Bearing (F)	6G469002	6G469002	6G467102
74	6G940402	Screw (L)	6G940402	6G940402	6H778001
75	6G670501	"O" Ring (B)	6G670501	6G670501	6G645301
76	6Z020652	Pinion Gear + Drive Gear	6Z020618	6Z020652	6Z020659
77	6G467302	Ball Bearing (G)	6G467302	6G467302	6G523401
78	6H886701	Side Cover	6H886701	6H899001	6H888201
79	6G332904	Screw (M)	6G332904	6G332904	6G332904
80	6G613400	Washer (H)	6G613400	6G613400	6G645600
81	6H597802	Screw (N)	6H597802	6H597802	6H732601
82	6H705101	Packing (B)	6H705101	6H705101	6H730801
83	6G522703	Ball Bearing (H)	6G522703	6G522703	6B861704
84	6G472401	Bearing Retainer (D)	6G472401	6G472401	6G525101
85	6G162401	"O" Ring (C)	6G162401	6G162401	6G672401
86	6H705702	Handle Screw	6H705702	6H705702	6H731502
87	6H887401	Handle Assembly	6H886801	6H899101	6H888301