



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	6H612701	Right side plate	26	6F055601	Ball bearing (C)	51	61214212	Line guide pawl	76	6G040801	Right side plate screw (B)
2	6G819801	Roller clutch	27	6G755201	Washer (C)	52	63731300	Line guide washer	77	6G011601	Front plate
3	6B421601	Bearing retainer (A)	28	63205901	Retainer (C)	53	63424807	Pawl cap	78	6G684801	Washer (E)
4	6B358605	Ball bearing (A)	29	6G790301	Drive shaft retainer	54	6G790901	Clutch wheel	79	6G011702	Stabilizer bar
5	6G894401	Click leaf spring (A)	30	6E134503	Drive shaft retainer screw (A)	55	6G863501	Drive shaft washer	80	6H612901	Left side plate
6	6F744101	Pinion shaft	31	6G850401	Drive shaft retainer screw (B)	56	6G791201	Drive gear	81	6G011902	Left set plate
7	6B175401	Spacer (A)	32	6G794109	Plate (A)	57	6G791301	Eared washer	82	63510906	Left set plate screw
8	6B175503	Spacer (B)	33	6G795709	Plate (B)	58	6G791402	Drag washer (A)	83	6F577802	Brake adjusting knob
9	6H145902	Cast control cap	34	6G318503	Screw (A)	59	6F904902	Key washer (A)	84	6F051701	Brake click spring
10	6G162402	"O" ring	35	6G611501	Screw (B)	60	6H118401	Drag washer (B)	85	6G793501	Set plate screw
11	6H612801	Frame assembly	36	6G790401	Clutch cam spring	61	6G358501	Key washer (B)	86	6G793602	Washer (F)
12	6F834701	Collar	37	6F440201	Washer (D)	62	6G011401	Gear shaft collar	87	6E167101	Set plate spring
13	6G009302	Spacer (C)	38	6F505701	Screw (C)	63	6F582501	Ball bearing (E)	88	6F613401	Brake dial retainer (A)
14	6G009402	Spacer (D)	39	6G790501	Clutch trip plate spring	64	6B553801	Bearing washer	89	6B339801	Brake dial retainer (B)
15	6G431004	Ball bearing (B)	40	6F794801	Yoke	65	6F028201	Click leaf spring holder	90	6F637701	Brake dial washer
16	6F793501	Clutch cam	41	6G850301	Yoke spring	66	6F032401	Click leaf spring (B)	91	6F717702	Magnet holder
17	6G009501	Clutch lever	42	6G790601	Pinion gear	67	61508901	Drag spring washer	92	6B543201	Magnet holder retainer
18	6G790001	Clutch cam plate	43	6G410301	Line guide	68	6G694201	Spacing sleeve	93	6F574303	Spacer (E)
19	6G009701	Clutch cam screw	44	6G010701	Worm shaft holder (A)	69	6H238603	Star drag	94	63757411	Spacer (F)
20	6G790101	Clutch trip plate	45	6G790701	Worm shaft assembly	70	6F850402	Handle collar	95	63757404	Spacer (G)
21	63716906	Washer (A)	46	6G466202	Ball bearing (D)	71	6H475101	Handle assembly	96	6G431102	Ball bearing (F)
22	63201402	Retainer (A)	47	6F836502	Level wind guard	72	6G793301	Handle nut	97	6E219701	Bearing retainer (B)
23	6G850701	Washer (B)	48	6B715601	Worm shaft holder (B)	73	60403206	Handle nut plate	98-109	6Z020354	Spool assembly
24	63205901	Retainer (B)	49	6F655501	Worm shaft washer	74	63538301	Handle nut plate screw			
25	6H537801	Drive shaft	50	63205901	Worm shaft retainer	75	6G040805	Right side plate screw (A)			