

SPINNING REEL

TD-ADVANTAGE 1500A/2000A



| Key No. | Parts No. | Parts Name |
|---------|-----------|------------------------------|
| 1 | H03-9301 | Drag Knob |
| 2 | F74-2501 | Drag Washer Retainer |
| 3 | F90-8701 | Drag knob Click Plate |
| 4 | F63-5001 | Drag Washer |
| 5 | F63-5201 | Eared Washer |
| 6 | F63-5101 | Key Washer |
| 2-7 | H03-9101 | Spool Assembly |
| 2-7 | H03-9101 | Spool Assembly (Extra Spool) |
| 8 | G47-2401 | Collar Retainer |
| 9 | G72-0401 | Collar (A) |
| 10 | F62-5501 | Washer (A) |
| 11 | G69-3901 | Click Leaf Spring Holder |
| 12 | F70-4901 | Spool Click Leaf Spring |
| 13 | G62-7901 | Spool Metal |
| 14 | G62-9602 | Main Shaft |
| 15 | G37-5001 | Pin |
| 16 | G47-1501 | Bearing Retainer (A) |
| 17 | G46-6202 | Ball Bearing (A) |
| 18 | G61-3501 | Collar (B) |
| 19 | G47-1301 | Rotor Nut |
| 20 | G63-0514 | Rotor |
| 21 | G62-7701 | Screw (A) |
| 22 | G19-5601 | Screw (B) |
| 23 | G61-2317 | Bail Arm |
| 24 | G20-5001 | Screw (C) |
| 25 | F89-7101 | Washer (B) |
| 26 | G28-1601 | Ball Bearing (B) |
| 27 | F92-1601 | Line Roller |
| 28 | G04-7601 | Collar (C) |
| 29 | G63-0701 | Bail Assembly |
| 30 | G47-1803 | Bail Spring Shaft |
| 31 | E31-3901 | Washer (C) |
| 32 | G47-1701 | Bail Spring |
| 33 | G61-2101 | Bail Spring Holder |
| 34 | G63-0601 | Cover (A) |
| 35 | G27-0801 | Screw (D) |
| 36 | G63-0901 | Cover (B) |
| 37 | G63-0801 | Bail Trip Lever |
| 38 | G61-3101 | Bail Trip Lever Spring |
| 39 | G61-1201 | Roller Clutch Retainer |

| Key No. | Parts No. | Parts Name |
|---------|-----------|-------------------------|
| 40 | G55-7101 | Screw (E) |
| 41 | G46-5401 | Clutch Cam Retainer |
| 42 | G22-0601 | Roller Clutch |
| 43 | G46-7501 | Spacing Sleeve |
| 44 | G46-7402 | Bearing Retainer (B) |
| 45 | G55-7101 | Screw (F) |
| 46 | 375-8509 | Washer (D) |
| 47 | G53-5101 | Ball Bearing (C) |
| 48 | G63-0001 | Pinion Gear |
| 49 | G61-0901 | Collar (D) |
| 50 | H03-8901 | Body |
| 51 | G61-1801 | Brake Shoe |
| 52 | F50-5701 | Screw (G) |
| 53 | G60-9921 | Anti-Reverse Lever |
| 54 | G62-7801 | Anti-Reverse Cam Spring |
| 55 | G62-9901 | Stabilizer Bar |
| 56 | G63-0406 | Rear Cover |
| 57 | 351-1801 | Screw (H) |
| 58 | G61-0103 | Washer (E) |
| 59 | G62-9501 | Oscillating Gear |
| 60 | G46-6001 | "O" Ring (A) |
| 61 | G46-6301 | Screw (I) |
| 62 | G46-7302 | Ball Bearing (D) |
| 63 | G67-0501 | "O" Ring (B) |
| 64 | G69-9002 | Drive Gear |
| 65 | G63-0206 | Side Cover |
| 66 | G46-8301 | Screw (J) |
| 67 | G61-3400 | Washer (F) |
| 68 | G61-2401 | Screw (K) |
| 69 | G63-0301 | Bearing Retainer (C) |
| 70 | G61-1501 | Screw (L) |
| 71 | F72-1001 | Collar (E) |
| 72 | G61-4302 | Handle Screw |
| 73 | G63-0101 | Bearing Retainer (D) |
| 74 | H03-9001 | Handle Assembly |
| 75 | G46-6100 | Washer (G) |
| 76 | G46-6202 | Ball Bearing (E) |
| 77 | 160-8101 | Washer (H) |
| 78 | F89-6801 | Clutch Cam |
| 79 | F83-3000 | Washer (I) |

| Key No. | Parts No. | Parts Name |
|---------|-----------|------------------------------|
| 2-7 | H03-9401 | Spool Assembly |
| 2-7 | H03-9401 | Spool Assembly (Extra Spool) |