


TEAM DAIWA – ADVANTAGE 153HST



| Key No. | Parts No. | Parts Name |
|---------|-----------|------------------------|
| 1 | G54-5503 | L/S PLT |
| 2 | F82-1210 | BRAKE ADJ KNOB |
| 3 | F05-1701 | BRAKE CLICK SPRING |
| 4 | F21-2201 | SET PLT SCREW |
| 5 | G54-5701 | MAGNET HOLDER |
| 6 | 375-7404 | SPACER A |
| 7 | 375-7411 | SPACER B |
| 8 | 637-4601 | BALL BEARING A |
| 9 | F03-2201 | BEARING RET A |
| 10-20 | Z01-3327 | SPOOL |
| 21 | G54-3006 | FRAME |
| 22 | G54-3401 | CLUTCH LEVER PLT A |
| 23 | G54-3601 | CLUTCH LEVER |
| 24 | G54-3501 | CLUTCH LEVER PLT B |
| 25 | 320-5901 | WORM SHAFT RET |
| 26 | 373-1306 | WORM SHAFT WASHER |
| 27 | G54-4801 | LEVEL WIND GUARD |
| 28 | G54-4301 | LINE GUIDE |
| 29 | 121-4212 | LINE GUIDE PAWL |
| 30 | 373-1303 | LINE GUIDE WASHER |
| 31 | F40-2801 | PAWL CAP |
| 32 | G12-8201 | WORM SHAFT COLLAR |
| 33 | G54-4601 | WORM SHAFT |
| 34 | G54-5401 | STABILIZER BAR |
| 35 | G54-5303 | FRONT PLT |
| 36 | B36-0401 | FRONT PLT SCREW |
| 37 | F83-4701 | BALL BEARING COLLAR |
| 38 | B86-1701 | BALL BEARING B |
| 39 | F79-3501 | CLUTCH CAM A |
| 40 | G54-3701 | CLUTCH CAM B |
| 41 | G54-4101 | CLUTCH CAM SPRING |
| 42 | G00-9701 | CLUTCH CAM SCREW |
| 43 | G54-3801 | CLUTCH TRIP PLT |
| 44 | 371-6907 | CLUTCH TRIP PLT WASHER |
| 45 | 320-1402 | CLUTCH TRIP PLT RET |
| 46 | F79-4801 | YOKE |
| 47 | G59-7301 | YOKE SPRING |
| 48 | G54-4201 | PINION GEAR |
| 49 | E21-9701 | BEARING RET B |
| 50 | G46-6202 | BALL BEARING C |
| 51 | G54-2704 | R/S PLT |

| Key No. | Parts No. | Parts Name |
|---------|-----------|--------------------------|
| 52 | G04-0801 | R/S PLT SCREW A |
| 53 | G47-3501 | R/S PLT SCREW B |
| 54 | B85-3101 | O RING A |
| 55 | B91-1746 | R/S PLT SCREW C |
| 56 | F80-0501 | PINION SHAFT |
| 57 | 171-5201 | O RING B |
| 58 | B17-5401 | SPOOL ADJ CAP METAL |
| 59 | B17-5503 | RUBBER WASHER |
| 60 | F57-4402 | CAST CONTROL CAP |
| 61 | G35-7506 | DRIVE SHAFT WASHER |
| 62 | F05-5601 | BALL BEARING D |
| 63 | G54-3901 | DRIVE SHAFT |
| 64 | G54-4001 | DRIVE SHAFT RET |
| 65 | E13-4508 | DRIVE SHAFT RET SCREW |
| 66 | G01-0201 | CLUTCH TRIP PLT SPRING |
| 67 | F76-1701 | A/R RATCHET |
| 68 | G00-1501 | DRIVE GEAR A |
| 69 | G54-4901 | DRIVE GEAR B |
| 70 | F79-6101 | EARED WASHER |
| 71 | G42-8501 | DRAG WASHER |
| 72 | F79-6301 | KEY WASHER |
| 73 | G45-5801 | DRAG WASHER B |
| 74 | G14-1801 | KEY WASHER B |
| 75 | G54-5001 | GEAR SHAFT COLLAR |
| 76 | F99-9803 | ROLLER CLUTCH |
| 77 | F58-2501 | BALL BEARING D |
| 78 | B55-3801 | BEARING WASHER |
| 79 | F02-8201 | CLICK LEAF SPRING HOLDER |
| 80 | F03-2401 | CLICK LEAF SPRING HOLDER |
| 81 | 150-8901 | DRAG SPRING WASHER |
| 82 | 373-7810 | SPACING SLEEVE |
| 83 | F57-6506 | STAR DRAG |
| 84 | F57-6601 | FRICTION WASHER |
| 85 | G54-5101 | HANDLE |
| 86 | F30-6400 | HANDLE KNOB WASHER |
| 87 | G54-5201 | HANDLE KNOB |
| 88 | F28-3101 | BALL BEARING F |
| 89 | B67-9308 | HANDLE KNOB SCREW |
| 90 | G55-1901 | HANDLE KNOB CAP |
| 91 | F83-7402 | HANDLE NUT |
| 92 | F57-7202 | HANDLE NUT PLT |