


SPINNING REEL

TEAM DAIWA FUEGO 2000



| Key No. | Parts No. | Parts Name | Key No. | Parts No. | Parts Name |
|---------|-----------|--------------------------|---------|-----------|-------------------------|
| 1 | G70-3001 | DRAG KNOB | 41 | G22-0601 | ROLLER CLUTCH |
| 2 | F74-2501 | DRAG WASHER RET | 42 | F89-1202 | ROLLER CLUTCH WASHER |
| 3 | F90-8701 | DRAG KNOB CLICK PLT | 43 | F84-6503 | SPACING SLEEVE |
| 4 | F63-5001 | DRAG WASHER | 44 | G27-9601 | BALL BEARING D |
| 5 | F63-5201 | EARED WASHER | 45 | F63-3503 | PINION GEAR COLLAR |
| 6 | F63-5101 | KEY WASHER | 46 | G56-6301 | PINION GEAR |
| 2-7 | G77-3701 | SPOOL | 47 | G27-9701 | ROLLER CLUTCH COVER |
| 8 | F76-5901 | O RING A | 48 | G70-2401 | BODY |
| 9 | F01-6401 | BALL BEARING A | 49 | F63-1401 | WORM SHAFT BUSH |
| 10 | F70-4901 | SPOOL CLICK LEAF SPRING | 50 | F91-0301 | WORM SHAFT |
| 11 | F62-5501 | SPOOL WASHER | 51 | 375-4101 | WORM SHAFT WASHER |
| 12 | F62-5401 | CLICK LEAF SPRING HOLDER | 52 | F63-1501 | WORM SHAFT COLLAR |
| 13 | F62-5301 | SPOOL METAL | 53 | F89-0902 | WORM SHAFT RET |
| 14 | G37-5001 | PIN | 54 | F89-1601 | OSC SLIDER |
| 15 | G28-1002 | MAIN SHAFT | 55 | F89-1701 | OSC PAWL |
| 16 | F97-9301 | ROTOR NUT | 56 | F91-3001 | OSC PAWL BUSH |
| 17 | B55-7604 | ROTOR NUT LOCK SCREW | 57 | 375-0801 | OSC PAWL WASHER |
| 18 | F94-5110 | ROTOR | 58 | F62-2901 | OSC SLIDER COVER |
| 19 | F92-1701 | LINE ROLLER SCREW | 59 | E15-0205 | OSC SLIDER COVER SCREW |
| 20 | F89-2236 | BAIL ARM | 60 | F89-0502 | STABILIZER BAR |
| 21 | F89-7101 | LINE ROLLER WASHER | 61 | F98-6701 | A/R CAM SPRING |
| 22 | G47-0901 | LINE ROLLER | 62 | F89-0313 | A/R LEVER |
| 23 | G28-1601 | BALL BEARING B | 63 | F01-6401 | BALL BEARING E |
| 24 | G47-1101 | O RING B | 64 | F05-5705 | DRIVE GEAR |
| 25 | G77-3501 | BAIL | 65 | 375-8500 | DRIVE GEAR WASHER |
| 26 | 351-7701 | BAIL HOLDER SCREW | 66 | 636-6403 | BALL BEARING F |
| 27 | F89-2301 | BAIL SPRING SHAFT | 67 | F88-9808 | SIDE COVER |
| 28 | E31-3901 | BAIL SPRING WASHER | 68 | G28-1301 | REAR COVER SCREW COLLAR |
| 28 | E31-3901 | BAIL SPRING WASHER | 69 | 351-1009 | SIDE COVER SCREW |
| 29 | F89-2401 | BAIL SPRING | 71 | F72-1001 | HANDLE COLLAR |
| 30 | F89-2601 | BAIL SPRING COVER | 72 | 160-8101 | LOCK WASHER |
| 31 | 351-1801 | BAIL SPRING COVER SCREW | 73 | G61-4301 | HANDLE SCREW |
| 32 | F90-8101 | BAIL TRIP COVER | 74 | G77-3601 | HANDLE |
| 33 | F72-7201 | BAIL TRIP LEVER | 75 | F97-9401 | ROTOR NUT WASHER |
| 34 | F62-4601 | BAIL TRIP PLT | 76 | G04-7901 | BAIL HOLDER WASHER |
| 35 | F89-1402 | BEARING RET | 77 | G47-8001 | BALL BEARING COLLAR |
| 36 | 351-7707 | BEARING RET SCREW | 80 | F89-2003 | REAR COVER SHIELD |
| 37 | G28-0101 | BALL BEARING C | 81 | F89-2105 | REAR COVER |
| 38 | G28-0001 | BALL BEARING COLLAR | 82 | G28-1401 | REAR COVER SCREW WASHER |
| 39 | G27-9901 | CLUTCH CAM RET | 83 | G28-2001 | REAR COVER SCREW |
| 40 | F89-6802 | CLUTCH CAM | | | |