


SPINNING REEL 402A



| Key No. | Parts No. | Parts Name | Key No. | Parts No. | Parts Name |
|---------|------------|------------------------|---------|------------|--------------------------|
| 1 | 6-441-3501 | Drag knob | 15 | 6-160-0121 | Bail washer |
| 2 | 6-374-7901 | Drag washer | 16 | 6-341-9902 | Bail nut |
| 3 | 6-730-8001 | Spool | 17 | 6-725-6701 | Bail |
| 4 | 6-374-6400 | Spool washer | 18 | 6-352-0402 | Bail holder screw |
| 5 | 6-711-1501 | Main shaft | 19 | 6-632-4011 | Pinion retainer |
| 6 | 6-480-5101 | Oscillating slider | 20 | 6-700-8403 | Body |
| 7 | 6-490-4411 | Oscillating slider pin | 21 | 6-111-5501 | Anti-reverse claw |
| 8 | 6-736-3803 | Rotor | 22 | 6-144-6111 | Anti-reverse claw spring |
| 9 | 6-142-5711 | Bail kick lever spring | 23 | 6-350-1931 | Anti-reverse claw screw |
| 10 | 6-570-6511 | Bail kick lever | 24 | 6-373-0100 | Drive gear washer |
| 11 | 6-352-1101 | Bail kick lever screw | 25 | 6-412-8901 | Drive gear |
| 12 | 6-140-9231 | Bail spring | 26 | 6-706-3804 | Body cover |
| 13 | 6-231-1001 | Arm lever | 27 | 6-351-6401 | Body cover screw |
| 14 | 6-362-3411 | Arm lever screw | 28 | 6-746-4801 | Handle |