


**SPINNING REEL 403A**



**KEY NO. 2 ~ 8**

**6-732-2001**

**SPOOL ASSEMBLY**

Key No.	Parts No.	Parts Name
1	6-740-3002	Drag knob
2	6-170-4001	Drag washer retainer
3	6-374-7901	Drag D washer
4	6-370-6901	Disc washer
5	6-375-5302	Drag A washer
* 6	6-513-0311	Spool
7	6-141-1611	Spool click claw
8	6-320-9701	Spool click claw retainer
9	6-374-6401	Spool washer
10	6-374-6400	Spool adjusting washer
11	6-711-1801	Main shaft
12	6-481-1601	Oscillating slider
13	6-490-4301	Oscillating slider pin
14	6-340-6602	Rotor nut
15	6-160-1612	Rotor washer
16	6-201-9003	Rotor
17	6-570-9511	Bail kick lever
18	6-140-6231	Bail kick lever spring
19	6-361-1512	Bail kick lever screw

Key No.	Parts No.	Parts Name
20	6-140-9231	Bail spring
21	6-230-7011	Arm lever
22	6-363-1311	Arm lever screw
23	6-341-9901	Bail nut
24	6-160-0121	Bail washer
25	6-250-3821	Line roller
26	6-725-6801	Bail
27	6-352-0401	Bail holder screw
28	6-371-6400	Pinion washer
29	6-402-6511	Pinion gear
30	6-700-8905	Body
31	6-413-5311	Drive gear
32	6-371-2800	Drive gear washer
33	6-706-4004	Body cover
34	6-111-5501	Anti-reverse claw
35	6-144-6111	Anti-reverse claw spring
36	6-350-1931	Anti-reverse claw screw
37	6-351-8501	Body cover screw
38	6-746-5301	Handle

\*Not sold separately. See Spool Assembly.