



PART NO.	DESCRIPTION	PRICE	PART NO.	DESCRIPTION	PRICE	PART NO.	DESCRIPTION	PRICE
270/1	Brake Nut, Complete	\$2.25	270/47	Worm Wheel with Pin No. 49	\$2.10	270/104	Driving Wheel	\$2.00
270/4	Line Spool, without Brake Nut (Specify Deep or Shallow)	\$5.00	270/48	Roller	\$.15	270/105	Driving Wheel	\$2.00
270/9	Washer (Resitex)	\$.10	270/49	Screw for Roller	\$.15	270/106	Pin for Driving Shaft	\$.10
270/9A	Washer (Metal)	\$.10	270/58	Crank Arm	\$2.50	270/107	Washer	\$.10
270/10K	Axle, Complete	\$1.50	270/59	Handle Grip	\$.50	270/108	Safety Washer	\$.10
270/11	Ratchet Wheel	\$.25	270/60	Grip Screw	\$.60	270/109	Counter Nut	\$.50
270/12	Pin for Ratchet Wheel	\$.10	270/61	Pin for Crank Arm	\$.15	270/110	Spring Washer	\$.10
270/14	Screw for Slide	\$.10	270/69	Ratchet	\$.15	270/111	Crank Arm, Complete	\$4.00
270/15	Flange, with Parts No. 22 & 23	\$4.25	270/72	Line Guide	\$2.75	270/112	Coupling Box	\$4.25
270/16	Driving Washer	\$.25	270/74	Spring Washer	\$.10	270/113	Driving Wheel	\$2.50
270/17	Hexagon Nut	\$.25	270/82	Pick-up Arm	\$4.50	270/114	Pin for Coupling Box	\$.10
270/19	Lug Screw	\$.40	270/83	Angle Lever	\$1.30	270/115	Washer (Resitex)	\$.10
270/20	Stop Pin	\$.10	270/85	Spring Ring	\$.10	270/116	Spring Washer	\$.15
270/21	Spring	\$.15	270/86	Tongue Washer	\$.15	270/117	Coupling Wheel	\$3.50
270/22	Counter Weight	\$.60	270/87	Washer (Resitex)	\$.10	270/118	Coupling Wheel	\$3.00
270/23	Screw for Counter Weight	\$.10	270/88	Tongue Washer	\$.15	270/119	Guide Ring	\$.30
270/24	Rubber Buffer with Spring	\$.15	270/89	Ratchet Spring	\$.15	270/120	Tongue Washer	\$.10
270/25	Bearing Screw	\$.35	270/90	Pin for Ratchet	\$.10	270/121	Safety Washer	\$.10
270/28	Lock Washer	\$.10	270/91	Cork Ring (2 Halves)	\$.30	270/122	Coupling Shaft, Complete with Part No. 123 through 127 (Part Numbers 123-126 are No Longer Available Separately)	\$3.50
270/29	Hexagon Nut	\$.15	270/92	Washer	\$.10	270/127	Spring for Taper Key	\$.15
270/30	Screw for Angle Lever	\$.10	270/93	Case with Bushing and Anti-Reverse Clutch But without Reel Stand	\$7.00	270/128	Change Button	\$.25
270/31	Spacing Bushing	\$.25	270/95	Anti-Reverse Clutch Spring	\$.15	270/129	Pin for Change Button	\$.15
270/32	Changing Spring	\$.25	270/96	Pin for Drag Lever	\$.15	270/130	Slide	\$.60
270/34	Cap for Pick-up Arm	\$.15	270/97	Drag Lever	\$.25	270/131	Driving Shaft	\$5.25
270/35	Bearing Screw	\$.25	270/98	Eccentric Bolt	\$.60	270/132	Plate Cover with Bushing	\$2.00
270/37	Ball Bearing	\$3.00	270/99	Lever for Anti-Reverse Clutch	\$.35	270/133	Screw for Cover	\$.15
270/39	Screw for Switch Ring	\$.15	270/100	Nut	\$.35	270/134	Stop Lever	\$.50
270/41	Bearing Bushing	\$.30	270/101	Screw for Cover	\$.15	270/135	Switch Ring	\$.40
270/42	Reel Stand	\$2.00	270/102	Case Cover with Bushing and Oiler	\$5.00	270/136	Braking Ring	\$.30
270/43	Cone Screw	\$.50	270/103	Driving Shaft	\$.50	270/137	Gasket	\$.10

Part numbers 270/18 and 270/38 have been replaced by part numbers 270/134 and 270/135 in conjunction with the introduction of new spare part numbers 270/136 and 270/137. The new bail switch, which is designed to prevent the pick-up arm from tripping prematurely during the cast, can also be used on earlier models of this reel. Part number 270/38 must be exchanged for part numbers 270/135, 270/136 and 270/137. Part number 270/18 must be exchanged for part number 270/134.