

SPARE PARTS CATALOG AND PRICE LIST

FIGURE NUMBER	PART NUMBER	DESCRIPTION	1000	1400	2000	3000	4000	5000	FIGURE NUMBER	PART NUMBER	DESCRIPTION	1000	1400	2000	3000	4000	5000	
0	103-310	TENSION SPRING	X						47	103-506	CASE COVER SCREW		X					
0	100-016	TENSION SPRING		X	X	X	X	X	47	103-500	CASE COVER SCREW			X	X	X		
1	100-019	LINE GUIDE	X						47	103-502	CASE COVER SCREW							X
1	100-020	LINE GUIDE		X	X	X	X	X	48	103-603	ROTATING HEAD	X						
3	104-060	PLANE NUT	X						48	103-604	ROTATING HEAD		X	X				
3	104-071	HEXAGON NUT		X	X	X	X	X	48	103-605	ROTATING HEAD				X			
4	100-028	PINHEAD SCREW	X						48	103-606	ROTATING HEAD							X
5	100-043	PIN	X						48	103-607	ROTATING HEAD							X
5	100-044	TENSION PIN		X	X	X	X		55	103-937	ANGLE LEVER	X						
5	100-036	TENSION PIN						X	55	103-948	ANGLE LEVER	X	X	X	X	X	X	
6	100-049	GRIP SCREW	X						57	103-966	BEARING SCREW	X						
6	104-000	GRIP SCREW		X	X				57	103-965	BEARING SCREW	X	X	X	X	X	X	
6	104-001	GRIP SCREW				X	X		58	104-064	HEXAGON NUT	X						
6	104-002	GRIP SCREW						X	58	104-065	HEXAGON NUT		X	X	X	X		
7	100-062	BAIL SPRING	X						58	104-066	HEXAGON NUT							X
7	103-342	BAIL SPRING					X	X	59	104-087	BAIL ARM COMPLETE	X						
7	103-343	BAIL SPRING						X	59	104-088	BAIL ARM COMPLETE		X	X				
7	103-344	BAIL SPRING						X	59	104-089	BAIL ARM COMPLETE				X			
8	103-255	WASHER	X	X	X				59	104-090	BAIL ARM COMPLETE						X	
8	104-358	WASHER		X	X	X	X	X	59	104-092	BAIL ARM COMPLETE					X		
9	100-072	SAFETY DISC		X	X	X	X		59	104-093	BAIL ARM COMPLETE						X	
9	103-801	SAFETY DISC						X	59	104-091	BAIL ARM COMPLETE							X
10	104-362	WASHER		X	X	X	X		62	104-168	SPOOL	X						
10	104-363	WASHER						X	62	104-172	SPOOL		X					
12	100-078	SAFETY RING		X	X	X	X		62	104-169	SPOOL			X				
14	104-366	WASHER	X					X	62	104-170	SPOOL				X			
14	100-088	WASHER		X	X	X	X	X	62	104-171	SPOOL					X		
15	104-367	WASHER	X						63	104-199	SPOOL						X	
15	100-097	WASHER		X	X	X	X		64	104-266	RATCHET	X	X	X	X	X	X	X
15	104-350	WASHER						X	65	104-280	PIN	X	X	X	X	X	X	X
16	100-098	WASHER		X	X	X	X	X	66	104-327	SAFETY RING	X						
18	103-130	PINION BEARING	X	X					66	104-326	SAFETY RING		X	X	X	X	X	X
18	100-353	PINION BEARING			X	X	X		67	104-341	RATCHET WHEEL							X
18	100-132	PINION BEARING						X	67	104-342	RATCHET WHEEL							X
19	100-134	CRANK NUT		X	X	X	X		68	104-452	BRAKE NUT COMPLETE	X						
19	104-810	CRANK NUT						X	68	104-450	BRAKE NUT COMPLETE		X	X	X	X		
20	100-139	HANDLE GRIP	X						68	104-451	BRAKE NUT COMPLETE							X
20	104-887	HANDLE GRIP		X	X				69	104-494	BRAKE SPINDLE CPL.	X						
20	104-888	HANDLE GRIP					X	X	69	104-495	BRAKE SPINDLE CPL.		X					
20	104-889	HANDLE GRIP						X	69	104-490	BRAKE SPINDLE CPL.			X				
21	104-902	BALL BEARING	X						69	104-491	BRAKE SPINDLE CPL.				X	X		
21	104-901	BALL BEARING		X	X	X	X		70	104-575	DRIVING GEAR CPL.	X						
21	100-177	BALL BEARING						X	70	104-576	DRIVING GEAR CPL.		X					
22	103-852	SPRING WASHER	X						70	104-572	DRIVING GEAR CPL.			X				
22	103-849	SPRING WASHER		X	X	X	X	X	70	104-573	DRIVING GEAR CPL.				X	X		
23	104-365	WASHER	X						70	104-574	DRIVING GEAR CPL.							X
23	101-156	WASHER		X	X	X	X		71	104-693	DRIVE SHAFT	X						
23	100-556	WASHER						X	71	104-703	DRIVE SHAFT		X					
24	103-855	SPRING WASHER	X						71	104-695	DRIVE SHAFT			X	X	X		X
24	101-154	SPRING WASHER		X	X	X	X		71	104-696	DRIVE SHAFT							
24	100-557	SPRING WASHER						X	73	104-796	BEARING COVER CPL.		X					
25	103-804	SNAP RING	X						73	104-797	BEARING COVER CPL.			X	X	X		
25	101-155	SNAP RING		X	X	X	X		73	104-798	BEARING COVER CPL.							X
25	100-558	SNAP RING						X	74	104-867	CRANK ARM COMPLETE	X						
26	103-851	SPRING WASHER		X	X	X	X		74	104-868	CRANK ARM COMPLETE		X					
26	100-560	SPRING WASHER						X	74	104-869	CRANK ARM COMPLETE			X				
26	104-292	PIN FOR SLIDE			X	X	X		74	100-208	CRANK ARM COMPLETE				X			
26	104-291	PIN FOR SLIDE						X	74	104-865	CRANK ARM COMPLETE					X		
26	104-290	PIN FOR SLIDE		X					74	104-866	CRANK ARM COMPLETE						X	
26	103-225	STOP LEVER INTERNAL	X						75	104-990	AXLE COMPLETE	X						
26	103-226	STOP LEVER INTERNAL		X					75	104-997	AXLE COMPLETE		X					
26	103-224	STOP LEVER INTERNAL			X			X	75	104-991	AXLE COMPLETE			X				
26	103-221	STOP LEVER INTERNAL				X	X		75	104-992	AXLE COMPLETE				X	X		
26	103-222	STOP LEVER INTERNAL						X	75	104-993	AXLE COMPLETE							X
26	103-014	HOUSING COMPLETE	X						77	105-020	SLIDE	X						
26	103-015	HOUSING COMPLETE			X				77	105-026	SLIDE-LEFT		X					
26	103-016	HOUSING COMPLETE				X	X		77	105-021	SLIDE			X				
26	103-017	HOUSING COMPLETE						X	77	105-025	SLIDE-LEFT				X			
26	103-026	HOUSING COMPLETE		X					77	105-022	SLIDE					X	X	
26	103-250	EXCENTER WHEEL	X	X	X	X	X	X	77	105-024	SLIDE-LEFT					X	X	
26	103-264	METAL WASHER	X						77	105-023	SLIDE							X
26	103-261	METAL WASHER		X	X	X	X		77	105-027	SLIDE-LEFT							X
26	103-262	METAL WASHER						X	77	105-030	SLIDE COMPLETE	X						
26	103-278	DRIVING PLATE	X						80	103-291	BRAKE DISC				X	X	X	
26	103-270	DRIVING PLATE		X	X	X	X		80	103-294	BRAKE DISC		X	X				
26	103-277	DRIVING PLATE	X						100	104-136	COVER			X	X			
26	103-276	DRIVING PLATE		X	X				100	104-134	COVER					X	X	
26	103-274	DRIVING PLATE				X	X		100	104-135	COVER							X
26	103-275	DRIVING PLATE						X	101	104-133	SLIDING COVER		X	X	X	X	X	X
26	103-293	BRAKE DISC	X						102	103-919	STOP LEVER EXTERNAL	X						
26	103-295	BRAKE DISC		X	X	X	X	X	102	103-925	STOP LEVER EXTERNAL		X	X				
26	103-300	BRIDGE PLATE		X	X	X	X	X	102	103-926	STOP LEVER EXTERNAL				X			
26	103-312	TENSION SPRING	X	X	X	X	X	X	102	103-927	STOP LEVER EXTERNAL							X
26	103-360	ANTI-REVERSE LEVER	X					X	102	103-928	STOP LEVER EXTERNAL							X
26	103-365	ANTI-REVERSE LEVER		X				X	103	104-152	SLIDING BRAKE LEVER		X	X				
26	103-366	ANTI-REVERSE LEVER						X	103	104-151	SLIDING BRAKE LEVER					X	X	X
26	103-394	COVER COMPLETE	X						104	104-147	NOISE DAMPER		X	X	X	X	X	X
26	103-403	COVER COMPLETE		X					105	103-312	TENSION SPRING		X	X				
26	103-405	COVER COMPLETE			X				105	103-313	TENSION SPRING					X	X	X
26	103-406	COVER COMPLETE				X	X		106	103-314	TENSION SPRING			X	X	X	X	X
26	103-407	COVER COMPLETE						X	107	104-148	BRAKE RING	X						
26	103-408	COVER COMPLETE		X					107	104-149	BRAKE RING		X	X				
26	103-409	COVER COMPLETE				X	X		107	104-146	BRAKE RING					X	X	X
26	103-410	COVER COMPLETE						X	108	100-223	HIGH SPEED SIGN		X	X	X	X	X	X
26	103-411	COVER COMPLETE						X	109	103-519	COUNTER WEIGHT SCREW	X						
26	103-412	COVER COMPLETE						X	109	103-504	COUNTER WEIGHT SCREW		X	X	X	X	X	X
26	103-413	COVER COMPLETE						X	110	103-346	STRAIGHT SPRING		X					
26	103-414	COVER COMPLETE						X	110	103-347	STRAIGHT SPRING			X				
26	103-415	COVER COMPLETE						X	110	103-349	STRAIGHT SPRING					X	X	X
26	103-416	COVER COMPLETE						X	111	103-289	BEARING DISC		X	X	X	X	X	X
26	103-417	COVER COMPLETE						X	112	104-140	COVER CAP		X	X				
26	103-418	COVER COMPLETE						X	113	103-621	COUNTER WEIGHT	X						
26	103-419	COVER COMPLETE						X	113	103-622	COUNTER WEIGHT		X					
26	103-420	COVER COMPLETE						X	113	103-623	COUNTER WEIGHT			X	X	X	X	
26	103-421	COVER COMPLETE						X										