



23a	Pinion gear	213	Lower gear housing
223	Key springs	57	Handle screw
214	Upper gear housing	224	Cover screw
58	Handle washer	215	Button cover
225	Main gear bearing	68	Ball bearing
216	Change speed button	226	Main gear bearing
88	Centering pins	217	Change speed shaft1
228	Ball bearing	89	Allen screw
220	Key	230	Button springs
101	High speed main gear	221	Key shaft
102	Low speed main gear	222	Internal screw

