

MC1SH

Key #	Description	Order ID #		Key #	Description	Order ID #
1	FRAME	DY-103570130		60	CLICK PLATE RETAINER	DY-101543012
2	CLUTCH BAR PLATE-R	DY-102881010		61	TENSION WASHER	DY-100073011
3	CLUTCH BAR PLATE-L	DY-102882010		62	SPOOL SPACER-B	DY-100074011
4	CLUTCH BAR	DY-102707010		66	GEAR SIDE COVER SCREW-A	DY-100202020
6	CLUTCH BAR SCREW	DY-101507010		67	GEAR SIDE COVER SCREW-B	DY-100202020
7	LEVEL WIND ASSEMBLY	DY-103522010		69	LUBE PORT CAP	DY-101698010
8	PIPE	DY-101406010		70	LUBE PORT CAP SCREW	DY-101507030
9	WORM SHAFT	DY-100017013		71	DRAG SPRING WASHER	DY-100088010
10	BALL BEARING	DY-102954010		72	CLICK HOLDER	DY-101765010
11	WORM SHAFT BUSHING-A	DY-102438010		73X	STAR DRAG COMPLETE	DY-U02932342
12	IDLER-S	DY-100019010		74	CLICK LEAF SPRING	DY-101763010
13	WORM SHAFT PIN	DY-100020010		75	CLICK PLATE-B	DY-101764010
16	WORM SHAFT WASHER	DY-100539010		76	CLICK PLATE RETAINER	DY-101766011
17	E-RING	DY-100047010		77	HANDLE WASHER	DY-100933010
18	PILLAR	DY-102711010		78X	HANDLE COMPLETE	DY-103813020
19	LEVEL WIND PIN	DY-100464011		79	BALL BEARING	DY-102950010
20	SPACER(OPTIONAL)	DY-100025020		80	HANDLE KNOB	DY-104030010
21	LEVEL WIND NUT	DY-100288021		81	BALL BEARING	DY-102950010
22	FRONT COVER	DY-103573070		82	HANDLE KNOB SCREW	DY-100180010
23	FRONT COVER SCREW	DY-100141020		83	HANDLE KNOB CAP	DY-101851120
24	BALL BEARING	DY-102970010		85	HANDLE NUT	DY-100319200
25	CRANK SHAFT	DY-100043012		86	HANDLE NUT RETAINER	DY-103642090
26	IDLER-L WASHER-A	DY-100548010		87	SCREW	DY-101202020
27	IDLER-L	DY-101938020		88X	SPOOL COMPLETE	DY-103512090
28	IDLER-L WASHER-B	DY-100045020		89	BALL BEARING	DY-102366010
29	BEARING PLATE	DY-103586010		90	PIN	DY-100120010
30	E-RING	DY-100047010		91	BRAKE HOLDER	DY-103532010
31	BEARING PLATE SCREW	DY-100135010		92	BRAKE SHOE	DY-100522010
33	CLUTCH CAM	DY-103582010		93	BRAKE SHOE SPRING	DY-100525010
34	CLUTCH SPRING	DY-102688010		94	MAGNET PLATE	DY-103533013
35	KICK LEVER	DY-102307011		95	MAGNET PLATE SCREW	DY-100526010
36	KICK LEVER SPRING	DY-102048010		96X	PALM SIDE PLATE ASSEMBLY	DY-UB3577100
38	CAM PLATE SCREW	DY-100293010		98	CONTROL DIAL	DY-102917010
39	PINION YOKE	DY-102073010		99	SPOOL COVER ASSEMBLY	DY-103580010
40	PINION GEAR	DY-103616010		100	MAGNET HOLDER ASSEMBLY	DY-U03539010
41	PINION YOKE SPRING	DY-102465010		105	SPOOL COVER SCREW	DY-100141010
42	RATCHET	DY-100818010		106	SPOOL SPACER-A	DY-101850010
43	RATCHET WASHER	DY-103772010		107	BALL BEARING	DY-102971010
44	DRIVE GEAR	DY-102871010		108	BEARING RETAINER	DY-102976010
45	DRAG WASHER-L	DY-102377010		114	WASHER(OPTIONAL)	DY-100073011
46	DRAG WASHER-D1	DY-100057020		120	BRAKE PLATE HOLDER ASSEMBLY	DY-103559010
47	DRAG WASHER-A	DY-100985010		121	SLIDE CAM SPRING	DY-102665010
48	DRAG WASHER-D2	DY-100986011		122	SLIDE CAM-H	DY-103342010
49	SLEEVE WASHER(OPTIONAL)	DY-100086030		123	SLIDE CAM SCREW	DY-100526020
50	SLEEVE	DY-101983010		124	SLIDE CAM-D	DY-102394010
51X	GEAR SIDE PLATE ASSEMBLY	DY-U03575180		125	CLICK SPRING	DY-102002010
53	ONE WAY CLUTCH	DY-102090010		127	LINK PLATE	DY-102894010
54	O-RING	DY-100209020		128	LINK PLATE SCREW	DY-103014010
55	BALL BEARING	DY-102971010		141	HOOD	DY-103571020
56	BEARING RETAINER	DY-101588011		142	HOOD SCREW	DY-103639010
57X	CAST CONTROL CAP ASSEMBLY	DY-U02254111		143	FRONT COVER SCREW-B	DY-100135010
58	CLICKER	DY-101674011		144	LOCK LEVER	DY-103581011
59	CLICK PLATE	DY-101675011		151	LOCK LEVER SPRING	DY-104100010

MC1SHL

Key #	Description	Order ID #		Key #	Description	Order ID #
1	FRAME	DY-103590130		60	CLICK PLATE RETAINER	DY-101543012
2	CLUTCH BAR PLATE-R	DY-102881010		61	TENSION WASHER	DY-100073011
3	CLUTCH BAR PLATE-L	DY-102882010		62	SPOOL SPACER-B	DY-100074011
4	CLUTCH BAR	DY-102707010		66	GEAR SIDE COVER SCREW-A	DY-100202020
6	CLUTCH BAR SCREW	DY-101507010		67	GEAR SIDE COVER SCREW-B	DY-100202020
7	LEVEL WIND ASSEMBLY	DY-103522010		69	LUBE PORT CAP	DY-101698010
8	PIPE	DY-101406010		70	LUBE PORT CAP SCREW	DY-101507030
9	WORM SHAFT	DY-100017013		71	DRAG SPRING WASHER	DY-100088010
10	BALL BEARING	DY-102954010		72	CLICK HOLDER	DY-101765010
11	WORM SHAFT BUSHING-A	DY-102438010		73X	STAR DRAG COMPLETE	DY-U02947312
12	IDLER-S	DY-100019010		74	CLICK LEAF SPRING	DY-101763010
13	WORM SHAFT PIN	DY-100020010		75	CLICK PLATE-B	DY-101764010
16	WORM SHAFT WASHER	DY-100539010		76	CLICK PLATE RETAINER	DY-101766011
17	E-RING	DY-100047010		77	HANDLE WASHER	DY-100933010
18	PILLAR	DY-102711010		78X	HANDLE COMPLETE	DY-103813020
19	LEVEL WIND PIN	DY-100464011		79	BALL BEARING	DY-102950010
20	SPACER(OPTIONAL)	DY-100025020		80	HANDLE KNOB	DY-104030010
21	LEVEL WIND NUT	DY-100288021		81	BALL BEARING	DY-102950010
22	FRONT COVER	DY-103592070		82	HANDLE KNOB SCREW	DY-100180010
23	FRONT COVER SCREW	DY-100141020		83	HANDLE KNOB CAP	DY-101851120
24	BALL BEARING	DY-102970010		85	HANDLE NUT	DY-101176190
25	CRANK SHAFT	DY-100381012		86	HANDLE NUT RETAINER	DY-103642090
26	IDLER-L WASHER-A	DY-100548010		87	SCREW	DY-101202020
27	IDLER-L	DY-101938020		88X	SPOOL COMPLETE	DY-103512090
28	IDLER-L WASHER-B	DY-100045020		89	BALL BEARING	DY-102366010
29	BEARING PLATE	DY-103586010		90	PIN	DY-100120010
30	E-RING	DY-100047010		91	BRAKE HOLDER	DY-103532010
31	BEARING PLATE SCREW	DY-100135010		92	BRAKE SHOE	DY-100522010
33	CLUTCH CAM	DY-103585010		93	BRAKE SHOE SPRING	DY-100525010
34	CLUTCH SPRING	DY-102690010		94	MAGNET PLATE	DY-103533013
35	KICK LEVER	DY-102308011		95	MAGNET PLATE SCREW	DY-100526010
36	KICK LEVER SPRING	DY-102058010		96X	PALM SIDE PLATE ASSEMBLY	DY-UB3596100
38	CAM PLATE SCREW	DY-100293010		98	CONTROL DIAL	DY-102917010
39	PINION YOKE	DY-102083010		99	SPOOL COVER ASSEMBLY	DY-103580010
40	PINION GEAR	DY-103620010		100	MAGNET HOLDER ASSEMBLY	DY-U03539010
41	PINION YOKE SPRING	DY-102465010		105	SPOOL COVER SCREW	DY-100141010
42	RATCHET	DY-101407010		106	SPOOL SPACER-A	DY-101850010
43	RATCHET WASHER	DY-103772010		107	BALL BEARING	DY-102971010
44	DRIVE GEAR	DY-102965010		108	BEARING RETAINER	DY-102976010
45	DRAG WASHER-L	DY-102377010		114	WASHER(OPTIONAL)	DY-100073011
46	DRAG WASHER-D1	DY-100057020		120	BRAKE PLATE HOLDER ASSEMBLY	DY-103559010
47	DRAG WASHER-A	DY-100985010		121	SLIDE CAM SPRING	DY-102665010
48	DRAG WASHER-D2	DY-100986011		122	SLIDE CAM-H	DY-103342010
49	SLEEVE WASHER(OPTIONAL)	DY-100086030		123	SLIDE CAM SCREW	DY-100526020
50	SLEEVE	DY-101983010		124	SLIDE CAM-D	DY-102394010
51X	GEAR SIDE PLATE ASSEMBLY	DY-U03594150		125	CLICK SPRING	DY-102002010
53	ONE WAY CLUTCH	DY-102090010		127	LINK PLATE	DY-102894010
54	O-RING	DY-100209020		128	LINK PLATE SCREW	DY-103014010
55	BALL BEARING	DY-102971010		141	HOOD	DY-103571020
56	BEARING RETAINER	DY-101588011		142	HOOD SCREW	DY-103639010
57X	CAST CONTROL CAP ASSEMBLY	DY-U02254111		143	FRONT COVER SCREW-B	DY-100135010
58	CLICKER	DY-101674011		144	LOCK LEVER	DY-103597011
59	CLICK PLATE	DY-101675011		151	LOCK LEVER SPRING	DY-104101010