





## PSP1XH

Key #	Description	Order ID #		Key #	Description	Order ID #
1	FRAME	DY-104937040		62	SPOOL SPACER-B	DY-100074021
2	CLUTCH BAR PLATE-R	DY-104636010		63	LOCKING PIN	DY-103673072
3	CLUTCH BAR PLATE-L	DY-104637010		64	E-RING	DY-100621010
4	CLUTCH BAR	DY-104674010		65	LOCKING PIN SPRING	DY-101308010
5	CLUTCH LINK	DY-104638010		66	GEAR SIDE COVER SCREW-A	DY-100035030
6	CLUTCH BAR SCREW	DY-101507030		67	GEAR SIDE COVER SCREW-B	DY-100035020
7	LEVEL WIND ASSEMBLY	DY-104640020		68	GEAR SIDE COVER SCREW-C	DY-100035010
8	PIPE	DY-103286010		69	LUBE PORT CAP	DY-101698440
9	WORM SHAFT	DY-103474010		70	LUBE PORT CAP SCREW	DY-100202030
10	BUSHING	DY-102605010		71	DRAG SPRING WASHER	DY-100088010
12	IDLER-S	DY-100019010		72	CLICK HOLDER	DY-101765010
13	WORM SHAFT PIN	DY-100020010		73X	STAR DRAG COMPLETE	DY-U02931711
15	WORM SHAFT BUSHING-B	DY-104642010		74	CLICKER	DY-101763010
16	WORM SHAFT WASHER	DY-100539020		75	CLICK PLATE	DY-101764010
17	E-RING	DY-100047010		76	CLICK PLATE RETAINER	DY-101766011
18	PILLAR	DY-102711010		77	HANDLE WASHER	DY-100933010
19	LEVEL WIND PIN	DY-100464011		78X	HANDLE COMPLETE	DY-101806580
20	SPACER(OPTIONAL)	DY-100025020		79	BALL BEARING	DY-104543010
21	LEVEL WIND NUT	DY-100288021		80	HANDLE KNOB COMPLETE	DY-103069150
22	FRONT COVER	DY-104643060		81	BALL BEARING	DY-104543010
23	FRONT COVER SCREW	DY-100152010		82	HANDLE KNOB SCREW	DY-100180010
24	BALL BEARING	DY-104542010		83	HANDLE KNOB CAP	DY-103816070
25	CRANK SHAFT	DY-105264010		85	HANDLE NUT	DY-104094100
27	IDLER-L	DY-101938020		86	HANDLE NUT RETAINER	DY-103642160
28	IDLER-L WASHER-B	DY-100647050		87	SCREW	DY-101202020
29	BEARING PLATE	DY-104411010		88X	SPOOL COMPLETE	DY-105193010
30	E-RING	DY-100047010		89	BALL BEARING	DY-100156010
31	BEARING PLATE SCREW	DY-100028070		90	PIN	DY-104399010
34	CLUTCH SPRING	DY-102688010		91	BRAKE HOLDER	DY-103670010
35	KICK LEVER	DY-102307011		92	BRAKE SHOE ASSEMBLY	DY-103272010
36	KICK LEVER SPRING	DY-104137010		94	BRAKE HOLDER PLATE	DY-103671010
37	CAM PLATE	DY-104639010		95	BRAKE HOLDER PLATE SCREW	DY-100526010
38	CAM PLATE SCREW	DY-100035050		96X	PALM SIDE PLATE ASSEMBLY	DY-104646080
39	PINION YOKE	DY-102073010		98	CONTROL DIAL	DY-102917300
40	PINION GEAR	DY-104369010		99	SPOOL COVER	DY-104747010
41	PINION YOKE SPRING	DY-102465010		105	SPOOL COVER SCREW	DY-103423010
42	RATCHET	DY-100818010		106	SPOOL SPACER-A	DY-101850010
43	RATCHET WASHER	DY-103772010		107	BALL BEARING	DY-100155010
44	DRIVE GEAR	DY-102872020		108	BEARING RETAINER	DY-102976010
45	DRAG WASHER-L	DY-102377011		117	CLUTCH WASHER	DY-100539030
46	DRAG WASHER-D1	DY-100057020		118	CLUTCH SCREW	DY-103013020
47	DRAG WASHER-A	DY-100985010		120	BRAKE PLATE HOLDER ASSEMBLY	DY-103559010
48	DRAG WASHER-D2	DY-100986010		121	SLIDE CAM SPRING	DY-102665010
49	SLEEVE WASHER(OPTIONAL)	DY-100086060		122	SLIDE CAM-H	DY-103342010
50	SLEEVE	DY-104537010		123	SLIDE CAM SCREW	DY-100526020
51X	GEAR SIDE PLATE ASSEMBLY	DY-U04644120		124	SLIDE CAM-D	DY-102394010
53	ONE WAY CLUTCH	DY-101515010		125	CLICK SPRING	DY-102002010
54	O-RING	DY-100209020		126	SPOOL COVER SPACER(OPTIONAL)	DY-103567010
55	BALL BEARING	DY-102381010		133	HOOK HOLDER	DY-102898020
56	BEARING RETAINER	DY-104461010		134	HOOK HOLDER WASHER	DY-101168020
57X	CAST CONTROL CAP ASSEMBLY	DY-U02254161		135	HOOK HOLDER SCREW	DY-100246030
58	CLICKER	DY-101674011		136	HOOK HOLDER SPRING	DY-102968011
59	CLICK PLATE	DY-101675011		155	BUSH	DY-104365010
60	CLICK PLATE RETAINER	DY-101543012		166	WASHER (G/METAL E-RING-BALL BEA	DY-100646010
61	TENSION WASHER	DY-100073011		167	GEAR SIDE COVER SCREW-D	DY-100202020