



| Key No . | Parts name | Key No . | Parts name |
|----------|----------------------|----------|--------------------|
| 1 | DRAG KNOB ASSEMBLY | 25 | SPRING HOLDER |
| 2 | DRAG WASHER RETAINER | 26 | INSERT METAL |
| 3 | KEY WASHER | 27 | BALL BEARING |
| 4 | WEARED WASHER | 28 | PINION GEAR |
| 5 | WASHER | 29 | SCREW |
| 6 | SPOOL ASSEMBLY | 30 | ANTI-REVERSE PAWL |
| 7 | WASHER | 31 | SPRING |
| 8 | CLICK GEAR | 32 | ANTI-REVERSE CAM |
| 9 | MAIN SHAFT | 33 | ANTI-REVERSE LEVER |
| 10 | ROTOR NUT | 34 | SCREW |
| 11 | ROTOR ASSEMBLY | 35 | BODY |
| 12 | SCREW | 36 | HANDLE SCREW CAP |
| 13 | BAIL ARM | 37 | WASHER |
| 14 | SCREW | 38 | INSERT METAL |
| 15 | WASHER | 39 | DRIVE GEAR |
| 16 | INSERT METAL | 40 | WASHER |
| 17 | LINE ROLLER | 41 | INSERT METAL |
| 18 | BAIL ASSEMBLY | 42 | OSCILLATING GEAR |
| 19 | BAIL HOLDER | 43 | OSCILLATING SLIDER |
| 20 | SPRING | 44 | Guide pin |
| 21 | BAIL TRIP SHAFT | 45 | SCREW |
| 22 | BAIL SPRING COVER | 46 | BODY COVER |
| 23 | SCREW | 47 | SCREW |
| 24 | WASHER | 48 | BODY CAP |
| | | 49 | HANDLE ASSEMBLY |