
MAXXUM 101/H - 52"

101 LBS THRUST
36 VOLT 37 AMPS
52" SHAFT



1	2-400-160	PLAIN END HOUSING ASSEMBLY
2	303-043	THRUST DISC- METAL
3	144-021	BEARING -SPHERICAL
4	991-040	WASHER FELT
5	784-025	BEARING RETAINER
6	116-025	BALL -STEEL
7	2-100-110	ARMATURE ASSEMBLY
8	788-040	RETAINING RING
9	990-051	WASHER-THRUST, STEEL
10	990-052	WASHER- NYLATRON
11	738-004	BRUSH PLATE -4" TERMINAL
12	975-041	SPRING -TORSION [2.EA]
13	188-094	BRUSH W/TERMINAL [2.EA]
14B	640-017	BRUSH WIRE-BLK
14R	640-121	BRUSH WIRE- RED
14G	640- 303	GROUND WIRE- GREEN
15	973-025	SPACER -BRUSH PLATE [2.EA]
16	830-027	SCREW -SELF TRDED 10-32 X 2" [2.EA]
17	431-110	HOUSING ASSEMBLY- CENTER
18	701-043	**O-RING [2.EA]
19	144-017	BEARING -FLANGE (SERVICE ONLY)
20	2-300-160	BRUSH END HOUSING ASSEMBLY
21	880-025	**SEAL [2.EA]
22	701-009	**O-RING -THRU BOLT [2.EA]
23	830-096	THRU BOLT 12-24 X 11.56" SS [2.EA]
■	2317051	MTR ASSEMBLY 36V 4" VARS [INCL.1-23]
24	2032068	TUBE-CARBON COMPOSITE 52"
■	1378130	PROPELLER KIT INCL. 25-27
25	2331130	PROPELLER- W/WEDGE
26	2093101	NUT-PROP,NYLOC (LARGE) MAX101
27	2091701	WASHER-PROP (LARGE) MAX 101
28	2265514	DECAL- MAX MOTOR REST [2.EA]
■	2771866	MOUNT,BOW ASSEMBLY FW STD
29	2263500	BOLT, SHOULDER (MAXXUM) [2.ea]
30	2264241	ARM-UPPER FW,STD
31	2262607	PIN- CLEVIS ZP MAX BWGRD
32	2260801	CLIP-SPRING ZP MAX BWGRD
33	2293501	BUSHING, STAINLESS STEEL [4.EA]
34	2774315	ARM-LOWER ASSEMBLY STD,FW,EXT
		INCL 38-40, 44-49
35	2263912	MOTOR REST (STD) FW
36	2261505	SPACER, MOTOR REST [6.EA]
37	2773987	BOWPLATE W/INSERT STD FW
38	2251601	ROPE (40"), MAXXUM MOUNT
39	2150400	PULL-GRIP
40	2151700	WASHER-EYE SHAFT(.562 OD)
41	2261708	WASHER-3/8"X1/2"X.010 (S/S) [2.EA]
42	2236000	BEARING NYLINER [2.EA]
43	2263434	SCREW, 8-18 X 1" PPH S/S [2.EA]
44	2152610	SPRING-PIN (LOCKBAR) [2.EA]
45	2233600	LOCK BAR-(BOW MOUNT)
46	2233602	LOCK BAR, REAR - ZINC
47	2152700	SPRING-(LOCKBAR) CAD.PLTD
48	2262703	SPRING STOP MAXXUM
49	2153602	EYE SHAFT-2LOCKBAR STD SS
50	2260506	HINGE-PIN (HEADLESS)ZINC
51	2293811	YOKE,MAX MNT-POLYPROPYLENE
■	2994833	BAG ASSEMBLY MAX STABILIZER KIT
■	2991866	BOWGUARD ASSEMBLY-HAND CTRL
52	2772315	BRACKET BASE TOP/EYELET ASSEMBLY
53	2991993	BRACKET BOTTOM/BEARING ASSEMBLY
55	2772352	EYELET- KIT
56	2263402	SCREW 1/4-20 X 3/4"(ZINC)
57	2263404	SCREW-1/4-20 X 2 1/4 SCHP SS [2.EA]
58	2261525	SPRING-SLEEVE UPPER
59	2261535	SPRING SLEEVE, LOWER
60	2264702	INSERT-TUBE (2 PER) B.MNT [2.EA]
61	2262704	SPRING, BOWGUARD, HAND CT
62	2011365	SCREW-COLLAR/NEW KNOB
63	2031520	COLLAR-DEPTH (W/O INSERT)
64	2011365	SCREW-COLLAR/NEW KNOB
65	2052900	STRAIN RELIEF-C.CORD/SP.C
66	2090600	LEADWIRE (10 GA) RINGS
67	2020700	TERMINAL RING,3/8" [2.EA]
68	2062592	CONTROL BOX,FW,.725 BORE
69	2990914	HANDLE ASSEMBLY W/O U-JOINT
70	2302742	SPRING-DETENT(OFF)
71	2302743	SPRING-DETENT,HANDLE-TILT
72	2302745	SPRING-RELEASE BUTTON
73	2303720	RELEASE BUTTON-HANDLE
74	2060409	HANDLE (TOP HALF)MAXIMIZE
75	2060415	HANDLE (LOWER HALF)
76	2303412	SCREW-6-20 X 5/8 SELF TAP [11.EA]
77	2060005	BEARING-HANDLE PIVOT [2.EA]
78	2302600	PIN-ACTUATOR
79	2302850	ACTUATOR-CAM
80	2302851	ACTUATOR-FWD/REV
81	2302740	SPRING-(ACTUATOR)
82	2302741	SPRING-CAM(ZNC PLTD STEEL)
83	2305810	TAG-AIR SWITCH LEADS
84	2264013	CTRL BOARD ASSEMBLY-RT 101/H
85	2061515	COLLAR-CTRL BOX (FRS-WTR)
86	2260290	CTRL BOX CVR- BLK
87	2265622	DECAL-COVER, MAX101/H
88	2998200	CIRCUIT BREAKER ASSEMBLY36V-101 [2.EA]
89	2301710	WASHER-INSUL.(TRANSF.BAR) [2.EA]
90	2372100	SCREW-8-18 X 5/8 THD [2.EA]
91	2383407	SCREW-10-24 X 2." PPH ZINC
92	2383124	NUT-10-24 NYLOCK ZINC PLT
93	2223430	SCREW-#8 X 3/4 PPH TYPE 25 SS [2.EA]
■	2994830	BAG ASSEMBLY-MAXXUM
*94	2263431	SCREW 1/4-20 X 3.5 PPH [6.EA]
*95	2261713	WASHER-1/4 FLAT S/S [6.EA]
*96	2263103	NUT-1/4-20 NYLOCK-JAM S/S [6.EA]
*97	2301720	WASHER-MOUNTING*RUBBER [6.EA]
98	2262605	PIN BWGRD UPPER THREADED ZP
99	2261722	WASHER 1/4 FLAT ZINC [2.EA]
100	2223100	NUT- TENSION 5/16-18 SS [2.EA]
101	2301310	SCREW- #8-18X1/2 SS [2.EA]

****Seal & Oring Kit P/N 2889460**

* This item is part of an assembly. This item cannot be sold separately due to machining and /or assembly that is required.

MAXXUM 101/H Wiring Diagram

