
RT101/B/H - 3X STEERING


BOWGUARD 360°® MOUNT
101 LBS THRUST
36 VOLT 46 AMPS
62” SHAFT

for use with "WWAF" serial numbers
3-year warranty from the date of purchase



1	2-100-215	ARMATURE ASSEMBLY 36V 4 VARS FW 101#
2	788-040	RETAINING RING
3	2-200-310	CENTER HOUSING ASSEMBLY 4.0 FW TXT MAX
4	2-300-340	BRUSH END HOUSING ASSEMBLY 4.0 FW TXT
5	144-017	BEARING -FLANGE (SERVICE ONLY)
6	880-025	SEAL [2.EA]
7	421-360	PLAIN END HOUSING ASSEMBLY 4.0
8	144-021	BALL BEARING
11	188-094	BRUSH 4"W/TERMINAL [2.EA]
12B	640-020	BRUSH WIRE-BLACK 10 AWG 78 (62")
12R	640-125	BRUSH WIRE-RED 10 AWG 79 1/2 (62")
13	738-004	BRUSH PLATE - 4" TERMINAL
14	975-041	SPRING -TORSION [2.EA]
17	701-043	O-RING [2.EA]
18	701-009	O-RING -THRU BOLT (2 REQ'D)
19	830-027	SCREW -SELF TREADED 10-32 X 2" [2.EA]
20	830-096	THRU BOLT 12-24 X 11.56" SS [2.EA]
21	973-025	SPACER -BRUSH PLATE [2.EA]
22	990-051	WASHER-THRUST, STEEL
23	990-052	WASHER- NYLATRON
24	2316257	MOTOR ASSEMBLY 36V VARS TXT 62"
25	2072012	TUBE (COMP) W/CSK HOLE 62"
■	1378132	PROPELLER KIT
26	2331160	PROPELLER (W.WEDGE 2)
27	2091701	WASHER-PROP (LARGE) MAX 101
28	2198401	ANODE
29	2262658	PROP PIN
30	2261722	WASHER 1/4 FLAT SS [2.EA]
31	2223100	NUT- TENSION 5/16-18 SS [2 .EA]
32	2262604	PIN- BWGRD UPPER THREADED
33	2262606	CLEVIS PIN MAXXUM BWGRD-SS
35	2260800	SPRING CLIP
36	2150400	PULL-GRIP
37	2151700	WASHER-EYE SHAFT(.562 OD)
■	2991847	MOUNT, BOW ASSEMBLY
38	2264249	ARM-UPPER SW,LONG
39	2293501	BUSHING, STAINLESS STEEL [4.EA]
40	2263500	BOLT- SHOULDER (MAXXUM) [2.EA]
41	2994320	ARM-LOWER ASSEMBLY,LONG,FW,EXT
42	2263915	MOTOR REST LONG MAXXUM
43	2065676	DECAL-MAXXUM,MOTOR REST [2.EA]
45	2993982	BOWPLATE,LONG SW-MACH/INSERT
46	2251601	ROPE (40"), MAXXUM MOUNT
47	2261707	WASHER-3/8X1/2X.010" SS [2.EA]
48	2236000	BEARING NYLINER-[2.EA]
50	2152612	SPRING-PIN LOCKBAR [2.EA]
51	2233621	LOCK BAR- BOW MOUNT
52	2233623	LOCK BAR, REAR - SS
53	2152701	SPRING-LOCKBAR SS
54	2262703	SPRING STOP
55	2153605	EYE SHAFT-2LOCKBAR LONG-SS
56	2260505	HINGE-PIN HEADLESS-SS
57	2293811	YOKE,MAX MNT-POLYPROPYLENE
■	2991765	BOW GUARD ASSEMBLY
58	2070120	KNOB CLAMP COLLAR
59	2071541	SPRING SLEEVE UPPER
■	2991555	COLLAR/CLAMP ASSEMBLY
60	2071550	COLLAR CLAMP "A"
61	2071555	COLLAR CLAMP "B"
62	2072621	PIN KNURLED
64	2072821	ORIENTATION BLOCK
65	2073102	NUT
66	2071718	WASHER #10 NYLON
67	2073412	SCREW 1/4 - 28"HHC
68	2073418	SCREW 10-32 SS
■	2991772	BRACKET/BEARING ASSEMBLY
*69	2261531	BEARING
*70	2262051	BRACKET BASE BOTTOM
71	2261535	SPRING SLEEVE-LOWER
72	2772318	BRACKET BASE TOP W/ EYELET
73	2262315	EYELET ROPE
74	2262705	SPRING BOWGUARD
75	2263422	SCREW 5/16-18 X 1" SHCS SS
76	2263424	SCREW 5/16-18 X 2-1/2" SHCS SS [2 EA.]
77	2013100	SPEED NUT
78	2070105	KNOB-TENSION
79	2070110	PIVOT KNOB [2 EA.]
80	2070118	COVER-PIVOT KNOB
82	2070206	COVER 3:1
83	2070800	COUPLER SOCKET
84	2070810	COUPLER DRIVE
85	2071500	COLLAR LOWER SUPPORT
86	2071513	YOKE-GEAR CARRIER
87	2071710	WASHER NYLATRON [2 EA.]
88	2071712	WASHER SS
89	2071714	WASHER FLAT #6 [2 EA.]
90	2071900	IDLER PLATE
91	2071905	BRACKET- SENSOR SWITCH
92	2072092	OUTER TUBE 3:1 62"
93	2072210	GEAR CARRIER
94	2072215	GEAR- IDLER
95	2072502	CONTROL BOX
96	2072705	SPRING DETENT
97	2072710	SPRING TENSION SLEEVE
98	2072810	DETENT BLOCK-TILT
99	2072811	DETENT BLOCK-SWITCH
100	2072900	RETAINER COUPLER
101	2073000	RING PRELOAD
102	2073100	NUT - NYLOC [3 EA.]
103	2073400	SCREW 5/16" X 1/2" SHOULDER
105	2073408	SCREW [2 EA.]
106	2073410	SCREW
107	2073414	SCREW 6-32 PPH [2 EA.]
108	2074000	POT CLIP
109	2074061	CONTROL BOARD ASSEMBLY
110	2074082	BATTERY METER
112	2075100	TENSION SLEEVE
113	2076701	KEY - TUBE
114	2077305	BEARING UPPER
115	2077316	BUSHING-PIVOT [2 EA.]
116	2077320	BEARING - GEAR CARRIER
117	2071560	COLLAR TUBE
118	2223468	SCREW 8-32 [4 EA.]
119	2263201	CLAMP WIRE HARNESS
120	2264015	LIGHT INDICATOR
121	2372100	SCREW 8-18 SS [2 EA.]
122	2073416	SCREW 8-32 SS SHCS [2 EA.]
123	2303412	SCREW 6-20 [2 EA.]
124	2303412	SCREW 6-20 X 5/8" [6 EA.]
125	2071525	SPACER-LIGHT INDICATOR
126	2992205	PINION - MAIN
127	2998601	INDICATOR ASSEMBLY
128	2075617	DECAL COVER RT101 W/3X
■	2994830	BAG ASSEMBLY - MAXXUM VECTOR
*129	2263431	1/4-20X3.5" PPH [6.EA]
*130	2261713	WASHER 1/4 FLAT SS [6.EA]
*131	2263103	NUT 1/4-20 NYLOC-JAM SS [6.EA]
132	2072815	BRACKET-TILT STOP
133	2261622	COLLAR HALF [2 EA.]
134	2263453	SCREW 1/4-20 X 1" [2 EA.]
135	2052900	STRAIN RELIEF
136	2090650	LEADWIRE
■	2994832	BAG ASSEMBLY-MAXXUM VECTOR
*137	2261505	SPACER, MOTOR REST [6.EA]
*138	2263434	SCREW, 8-18 X 1" PPH SS [2.EA]
139	2990404	PIVOT HANDLE ASSEMBLY
140	2072102	SCREW #6 X 1/4" [2 EA.]
141	2070425	HANDLE TUBE
142	2070411	LATCH-BUTTON
143	2070010	BEARING
144	2990930A	HANDLE ASSEMBLY-EXT.
■	2994841	STABILIZER / STRAP BAG ASSEMBLY
145	2268400	SHAFT - SUPPORT
146	2268401	BUMPER-SHAFT
147	2263464	SCREW 1/4 -10 X 1" SS
148	2011720	LOCKWASHER
149	2263804	STRAP - HOLD DOWN
150	2332101	SCREW #8-32 X 1/2" SS [2 EA.]
151	2071720	#4 WASHER SS
152	2373440	#4 SCREW SS
200	2075120	URETHANE PAD

Seal & Oring Kit P/N 2889460 * This item is part of an assembly. This item cannot be sold separately due to machining and /or assembly that is required.


BATTERY METER
BLACK
RED
CONTROL BOARD
M-
B-
B+
M+
INDICATOR LIGHT
BLACK LEADS B-
RED LEADS B+
RED M+
BLACK M-
CONNECTING WIRE
CONNECTING WIRE
POTENTIOMETER