
VECTOR 55- 3X STEERING **for use with "AH" serial numbers**

SUPER DUTY BRACKET **3-year warranty from the date of purchase**

55 LBS THRUST

12 VOLT 50 AMPS


36" & 42" SHAFT



1	2-100-115	ARMATURE ASSEMBLY
2	140-010	BALL BEARING
3	788-015	RETAINING RING
4	2-200-101	HOUSING ASSEMBLY CENTER 3.62 TXT
5	421-065	HOUSING -BRUSH END 3.62 TXT
6	2-400-101	PLAIN END HOUSING ASSEMBLY 3.625
7	144-049	BEARING - FLANGE (SERVICE ONLY)
8	880-003	SEAL
9	880-006	SEAL WITH SHIELD
10	188-036	BRUSH ASSEMBLY [2.EA]
11	725-050	BRUSH RETENTION- PAPER TUBE
12	738-036	BRUSH PLATE W/HOLDER
13	975-040	SPRING - TORSION [2.EA]
14	337-036	GASKET
15	701-008	O-RING, THRU-BOLT [2.EA]
16	701-081	O-RING
17	830-007	SCREW-8-32 [2.EA]
18	830-042	THRU-BOLT 10-32X8.83 [2.EA]
19	990-067	WASHER- STEEL THRUST
20	990-070	WASHER - NYLATRON [2.EA]
21	2097101	MOTOR ASSEMBLY 12V 3.62 VARS 36”
	2097090	MOTOR ASSEMBLY 12V 3.62 VARS 42”
25	2072000	TUBE- COMPOSITE 3:1 36"
	2072001	TUBE- COMPOSITE 3:1 42”
■	1378131	PROPELLER KIT
26	2091160	PROPELLER W/WEDGE 2
27	2151726	WASHER-5/16 SS
28	2053101	NUT-PROP NYLOC
29	2092600	PIN-DRIVE
30	2011385	SCREW-TENSION
31	2070100	KNOB ORIENTATION COLLAR
32	2070513	PIN HINGE ZINC
33	2070515	PIN PIVOT ZINC
34	2071505	ORIENTATION COLLAR
■	2991825	BRACKET/HINGE ASSEMBLY
35	2071872	HINGE 3:1 BRACKET
36	2071941	BRACKET FW BLACK
37	2072700	SPRING
39	2072800	TENSION BLOCK
40	2073402	SCREW 5/16 X 1 1/4” SHOULDER
41	2073603	T-BAR
42	2077202	TILT LEVER
43	2077310	BUSHING HINGE [2 EA.]
44	2263452	SCREW 1/4-20 SHCS [2 EA.]
45	2331700	WASHER CLAMP [2 EA.]
46	2332700	SPRING
47	2013000	E-RING
48	2991301	CLAMP / HANDLE ASSEMBLY
49	2263101	NUT-T
50	2013100	SPEED NUT
51	2070105	KNOB-TENSION
52	2070110	PIVOT KNOB [2 EA.]
53	2070117	COVER-PIVOT KNOB [2 EA.]
54	2070201	COVER 3:1
55	2070801	COUPLER SOCKET
56	2070810	COUPLER DRIVE
57	2071500	LOWER COLLAR SUPPORT
58	2071512	YOKE-GEAR CARRIER
59	2071710	WASHER NYLATRON [2 EA.]
60	2071712	WASHER SS
61	2071714	WASHER FLAT #6 [2 EA.]
62	2071900	IDLER PLATE
64	2071905	BRACKET- SENSOR SWITCH
65	2072085	OUTER TUBE 3:1 36”
	2072086	OUTER TUBE 3:1 42”
67	2072210	GEAR CARRIER
68	2072215	GEAR- IDLER
69	2072501	CONTROL BOX
70	2072705	SPRING DETENT
71	2072710	SPRING TENSION SLEEVE
72	2072810	DETENT BLOCK-TILT
73	2072811	DETENT BLOCK-SWITCH
74	2072900	RETAINER COUPLER
75	2073000	RING PRELOAD
76	2073100	HEX NUT - NYLOC [3 EA.]
77	2073400	SCREW 5/16” X 1/2” SHOULDER
78	2073408	SCREW [2 EA.]
79	2073410	SCREW
80	2073414	SCREW 6-32 PPH [2 EA.]
82	2074000	POT CLIP
83	2074060	CONTROL BOARD ASSEMBLY
84	2074070	BATTERY METER
85	2075100	TENSION SLEEVE
86	2076701	KEY - TUBE
87	2077305	BEARING UPPER
88	2077316	BUSHING PIVOT [2 EA.]
89	2077320	BEARING - GEAR CARRIER
90	2071560	COLLAR TUBE
91	2223468	SCREW 8-32 [4 EA.]
92	2263201	CLAMP WIRE HARNESS
93	2264015	LIGHT INDICATOR
94	2372100	SCREW 8-18 SS [2 EA.]
95	2073416	SCREW 8-32 SS SHCS [2 EA.]
96	2332103	SCREW 6-20 SS [3 EA.]
97	2303412	SCREW 6-20 X 5/8” [8 EA.]
98	2071525	SPACER-INDICATOR LIGHT
99	2992205	PINION - MAIN
100	2998600	INDICATOR ASSEMBLY
101	2075602	DECAL VECTOR 55
102	2072815	BRACKET- TILT STOP
103	2261622	COLLAR HALF [2 EA.]
104	2263453	SCREW 1/4-20 X 1” [2 EA.]
105	2052900	STRAIN RELIEF
106	2090600	LEADWIRE
106A	2307310	BEAD - FERRITE (CE MODELS ONLY)
106B	2075401	HEAT SHRINK 1.10” OD X 3.5” (CE MODELS ONLY)
107	2990404	PIVOT HANDLE ASSEMBLY
108	2072102	SCREW #6 X 1/4” [2 EA.]
109	2070425	HANDLE TUBE
110	2070411	LATCH-BUTTON
111	2070010	BEARING
112	2990931A	HANDLE ASSEMBLY-EXT.
113	2332101	SCREW #8-32 X 1/2” SS [2 EA.]
114	2071720	#4 WASHER SS
115	2373440	#4 SCREW SS

Seal & O-Ring Kit p/n 2888460

* This item is part of an assembly. This item cannot be sold separately due to machining and /or assembly that is required.


BLACK
BATTERY METER
RED
CONTROL BOARD
M-
B-
B+
M+
INDICATOR LIGHT
BLACK LEADS B-
RED LEADS B+
POTENTIOMETER
RED M+
BLACK M-