



MIT AVOCAST RZT 8000 Rev1 03-05-15  
1377153

KEY NO.	PART NO.	DESCRIPTION
27	1259548	Line Sinker Screw
28	1379115	Ball Arm
29	1259606	Line Roller
30	1347153	Line Roller Bearing
31	1259604	C-Ring
32	1259603	Washer
33	1379116	Ball Assembly
34	1111479	Rotor Cover Screw
35	1379117	Rotor Cover
36	1379118	Ball Tip Lever
37	1347157	Pivot Arm
38	1259546	Press Spring
39	1389494	Rotor Washer(2req)
40	1379119	Spool Assembly
41	1379120	Shallow Spool Assembly(Not Included)
42	1379120	Body Head Cover Screw-S
43	1259612	Washer
44	1379121	Body Head Cover
45	1379122	Body Head Cover Screw-L
46	1379123	Rotor Brake
47	1122148	Screw(2req)
48	1259620	Reliner Plate
49	1131801	Pin
50	1259621	Pin
51	1259622	Gear
52	1379124	Body
53	1122132	Bushing
54	1259624	Oscillation Gear
55	1259625	Worm Shaft
56	1259619	Pinion Gear
57	1122123	Screw(4req)
58	1259613	Pinion Bearing Reliner
59	1259614	Ball Bearing
60	1259615	Bearing Collar
61	1259616	Bushing
62	1259617	Clutch
63	1259618	One Way Clutch Bearing
64	1259629	Spring
65	1379125	Handle Cap
66	1259628	POW Washer
67	1111466	Support
68	1379126	Ball Bearing(2req)
69	1122182	Washer
70	1111500	Drive Gear
71	1379127	Adjust Washer
72	1379127	Handle Assembly
73	1379128	Body Cover
74	1259633	Body Cover Screw(4req)
75	1122144	Body Cover Screw
76	1259637	Null
77	1259623	Guide Shaft
78	1122193	POW Bushing
79	1259625	Guide Shaft
80	1259627	Plate
81	1122192	Clutch Claw
82	1259635	Sinker Reliner Plate
83	1128277	Screw(2req)
84	1259639	Screw
85	1379129	Body Rear Cover
86	1259638	Waterproof Seal
87	1259644	Spring
88	1259643	Anti-Reverse Lever
89	1143861	Screw
90	1379130	Anti-Reverse Button
91	1122151	Screw
92	1259636	Sinker
93	1126275	Screw(4req)
	1259599	Drag Washer