



NO	DESCRIPTION	PART NO.	NO	DESCRIPTION	PART NO.
51	Handle Cap	1497909	89	Trip Lever	1497930
52	Screw(2req)	1347162	90	Bushing	1188261
53	Retainer Plate	1347204	91	Screw	1309754
54	Pin	1347163	92	Drag Gear Barrier	1497931
55	Gear	1497953	93	Spring	1131817
56	Bushing(2req)	1341533	94	Drag Switch-lever	1497932
57	Oscillation Gear	1347205	95	Right Spanner	1497933
58	Slider	1497911	96	Screw	1527576
59	Guide Claw	1122192	97	Left Spanner	1497934
60	POM Bushing	1132097	98	Screw	1527577
61	Fastener	1131804	99	Ball Bearing	1111486
62	Slider Retainer Plate	1347173	100	Main Gear	1497935
63	Screw(2req)	1277054	101	Main Gear Washer	1277037
64	Worm Shaft	1497954	102	Body Cover	1497955
65	Bushing	1347170	103	Spring	1347179
66	Guide Shaft	1497913	104	Bushing	1131794
67	Guide Shaft	1497914	105	Guide Block	1347180
68	Spring	1497915	106	Guide Shaft	1497937
69	Anti-reverse Lever	1132086	107	Screw	1497938
70	Anti-reverse Spring	1347209	108	Click Plate	1497939
71	Anti-reverse Button	1527574	109	Screw(5req)	1527578
72	Anti-reverse Screw	1527575	110	Screw	1527579
73	Retainer Plate	1497916	111	Washer	1497940
74	Click Spring	1497917	112	Main Shaft Collar	1497941
75	Screw	1497918	113	Handle Assembly	1497942
76	Retainer Plate	1497919	114	Spool Assy	1498815
77	Screw(5req)	1117984			
78	Trip Lever	1497920			
79	Screw	1497921			
80	Inner Gear Washer(2req)	1117948			
81	Small Torsion Spring	1497922			
82	Stop Claw	1497923			
83	Drag Gear Barrier	1497924			
84	Trip Lever	1497925			
85	Drag Holder	1497926			
86	Drag Switch-lever	1497927			
87	Drag Spring	1497928			
88	Bushing	1497929			
89	Trip Lever	1497930			
90	Bushing	1188261			
91	Screw	1309754			
92	Drag Gear Barrier	1497931			
93	Spring	1131817			
94	Drag Switch-lever	1497932			
95	Right Spanner	1497933			
96	Screw	1527576			
97	Left Spanner	1497934			
98	Screw	1527577			
99	Ball Bearing	1111486			
100	Main Gear	1497935			
101	Main Gear Washer	1277037			
102	Body Cover	1497955			
103	Spring	1347179			
104	Bushing	1131794			
105	Guide Block	1347180			
106	Guide Shaft	1497937			
107	Screw	1497938			
108	Click Plate	1497939			
109	Screw(5req)	1527578			
110	Screw	1527579			
111	Washer	1497940			
112	Main Shaft Collar	1497941			
113	Handle Assembly	1497942			
114	Spool Assy	1498815			

NO	DESCRIPTION	PART NO.
1	Drag Knob Assembly	1497884
2	Spool Clasp	1111145
3	Key Washer(2req)	1143840
4	Eared Washer	1357790
5	Drag Washer(3 req)	1379588
6	Spool	1497943
7	Line Clip(2req)	1259574
8	Line Clip Bushing(2req)	1277079
9	Spring(2req)	1277112
10	Click Plate	1259577
11	Bushing	1294639
12	Screw	1385581
13	Spring	1259579
14	Screw	1294638
15	Washer	1122023
16	Click Gear	1294640
17	Washer	1294641
18	Main Shaft	1497944
19	Nut	1385668
20	Screw	1378050
21	Rotor	1497945
22	Rotor Brush(2req)	1497946
23	Bail Arm Bushing(2req)	1377596
24	Bail Holder	1497899
25	Screw(2req)	1527570

NO	DESCRIPTION	PART NO.
26	Bail Trip Lever	1497948
27	Press Spring	1498359
28	Pivot Arm	1277164
29	Rotor Cover	1497949
30	Rotor Cover Screw	1527572
31	Bail Arm	1497902
32	Line Roller Collar	1497903
33	Line Roller Bushing	1497904
34	Line Roller	1457805
35	Line Roller Bushing	1457806
36	Bail Assembly	1497950
37	Bail Arm Screw Washer	1417809
38	Line Roller Screw	1527573
39	Washer	1259612
40	Screw(3req)	1377594
41	Ball Bearing Retainer	1497906
42	Ball Bearing	1259614
43	Bearing Collar	1498360
44	Bushing	1498361
45	Clutch Assembly	1111483
46	Pinion Gear Bushing	1498362
47	Pinion Gear	1497951
48	Body Assembly	1497952
49	POM Washer	1530497
50	Washer	1379126