



# MITCHELL®

## Model 1580060 MX SURF 8000 00

IETM	DESCRIPTION	MX SURF 8000	IETM	DESCRIPTION	MX SURF 8000	IETM	DESCRIPTION	MX SURF 8000
1	DRAG KNOB ASSEMBLY	1591165	27	SCREW	1111460	53	SCREW	1122130
2	SCREW	1085341	28	WASHER	1125966	54	RETAINER BLOCK	1122183
3	RETAINER PLATE	1122157	29	BUSHING	1125967	55	WASHER	1122185
4	WATERPROOF RING	1122158	30	BALL BEARING	1112125	56	BALL BEARING(4 req.)	1131801
5	KEY WASHER	1562759	31	LINE ROLLER	1125969	57	BUSHING	1122184
6	EARED WASHER	1122160	32	BAIL ASSY	1591169	58	OSCILLATION GEAR	1122186
7	WASHER	1122161	33	TRIP LEVER	1122176	59	WORM SHAFT	1122187
8	KEY WASHER	1562708	34	SPRING	1122177	60	GUIDE BAR II	1558329
9	SPOOL ASSEMBLY	1591166	35	HOLDER	1122178	61	RETAINER BLOCK	1122189
10	CLICK GEAR WASHER	1122023	36	SCREW	1122123	62	GUIDER BAR I	1558328
11	CLICK GEAR	1122164	37	BALL BEARING RETAINER	1122122	63	SLIDER	1122191
12	WASHER	1122165	38	WASHER	1111480	64	SCREW	1341544
13	MAIN SHAFT	1558330	39	ONE WAY CLUTCH BEARING	1111483	65	SCREW	1111492
14	ROTOR	1591167	40	SCREW	1122123	66	SCREW	1122151
15	BRUSH	1122168	41	BALL BEARING	1111486	67	LINE GUIDE PAWL	1122192
16	BAIL HOLD COVER	1557762	42	PINION GEAR	1122179	68	BUSHING	1122193
17	SCREW	1122110	43	SPRING	1108940	69	SLIDER PLATE	1122194
18	SCREW	1111479	44	SPRING	1122125	70	BODY COVER	1591172
19	BAIL ARM COVER	1557763	45	BODY	1591170	71	SCREW	1111513
20	ROTOR NUT	1111457	46	SCREW	1122144	72	SCREW	1122144
21	SCREW	1085900	47	HANDLE SCREW CAP	1591171	73	HANDLE ASSEMBLY	1591173
22	LEVER SPRING	1122171	48	WASHER	1111494	74	REAR COVER	1557768
23	LEVER	1122172	49	SCREW	1122127	75	SCREW	1122148
24	BAIL ARM	1591168	50	BALL BEARING(2 req.)	1111486	76	ANTI-REVERSE LEVER	1122199
25	SCREW	1122116	51	DRIVE GEAR	1122182	77	ANTI-REVERSE BUTTON	1591164
26	BUSHING	1122174	52	WASHER	1111500	78	SCREW	1122151