


MITCHELL®

Model 1570785 MX5 1000S



NO	DESCRIPTION	PART NO.
1	Drag Knob Assembly	1589390
2	Washer Retaining Ring	1092606
3	Eared Washer	1280353
4	Felt Washer(2req.)	1589391
5	Keyed Washer	1280355
6	Spool	1589392
7	Line Clip	1589393
8	Line Clip Retainer	1385637
9	Spool Clicker Spring Screw(2req.)	1294638
10	Spool Click Spring	1259579
11	Spool Clicker Spacer Ring	1385579
12	Spool Click Plate	1385578
13	Spool Clicker Spring Screw	1385581
14	Spool Adjust Washer	1385627
15	Main Shaft Washer(2req.)	1252700
16	Pom Bushing	1589394
17	Spool Holder	1385603
18	Click Gear	1447840
19	Main Shaft	1589395
20	Nut Set Screw	1126258
21	Rotor Nut Set Plate	1447834
22	Rotor Nut	1259462
23	Rotor Washer	1447827
24	Rotor Assembly	1589396
25	Bail Arm Screw(2req.)	1589397
26	Bail Holder	1589398
27	Bushing(2erq.)	1188261
28	Line Roller Screw	1589499
29	Bail Arm	1589500
30	Line Roller Collar	1589501
31	Bearing(3req.)	1112125
32	Line Roller Washer	1110165
33	Line Roller	1589502
34	Bail Assembly	1589503
35	Screw	1589504
36	Bail Arm Cover	1589505
37	Bail Spring	1363787
38	Bail Arm Lever	1385621
39	Rotor Trip Lever	1589506
40	Rotor Washer	1114764
41	Screw(3req.)	1589507
42	Ball Bearing Retainer	1589508
43	Bearing(2req.)	1259447
44	Bearing Holder	1280475
45	Clutch Assembly	1589509
46	Pinion	1589510
47	Sleeve	1589511
48	Body Assembly	1589512
49	Handle Cap	1589513
50	Body Side Cover Assembly	1589514
51	Bearing(2req.)	1126286
52	Slider Guide Shaft	1589515
53	Slider	1525131
54	Body Rear Cover	1589516
55	Slider Screw	1126275
56	Oscillation Gear	1589517
57	Screw(3req.)	1277091
58	Clutch Switch	1589518
59	Clutch Switch Spring	1252722
60	Pom Bushing	1279733
61	Screw	1589519
62	A/R Pulling Spring	1589520
63	Driver Gear	1589521
64	Washer	1085287
65	Body Cover Assembly	1589522
66	Screw	1589523
67	Screw(3req.)	1589524
68	Handle Assembly	1589525
69	Spool Assembly	1589526

MIT SP MX5 1000S