


MITCHELL®

Model 1570787 MX5 2500 HS



NO	DESCRIPTION	PART NO.
1	Drag Knob Assembly	1589527
2	Drag Knob Seal	1447857
3	Drag Washer Retainer	1277085
4	Key Washer(2req)	1085296
5	Eared Washer	1085297
6	Felt Washer(3req)	1589528
7	Spool	1589594
8	Line Clip	1589530
9	Line Clip Retainer	1385637
10	Spool Clicker Spring Screw(2req)	1294638
11	Spool Click Spring	1259579
12	Spool Clicker Spacer Ring	1385579
13	Spool Click Plate	1385578
14	Spool Clicker Spring Screw	1385581
15	Spool Adjust Washer	1385627
16	Main Shaft Washer(2req.)	1252700
17	Pom Bushing	1589572
18	Spool Holder	1385603
19	Click Gear	1447840
20	Main Shaft	1589573
21	Nut Set Screw	1385554
22	Rotor Nut Set Plate	1277088
23	Rotor Nut	1257336
24	Rotor Washer	1385555
25	Rotor Assembly	1589574
26	Bail Arm Screw(2req.)	1589536
27	Bail Holder	1589537
28	Bushing(2req.)	1188261
29	Line Roller Screw	1589538
30	Bail Arm	1589539
31	Line Roller Collar	1589540
32	Bearing(2req.)	1112125
33	Line Roller Washer	1110165
34	Line Roller	1589541
35	Bail Assembly	1589575
36	Screw	1589543
37	Bail Arm Cover	1589576
38	Bail Spring	1363787
39	Bail Arm Lever	1385551
40	Rotor Trip Lever	1589577
41	Screw(2req)	1126267
42	Body Head Cover	1589547
43	Rotor Washer	1483090
44	Screw(3req.)	1276926
45	Ball Bearing Retainer	1308703
46	Bearing(2req.)	1259431
47	Bearing Holder	1385608
48	Clutch Assembly	1589550
49	Pinion	1589588
50	Washer	1277424
51	Body Assembly	1589681
52	Handle Cap	1589553
53	Body Side Cover Assembly	1589595
54	Bearing	1589555
55	Slider Guide Shaft	1589580
56	Slider	1525156
57	Body Rear Cover	1589596
58	Slider Screw	1525158
59	Screw	1307857
60	Oscillation Gear	1589582
61	Bearing	1589583
62	Screw(3req.)	1102139
63	Clutch Switch	1589562
64	Clutch Switch Spring	1252722
65	Pom Bushing	1279733
66	Screw	1589563
67	A/R Pulling Spring	1589564
68	Driver Gear	1589591
69	Washer	1257352
70	Bearing	1259431
71	Body Cover Assembly	1589597
72	Screw	1589567
73	Screw(3req.)	1589568
74	Handle Assembly	1589586
75	Spool Assembly	1589598

MIT SP MX5 2500 HS