



Model 1571221 MX5 4000HS



NO	DESCRIPTION	PART NO.
1	Drag Knob Assembly	1589527
2	Drag Knob Seal	1447857
3	Drag Washer Retainer	1277085
4	Key Washer(2req)	1085296
5	Eared Washer	1085297
6	Felt Washer(3req)	1589528
7	Spool	1589529
8	Line Clip	1589530
9	Line Clip Retainer	1589531
10	Spool Clicker Spring Screw(2req)	1294638
11	Spool Click Spring	1259579
12	Spool Clicker Spacer Ring	1385579
13	Spool Click Plate	1385578
14	Spool Clicker Spring Screw	1385581
15	Spool Adjust Washer	1385627
16	Main Shaft Washer(2req.)	1252700
17	Pom Bushing	1589532
18	Spool Holder	1385603
19	Click Gear	1447840
20	Main Shaft	1589533
21	Nut Set Screw	1385554
22	Rotor Nut Set Plate	1589534
23	Rotor Nut	1257336
24	Rotor Washer	1385555
25	Rotor Assembly	1589535
26	Bail Arm Screw(2req.)	1589536
27	Bail Holder	1589537
28	Bushing(2req.)	1188261
29	Line Roller Screw	1589538
30	Bail Arm	1589539
31	Line Roller Collar	1589540
32	Bearing(2req.)	1112125
33	Line Roller Washer	1110165
34	Line Roller	1589541
35	Bail Assembly	1589542
36	Screw	1589543
37	Bail Arm Cover	1589544
38	Bail Spring	1589545
39	Bail Arm Lever	1385551
40	Rotor Trip Lever	1589546
41	Screw(2req)	1126267
42	Body Head Cover	1589547
43	Rotor Washer	1483090
44	Screw(3req.)	1589548
45	Ball Bearing Retainer	1308703
46	Bearing(2req.)	1259432
47	Bearing Holder	1589549
48	Clutch Assembly	1589550
49	Pinion	1589551
50	Washer	1277424
51	Body Assembly	1589552
52	Handle Cap	1589553
53	Body Side Cover Assembly	1589554
54	Bearing	1589555
55	Slider Guide Shaft	1589556
56	Slider	1589557
57	Body Rear Cover	1589558
58	Slider Screw	1525911
59	Screw	1307857
60	Oscillation Gear	1589559
61	Bearing	1589560
62	Screw(3req.)	1589561
63	Clutch Switch	1589562
64	Clutch Switch Spring	1385426
65	Pom Bushing	1279733
66	Screw	1589563
67	A/R Pulling Spring	1589564
68	Driver Gear	1589565
69	Washer	1257352
70	Bearing	1126394
71	Body Cover Assembly	1589566
72	Screw	1589567
73	Screw(3req.)	1589568
74	Handle Assembly	1589569
75	Spool Assembly	1589570