



Part No.	Part Name
81359	HEX NUT LOCK WASHER
81981	ANTI-REV. LOCK WASHER
82159	ANTREV.LVR/CNTRWT SCREW
82915	STEEL BAIL SPRING
82918	COUNTERWEIGHT
82919	BRASS HEX NUT
82920	STEEL KEYED WASHER
82926	BAIL TRIP COVER
82931	ROT.HEAD BALLBEARING
82951	COVERPLATE SCREW
83060	STEEL BAIL TRIP SPRING
83112	BRASS BAIL TRIP
83113	BRASS BAILTRIP SCREW
83114	BAIL TRIP LOCK WASHER
83115	ANT.INERT.BRKE.RETAINER
83116	ANTI-INERTIA DISC
83117	ANTI-INERTIA SPRING
83190	OIL DUST SHIELD
83211	BRASS SHIMS/ADJ.DR.GR.
83505	ROLLER LINEGUIDE & BUSHING
83506	LINE GUIDE BUSHING
83507	STEEL LN. GUIDE WASHER
83531	BAIL BUMPER
83564	DRAG HEX NUT
83565	STEEL TRIGGER SPRING
83566	WATERPROOF WASHER
83567	STEEL DRAG SCREW
83569	ANT.REV. & TRP LVR SCREW
83580	COVER PLATE SCREW
83652	BRASS BAILWIRE NUT
83759	DRAG BUTTON SCREW
83926	SELF CENTERING RATCHET
84486	CROSSWIND DISC BUSHING
84499	STEEL BAILWIRE SCREW
84500	SPOOL—STANDARD GRAPHITE
84501	LINE GUIDE & BUSHING
84502	BAIL ARM
84504	BRASS BAIL SCREW N1
84505	BRONZE MAIN AXLE
84506	STEEL BAIL WIRE
84507	BRACKET

Part No.	Part Name
84508	BRASS BAIL SCREW N2
84510	RELEASE PLATE
84511	BRASS PINION
84513	ANTI-REVERSE BUTTON
84514	HANDLE SCREW
84517	STEEL DRAG SPRING
84518	DRAG SPRING CASING
84520	DRAG KNOB CLICK SPRING
84521	DRAG KNOB
84522	BRASS & STEEL DRAG ASMBLY
84523	C.W. GEAR
84524	OSCILLATION SLIDE
84525	OSCILLATION SLIDE RETAINER
84526	STEEL ANTI-REVERSE CLICK
84527	ANTI-REVERSE LEVER
84528	CLICK DRIVE
84529	BRONZE MAIN GEAR
84530	COVERPLATE
84532	HANDLE COMPLETE
84538	BRASS THRUST SCREW
84539	ROTOR SUPPORT WASHER
84541	HOUSING
84542	ALUM ALLOY ROT HEAD
84544	STEEL ANTI-REVERSE RET.
84546	BRASS HANDLE CTRWT
84558	HANDLE CORE
84559	HANDLE ARM
84584	GRAPHITE ROTATING HEAD
84585	BAIL WIRE WBRACKET
84586	BAIL ARM
84587	BAIL ARM & BRACKET
84588	STEEL AXLE RETAINER
84589	BAIL SPRING GUIDE
84590	BAIL TRIP LEVER
84591	STEEL BAIL SPRING
84592	BAIL SPRING COVER
84593	BAIL TRIP COVER
84594	BAILCVR & HEX NUT RET SCR
84595	STEEL HEX NUT RETAINER
84596	BAIL RELEASE DISC