



Part No.	Description	Part No.	Description
8505500	BALL BEARING	8642800	BAIL SPRING
8507600	HANDLE CAP SCREW W/ WASHER	8642900	TRIP LEVER
8508300	CAP SCREW WASHER	8643000	TRIP LEVER SPRING
8633000	SPOOL	8643100	TRIP LEVER SPRING PIN
8633100	COVER PLATE N1	8643200	TRIP LEVER SCREW W/ BUSHING
8633200	COVER PLATE N2	8643300	KEYED WASHER
8633300	SIDE PLATE	8643400	ROTATING HEAD NUT
8633400	HOUSING	8643500	KEYED SPACER WASHER
8640600	ANTI-REVERSE BUTTON	8643600	PINION GEAR W/ RATCHET
8640800	ROTATING HEAD	8643700	BEARING RETAINER
8641100	DRAG KNOB	8643800	BEARING RETAINER SCREW
8641200	DRAG RETAINER	8643900	ANTI-REVERSE DOG
8641300	KEYED DRAG WASHER	8644000	AR DOG SCREW W/ BUSHING
8641400	DRAG WASHER	8644100	ANTI-REVERSE LEVER
8641500	EARED DRAG WASHER	8644200	HOUSING BUSHING
8641600	BASE DRAG WASHER	8644500	ANTI-REVERSE FRICTION SPRING
8641700	CLICK GEAR	8644700	SIDE PLATE SCREW
8641800	AXLE	8644800	HANDLE
8641900	BAIL ARM	8645300	AXLE W/ CLICK GEAR
8642000	BAIL RETAINING PIN	8646600	SPOOL CLICK
8642100	RETAINING PIN CLIP	8646700	SPOOL CLICK SPRING
8642200	LINE GUIDE SCREW	8646800	SPOOL CLICK SCREW
8642300	LINE GUIDE RACE	8647100	SHIM - DRIVE GEAR
8642400	LINE GUIDE	8647400	CROSS WIND GEAR
8642500	BAIL WIRE W/ MOUNT	8647500	OSCILLATION SLIDE
8642700	COVER PLATE SCREW	8647600	OSCILLATION SLIDE SCREW