


1	Drag Knob Assembly	888-9993
2	Retaining Ring	859-3300
3	Double "D" Washer	859-3100
4	Drag Washer	859-3200
5	Eared Washer	859-3000
6	Spool, Aluminum	888-9994
7	Spool, Graphite	888-9181
8	Gasket Ring	800-0715
9	Spool Core Assembly	888-9193
10	Spindle Spool	880-4300
11	Base Drag Washer	859-3900
12	Line Guide	888-9995
13	Plastic Bushing	880-7800
14	Line Guide Washer	866 7700
15	Ball Arm Screw	888 9190
16	Bail Trip Cover Plate	888 9996
17	Bail Trip Actuation Screw	880 8000
18	Bail Trip Lever (Sz 30)	880 7100
19	Bail Trip Spring	880 7600
20	Bail Arm	888 9997
21	Line Guide Screw (Black)	842 9400
22	Line Control Spring	880-2900
23	Line Control Rocker	888-9998
24	Hex Nut Rotor	842-9900
25	Rotor Retainer Screw	850-5900
26	Rotor Hex Nut Retainer	850-3900
27	Oscillation Shaft Assembly	888-9168
28	Plastic Ball	880-6600
29	Bail Weight	888-9999
30	Balancing Weight Screw	888-9192
31	Bail Spring Pin	880-7500
32	Bail Spring	866-4100
33	Bail Pin Sheath	880-7300
34	Screw (Black)	859-6000
35	Bail Trip Rocker	880-7200
36	Anti-Reverse Friction Spring	888-9189
38	Rotor Weight	889-0001
39	Rotor	889-0002
40	Rotor Cover Plate	889-0003
41	Cap	888-9986
42	Ball Bearing	859-2400
43	Anti-Reverse Switch Sleeve	890-5500
44	Pinion Sleeve	880-5400
45	Pinion	880-5300
46	Pinion Ball Bearing	850-5500
47	Pinion Bearing Retainer	880-3400
48	Bearing Retainer Screw	859-6000
49	Drive Gear	880-4500
51	Shim Washer	850-5600
52	Side Cover Assembly	889-0005
53	Side Cover Screw (Black)	859-5700
54	Anti-Reverse Switch	889-0006
55	Anti-Reverse Shaft	880-3300
56	Anti-Reverse Spring	850-5300
57	Body Assembly	889-0007
58	Oscillation Gears	888-9169
59	Oscillation Shaft Screw	859-0700
60	Oscillation Slide	880-5000
61	Oscillation Slide Bar	880-5100
64	Anti-Reverse Pawl Assembly	889-0008
65	Brass Sleeve	880-9700
66	Drive Bearing Retainer	8890004
67	Crank Handle Assembly	889-0009

www.reelschematic.com