


OCEAN CITY'S "BRIGANTINE" REELS NOS. 111, 978 AND 980
(Model B)



HOW TO ORDER PARTS FOR YOUR REEL—Locate the part desired in the illustration above and note part number, when ordering, state quantity, part number and model letter which you will find on underside of reel stand. Enclose money order, stamps or check. Our minimum charge for one order is \$2.50; please add \$.15 on each order for return postage and insurance.

PART No.	PART NAME	PRICE	PART No.	PART NAME	PRICE	PART No.	PART NAME	PRICE	PART No.	PART NAME	PRICE
1-F	Bridge (for Model No. 111 only)	.35	15-C	Eccentric Spring (for Model Nos. 978 and 980)	.12	25	Handle Knob Rivet	.06	42-F	Right Side Plate (for Model No. 111)	.80
1-F	Bridge (for Model Nos. 978 and 980)	.30	15-D	Eccentric Spring (for Model No. 111)	.12	26	Handle Knob Flat Washer	.01	42-G	Right Side Plate (for Model Nos. 978 and 980)	.50
2-C	Bridge Screw (for Model No. 111)	.02	16-F	Free Spool Lever (for Model No. 111)	.26	28	Handle Knob Oiler (for No. 980 only)	.24	44-Q	Spool (for Model No. 978)	1.00
2-D	Bridge Screw (for Model Nos. 978 and 980)	.02	16-F	Free Spool Lever (for Model Nos. 978 and 980)	.24	31-F	Left Side Plate Complete with Part Nos. 5-E, 6-D, 7-C (for Model Nos. 978 and 980)	.80	44-R	Spool (for Model No. 980)	1.00
3-B	Bridge Screw Nut (for Model Nos. 978 and 980)	.04	17	Free Spool Lever Screw	.05	31-G	Left Side Plate Complete with Part Nos. 5-F, 6-E, 7-D (for Model Nos. 978 and 980)	.50	44-S	Spool (for Model No. 111)	1.00
5-E	Click Button (for Model No. 111)	.12	19-H	Frame Post (for Model No. 978)	.12	34	Left Side Oil Cap	.12	46-A	Yoke (for Model No. 111)	.20
5-F	Click Button (for Model Nos. 978 and 980)	.12	19-I	Frame Post (for Model No. 980)	.12	35	Left Side Oil Cap Spring	.04	46-B	Yoke (for Model Nos. 978 and 980)	.16
6-D	Click Pawl (for Model No. 111)	.12	22-F	Handle Complete with Part Nos. 24-E, 25, 26 and 28 (for Model No. 980)	.80	40	Left and Right Side Bearing	.20	47-D	Yoke Plate (for Model No. 111)	.30
7-C	Click Spring and Rivets (for Model No. 111)	.14	22-F	Handle Complete with Part Nos. 24-C, 25, 26 and 28 (for Model No. 980)	.80	37-E	Main Gear (for Model No. 111)	.50	47-E	Yoke Plate (for Model Nos. 978 and 980)	.28
7-D	Click Spring and Rivets (for Model Nos. 978 and 980)	.14	22-H	Handle Complete with Part Nos. 24-D and 25 (for Model No. 980)	.80	38-D	Pinion Gear (for Model Nos. 978 and 980)	.30	48-B	Yoke Spring (for Model No. 111)	.04
14-C	Eccentric (for Model No. 111)	.50	24-C	Handle Knob (for Model No. 978)	.24	38-E	Pinion Gear (for Model Nos. 978 and 980)	.30	48-B	Yoke Spring (for Model Nos. 978 and 980)	.04
14-D	Eccentric (for Model Nos. 978 and 980)	.50	24-D	Handle Knob (for Model No. 978)	.24	39-D	Pinion Gear Clutch (for Model No. 111)	.26	49-B	Yoke Guide Stud (for Model No. 111)	.06
			24-E	Handle Knob (Wood) (for Model No. 111)	.10				49-C	Yoke Guide Stud (for Model Nos. 978 and 980)	.06
									50	Yoke Guide Stud Screw (for Model No. 111)	.02
									50-C	Yoke Guide Stud Screw (for Model Nos. 978 and 980)	.02