
OCEAN CITY "BRIGANTINE" REEL NO. 111

(Model B)



HOW TO ORDER PARTS FOR YOUR REEL—Locate the part desired in the illustration above and note part number. When ordering, state quantity, part number, part name and model letter which you will find on underside of reel stand. Enclose money order, stamps or check. Our minimum charge for one order is \$.25; please add \$.15 on each order for return postage and insurance.

FORM 164													
.02	Screw, Left Side Stand	Screv	57-E	.80	Stand		.80	Part Nos. 5-E, 6-D and 7-C		.05	Free Spool Lever Screw	17	
	w, Right Side Stand	Screv	54-F	.80	Right Side Plate	42-F		Left Side Plate Complete with	31-F	.26	Free Spool Lever		
	w, Left & Right Side Plate	Screv	52	.12	Right Side Adjusting Cap			Handle Knob Oiler	28	.12	Eccentric Spring		
	Guide Stud Screw	Yoke	50	.20	Left and Right Side Bearing			Handle Knob Felt Washer	26	.50	Eccentric		
.06	• Guide Stud	Yoke	49-B	.26	Pinion Gear Clutch	39		Handle Knob Rivet	25	.14	Click Spring and Rivets	7-C	* A=
	Yoke Spring	Yoke	48	.30	Pinion Gear		24	Handle Screw	24-0	.12	Click Pawl	6-D	
	Plate	Yoke	47-D	.50	Main Gear	37-E	.80	Nos. 24-C, 25, 26 and 28	3	.12	Click Button		
	,	Yoke	46-E	.04	Left Side Oil Cap Spring	35		Handle Complete with Part	22-F	.02	Bridge Screw		
1.00	<u>s</u>	Spoo	44-0	.12	Left Side Oil Cap	34	.12	Frame Post	19-F	.35	Bridge	- -	
PRICE	PART NAME	No.	PART No.	PRICE	o. PART NAME	PART No.	PRICE	PART NAME	PART No.	PRICE	No. PART NAME	PART No.	