
OCEAN CITY "BRIGANTINE" REEL NO. 980



HOW TO ORDER PARTS FOR YOUR REEL—Locate the part desired in the illustration above and note part number. When ordering, state quantity, part number, part name and model letter which you will find on underside of reel stand. Enclose money order, stamps or check. Our minimum charge for one order is \$.25; please add \$.15 on each order for return postage and insurance.

FORM 165						`				
Screw, Left Side Stand	57-F	.60	Stand	43-R	.50	Part Nos. 5-F, 6-E and 7-D		.05	Free Spool Lever Screw	
Screw, Right Stand & Left Plate		.50	Right Side Plate	42-G			31-1	.24	Free Spool Lever	
screw, kight side Flate		.12	Right Side Adjusting Cap		.24		28	.12	Eccentric Spring	
7: 1: 6: 1 5: :		; ;	ron and right olde bearing		.01	Handle Knob Felt Washer	26	.50	Eccentric	1-D
Yoke Guide Stud Screw		30	left and Bight Side Begring		.06	Handle Knob Rivet	25	.].4	Click Spring and Rivets	7-D
Yoke Guide Stud		.26	Pinion Gear Clutch		.24	Handle Knob	24-C	.08	Click Pawl	
Yoke Spring	48-B	.30	Pinion Gear		.16		23	.12	Click Button	5-
Yoke Plate		.50	Main Gear	37-F	.80	Nos. 24-C, 25, 26 and 28		.04	Bridge Screw Nut	
Yoke		.04	Left Side Oil Cap Spring	35		Handle Complete with Part	22-F	.02	Bridge Screw	
Spool		.12	Left Side Oil Cap	34	.12		19-1	.30	Bridge	ī
No. PART NAME	PART No.	PRICE	IO. PART NAME	PART No.	PRICE	No. PART NAME	PART No.	PRICE	o. PART NAME	PART No.