





FS-50 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO
100	21000775	MAIN BODY	705	27050031
102	21020002	DRIVE GEAR BUSHING	708	27080033
200	22001179	SIDE PLATE	718	27180124
300	23000884	ROTOR	719	27190002
301	23010028	BAIL ARM	722	27220012
304	23040438	BAIL ARM COVER	725	27250020
305	23050045	KICK LEVER	800	28000032
307	23070061	BAIL HOLDER	801	28010006
309	23090029	BAIL ARM SUPPORT PIN	803	28030013
309-1	23090018	BAIL ARM SUPPORT PIN	804	28040002
310	23100017	COMPRESSION SPRING	808	28080041
313	23130188	BAIL WIRE ASSY.	809	28090011
315	23150022	LINE ROTOR	814	28140002
316	23160002	LINE ROTOR BUSHING	0910096	0910096
317	23170008	LINE ROLLER WASHER	0920431	0920431
318	23180001	ROTOR NUT	0920376	0920376
400	240012248	SPOOL ASSY.	0920150	0920150
405	24050001	DARG WASHER RETAINER	0930047	0930047
500	25000474	HANDLE ASSY.	0930836	0930836
513	25130140	HANDLE CAP	0930561	0930561
515	25150002	HANDLE SCREW CAP WASHER	0930470	0930470
600	26000401	DRAG KNOB ASSY.	09301273	09301273
610	26100015	DRAG WASHER	0930662	0930662
611	26110005	EARED WASHER	0930300	0930300
612	26120007	KEY WASHER	0930649	0930649
700	27000074	DRIVE GEAR	0930808	0930808
702	27020026	PINION GEAR		



209OKA01516501

ReelSchematic