



AV-30b-LE PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004302	Main body	705	27050099	Transmission gear
105	21050012	Pinion bearing fixed plate	708	27080096	Oscillating slider
105-1	21056571	Pinion bearing fixed plate	716	27160008	Oscillation slider plate
108	21081426	Cap	718	27180703	Main shaft
200	22003580	Side plate	719	27190025	Click gear
201	22010572	Main body decoration	722	27220009	Click gear washer
201-1	22010571	Side plate decoration	800	28000333	Anti-reverse/anti-re lever
201-2	22010111	Main body decoration	800-1	28000324	Anti-reverse/anti-re lever
201-3	22010112	Side plate decoration	801	28010024	Anti-re lever spring
300	23004996	Rotor	0910632	0910632	Ball bearing
301	23011793	Bail arm	0910039	0910039	Ball bearing
304	23042491	Bail arm cover	0910049	0910049	Ball bearing
305	23050141	Kick lever	0910091	0910091	Ball bearing
306	23060945	Bail holder cover	0910013	0910013	Ball bearing
307	23071409	Bail holder	0910015	0910015	Ball bearing
309	23090002	Bail arm slider	0910215	0910215	Ball bearing
310	23100005	Compression spring	0920319	0920319	Washer
313	23131451	Bail wire assy.	0920376	0920376	Washer
315	23150022	Line roller	0920154	0920154	Washer
318	23180005	Rotor nut	0930438	0930438	Screw
400	240014714	Spare spool assy.	0930541	0930541	Screw
405	24050042	Drag washer retainer	0930471	0930471	Screw
407	24070009	Extension spring	0930209	0930209	Screw
500	25004419	Handle assy.	0930058	0930058	Screw
504	25040004	Handle screw cap washer	09301462	09301462	Screw
513	25130721	Handle cap	0930544	0930544	Screw
600	26003399	Drag knob assy.	09301265	09301265	Screw
610	26100011	Drag washer	0930307	0930307	Screw
611	26110005	Eared washer	0930429	0930429	Screw
612	26120007	Key washer	0930838	0930838	Screw
612-3	26120032	Key washer	0930663	0930663	Screw
700	27000318	Drive gear	0930433	0930433	Screw
702	27020909	Pinion gear			

209OKA09313301