



AV-10b-LE PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003867	MAIN BODY	702	27020448	PINION GEAR
105	21050012	PINION BEARING FIXED PLATE	705	27050153	TRANSMISSION GEAR
105-1	21050039	PINION BEARING FIXED PLATE	705-1	27050155	TRANSMISSION GEAR
108	21087073	CAP	708	27080130	OSCILLATING SLIDER
118	21180030	MAIN BODY RAMP	716	27160026	OSCILLATION SLIDER PLATE
200	22003311	SIDE PLATE	718	27180726	MAIN SHAFT
201	22010567	MAIN BODY DECORATION	719	27190025	CLICK GEAR
201-1	22010568	SIDE PLATE DECORATION	722	27220009	CLICK GEAR WASHER
201-2	22010569	MAIN BODY DECORATION	725	27250028	TRANSMISSION GEAR BUSHING
201-3	22010570	SIDE PLATE DECORATION	800	28000333	ANTI-REVERSE/ANTI-RE LEVER
300	23004815	ROTOR	800-1	28000402	ANTI-REVERSE/ANTI-RE LEVER
301	23011900	BAIL ARM	801	28010024	ANTI-RE LEVER SPRING
304	23042677	BAIL ARM COVER	0910618	0910618	BALL BEARING
305	23050162	KICK LEVER	0910374	0910374	BALL BEARING
306	23061037	BAIL HOLDER COVER	0910039	0910039	BALL BEARING
307	23071500	BAIL HOLDER	0910335	0910335	BALL BEARING
309	23090033	BAIL ARM SLIDER	0910013	0910013	BALL BEARING
310	23100060	COMPRESSION SPRING	0920388	0920388	WASHER
313	23131608	BAIL WIRE ASSY.	0920540	0920540	WASHER
315	23150052	LINE ROLLER	0920386	0920386	WASHER
318	23180019	ROTOR NUT	0930541	0930541	SCREW
400	240014717	SPOOL ASSY.	09301326	09301326	SCREW
405	24050042	DRAG WASHER RETAINER	0930307	0930307	SCREW
407	24070009	EXTENSION SPRING	0930928	0930928	SCREW
500	25004419	HANDLE ASSY	0930060	0930060	SCREW
513	25130824	HANDLE CAP	0930433	0930433	SCREW
515	25150002	HANDLE SCREW CAP WASHER	09301327	09301327	SCREW
600	26003170	DRAG KNOB ASSY.	0930544	0930544	SCREW
610	26100011	DRAG WASHER	09301262	09301262	SCREW
612	26120006	KEY WASHER	09301450	09301450	SCREW
612-1	26120054	KEY WASHER	0930431	0930431	SCREW
612-4	26120032	KEY WASHER	0930830	0930830	SCREW
700	27000420	DRIVE GEAR			

209OKA09017101