



### AV-80b WH PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003757	Main body	708	27080069	Oscillating slider
105	0910332	Pinion bearing fixed plate	716	27160010	Oscillation slider plate
105-1	21056580	Ball bearing plate	718	27180613	Main shaft
108	21081499	Cap	719	27190005	Click gear
200	22003870	Side plate	722	27220005	Click gear washer
201	22010239	Main body decoration	725	27250019	Transmission gear bushing
201-1	22010240	Side plate decoration	800	28000256	Anti-reverse/anti-re lever
201-2	22010249	Main body decoration	800-1	28000327	Anti-reverse/anti-re lever
201-3	22010250	Side plate decoration	801	28010039	Anti-re lever spring
300	23004743	Rotor	0910529	0910529	Ball bearing
301	23011777	Bail arm	0910013	0910013	Ball bearing
304	23042727	Bail arm cover	0910184	0910184	Ball bearing
305	23050136	Kick lever	0910139	0910139	Ball bearing
306	23067153	Bail holder cover	0910015	0910015	Ball bearing
307	23071464	Bail holder	0920209	0920209	Washer
309	23090030	Bail arm slider	0920355	0920355	Washer
310	23100049	Compression spring	0920377	0920377	Washer
313	23131406	Bail wire assy.	0920170	0920170	Washer
315	23150022	Line roller	0920539	0920539	Washer
318	23180008	Rotor nut	0930452	0930452	Screw
400	240013877	Spool assy.	0930575	0930575	Screw
405	24050031	Drag washer retainer	0930562	0930562	Screw
407	24070006	Extension spring	0930945	0930945	Screw
500	25005428	Handle assy.	0930454	0930454	Screw
504	25040003	Handle screw cap washer	0930450	0930450	Screw
513	25130789	Handle cap	0930058	0930058	Screw
600	26002997	Drag knob assy.	0930471	0930471	Screw
610	26100053	Drag washer	0930544	0930544	Screw
611	26110021	Eared washer	09301274	09301274	Screw
612	26120063	Key washer	0930643	0930643	Screw
612-2	26120064	Key washer	0930972	0930972	Screw
700	27000332	Drive gear	09301085	09301085	Screw
702	27020887	Pinion gear	0930663	0930663	Screw
705	27050073	Transmission gear			