



AB-10000 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004494	Main body	705	27050212	Transmission gear
105	0910396	Ball bearing plate	708	27080184	Oscillating slider
105	21050082	Pinion bearing fixed plate	709	27090005	"c" retainer
108	21081540	Cap	717	27170013	Worm shaft slider
200	22004589	Side plate	718	27180790	Main shaft
201	22010917	Side plate decoration	719	27190005	Click gear
201	22010918	Main body decoration	722	27220005	Click gear washer
202	22020022	Click pawl	725	27250002	Transmission gear bushing
300	23005167	Rotor	726	27260024	Clutch cam
301	23012238	Bail arm	727	27270092	Clutch bar
304	23042832	Bail arm cover	728	27280014	Clutch spring
305	23050227	Kick lever	729	27290022	Clutch slider
307	23071856	Bail holder	730	27300018	Pinion gear yoke
309	23090037	Bail arm support pin	731	27310003	Clutch block spring
310	23100070	Compression spring	732	27320001	Clutch bar bushing
313	23131793	Bail wire assy	800	28000444	Anti-reverse/anti-re lever
315	23150075	Line roller	800	28000327	Anti-reverse/anti-re lever
316	23160011	Bushing	801	28010039	Anti-re lever spring
317	23170008	Line rollerwasher	0910494	0910494	Ball bearing
318	23180008	Rotor nut	0910184	0910184	Ball bearing
400	240015723	Spool assy.	0910139	0910139	Ball bearing
400	240015738	Spool assy.	0910015	0910015	Ball bearing
405	24050031	Drag washer retainer	0910013	0910013	Ball bearing
407	24070006	Extension spring	0920209	0920209	Washer
407	24070042	Extension spring	0920169	0920169	Washer
413	24130012	Waterproof retainer	0920589	0920589	Washer
500	25006331	Handle assy.	0920170	0920170	Washer
504	25040003	Handle screw cap washer	0920210	0920210	Washer
513	25130781	Handle cap	0920340	0920340	Washer
600	26003845	Drag knob assy.	0920539	0920539	Washer
600	26004343	Drag knob	0920246	0920246	Washer
602	26020006	Drag spring	0930452	0930452	Screw
607	26070063	Drag knob holder	0930575	0930575	Screw
609	26090016	Click gear	0930196	0930196	Screw
610	26100053	Drag washer	09301404	09301404	Screw
611	26110021	Eared washer	09301211	09301211	Screw
611	26110022	Eared washer	0930246	0930246	Screw
612	26120063	Key washer	09301271	09301271	Screw
612	26120064	Key washer	09301189	09301189	Screw
619	26190018	Knob retainer	0930643	0930643	Screw
700	27002080	Drive gear	0930964	0930964	Screw
702	27020895	Pinion gear	0930819	0930819	Screw
705	27050211	Transmission gear	0930663	0930663	Screw