



BD-40 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004050	MAIN BODY	716	27160005	OSCILLATION SLIDER PLATE
102	21020002	DRIVE GEAR BUSHING	718	27180464	MAIN SHAFT
200	22003403	SIDE PLATE	719	27190017	CLICK GEAR
300	23004508	ROTOR	722	27220022	CLICK GEAR WASHER
301	23011299	BAIL ARM	722-1	27220023	CLICK GEAR WASHER
304	23042215	BAIL ARM COVER	725	27250020	TRANSMISSION GEAR BUSHING
305	23050128	KICK LEVER	800	28000373	ANTI-REVERSE/ANTI-RE LEVER
307	23073228	BAIL HOLDER	800-1	28000374	ANTI-REVERSE/ANTI-RE LEVER
309	23090030	BAIL ARM SUPPORT PIN	801	28010024	ANTI-RE LEVER SPRING
310	23100002	COMPRESSION SPRING	804	28040036	ANTI-RE PAWL
313	23131236	BAIL WIRE ASSY.	808	28080028	RATCHET
315	23150010	LINE ROLLER	809	28090018	SILENT SPRING
316	23160002	LNE ROTOR BUSHING	910-2	0910327	BALL BEARING
318	23180001	ROTOR NUT	920-16	0920376	WASHER
400	240011164	SPOOL ASSY.	920-2	0920151	WASHER
405	24050031	DRAG WASHER RETAINER	920-3	0920075	WASHER
500	25004799	HANDLE ASSY.	930-1	0930998	SCREW
513	25130653	HANDLE CAP	930-2	0930470	SCREW
515	25150002	HANDLE SCREW CAP WASHER	930-3	0930170	SCREW
600	26004242	DRAG KNOB ASSY.	930-4	0930715	SCREW
610	26100055	DRAG WASHER	930-5	0930640	SCREW
611	26110019	EARED WASHER	930-6	0930966	SCREW
612	26120046	KEY WASHER	930-7	0930214	SCREW
612-1	26120056	KEY WASHER	930-8	0930826	SCREW
700	27000264	DRIVE GEAR	930-13	0930574	SCREW
702	27020709	PINION GEAR	930-26	09301000	SCREW
705	27050076	TRANSMISSION GEAR	930-28	0930410	SCREW
708	27080060	OSCILLATING SLIDER	930-30	0930054	SCREW