



CT - 15D(1 of 2) Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000642	11100048-04003B	MAIN BODY		704	17040024	11704015-03001	LINE GUIDE SUPPORT BAR	
102	11020037	11102005-06005	BODY FOOT		705	17050011	11705006-06	TRANSMISSION GEAR	
105	11050006	11105003-01	WORM SHAFT BUSHING		706	17060003	11706002-06	TRANSMISSION GEAR	
105-1	11050013	11105009-01001	WORM SHAFT BUSHING		707	17070009	11707008-11	TRANSMISSION GEAR	
117	11170017		NUT		708	17080014	11708008-01001	TRANSMISSION GEAR	
200	12001075	11200086-01A01C	MAIN SIDE PLATE		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
201	12010020	11201014-06001	ANTI-RE PAWL		710	17100044	1171001206917	LINE GUIDE ASSY.	
204	12040016	11204007-06	COMPRESSION SPRING		712	17120039	11712031-03001	WORM SHAFT	
207	12070061	11207026-06001	HOLDED PLATE		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
208	12080037	11208017-06001	SIDE PLATE COVERS		715	17150004	11715003-06001	LINE GUIDE PAWL	
211	12110006	11211005-03001	ANTI-RE PAWL PIN		720	17200003	11720003-06001	DRIVE GEAR SHAFT BUSHING	
212	12120037	1121200301001	COUNTER COVER ASSY.		800	18000015	11800004-12003	CLUTCH CAM	
215	12150015	11215011-03001	HOLD PLATE BUSHING		801	18010008	11801006-06001	CLUTCH SPRING	
216	12160004	11216001-06002	ANTI-RE PAWL SPRING		802	18020078	1180201106001	CLUTCH BAR ASSY.	
219	12190013	11219011-03	SIDE PLATE BUSHING		804	18040009	11804009-06001	CLUTCH SLIDER	
219-1	12190020	11219017-03001	SIDE PLATE BUSHING		805	18050005	11805005-06001	PINION GEAR YOKE	
221	12210001	11221001-07	"O"RING		806	18060001	11806001-06	YOKE SPRING	
224	12240004	11224001-02905	ONE WAY BEARING CAP		807	18070002	11807001-06002	YOKE BRAKED PLATE	
300	13000444	11300030-01001	VICE SIDE PLATE		815	18150001		CLUTCH BAR SCREW	
302	13020014	11302002-06001	WASHER		910	19100030		DEPTH COUNTER	
302-2	13020011	11302008-03	BUSHING		9102	0910099	01081605-61	BALL BEARING	
302-3	13020025	1130201301	WASHER		9103	0910153	01101609-61	ONE WAYBALL BEARIN	
303	13030045	11303010-03907	CLICK BUTTON		9106	0910227	01041104-61	BALL BEARING	
304	13040001	11304003-06	CLICK PAWL		9107	0910248	01061335-61	BALL BEARING	
304	13040015	11304011-16001	CLICK PAWL		912	19120013		COVER BOARD	
304-1	13040012	0	CLICK PAWL		912-1	19120014		COVER BOARD	
305	13050003	11305001-01002	CLICK PAWL SPRING		9201	0920283	025.1x8x0.5-6	WASHER	
305	13050006	11305002-06001	CLICK PAWL SPRING		9201-1	0920111	025.1x11.5x.5-6	WASHER	
311	13110028	11311007-06001	SIDE PLATE COVER		9202	0920114	025.1x9.5x0.2-6	WASHER	
400	14000482	1140004204005A	SPOOL ASSY.		9204	0920133	026x13x0.4-8	WASHER	
401	14010026	1140101101	CLICK GEAR		9205	0920343	028x25x1-1	WASHER	