



CT - 25L (1 of 2) Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000665	11100053-04003B	MAIN BODY		703	17030012	11703012-03001	WORM SHAFT GUARD	
102	11020046	11102010-06002	BODY FOOT		704	17040027	11704018-03001	LINE GUIDE SUPPORT BAR	
105	11050006	11105003-01	WORM SHAFT BUSHING		705	17050013	11705008-06	TRANSMISSION GEAR	
117	11170017		NUT		706	17060006	11706003-06	TRANSMISSION GEAR	
200	12000984	11200067-01A01C	MAIN SIDE PLATE		707	17070004	11707003-01	TRANSMISSION GEAR	
201	12010013	11201013-06001	ANTI-RE PAWL		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
204	12040016	11204007-06	COMPRESSION SPRING		710	17100046	1171001306917	LINE GUIDE ASSY.	
207	12070058	11207023-06001	HOLDED PLATE		712	17120034	11712025-03001	WORM SHAFT	
208	12080003	11208013-06001	SIDE PLATE COVERS		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
211	12110006	11211005-03001	ANTI-RE PAWL PIN		715	17150008	11715003-06001C	LINE GUIDE PAWL	
215	12150015	11215011-03001	HOLD PLATE BUSHING		720	17200003	11720003-06001	DRIVE GEAR SHAFT BUSHING	
216	12160004	11216001-06002	ANTI-RE PAWL SPRING		800	18000014	11800004-12002	CLUTCH CAM	
219	12190014	11219012-03	SIDE PLATE BUSHING		801	18010007	11801005-06001	CLUTCH SPRING	
219-1	12190021	11219018-03001	SIDE PLATE BUSHING		802	18020076	1180201006001	CLUTCH BAR ASSY.	
221	12210001	11221001-07	"O"RING		804	18040008	11804008-06001	CLUTCH SLIDER	
224	12240004	11224001-02905	ONE WAY BEARING CAP		805	18050004	11805004-06001	PINION GEAR YOKE	
300	13000139	11300025-11	VICE SIDE PLATE		806	18060001	11806001-06	YOKE SPRING	
302	13020014	11302002-06001	WASHER		807	18070002	11807001-06002	YOKE BRAKED PLATE	
302-2	13020022	11302009-13002	BUSHING		815	18150001		CLUTCH BAR SCREW	
302-3	13020025	1130201301	SPOOL SHAFT BUSHING		9102	0910099	01081605-61	BALL BEARING	
303	13030005	11303004-03907	CLICK BUTTON		9103	0910152	01101609-6	BALL BEARING	
304	13040001	11304003-06	CLICK PAWL	3046	9106	0910227	01041104-61	BALL BEARING	
304	13040015	11304011-16001	CLICK PAWL		9107	0910248	01061335-61	BALL BEARING	
304-1	13040012	0	CLICK SPRING		912	19120012	11912007-04001	COVER BOARD	
305	13050003	11305001-01002	CLICK PAWL SPRING	3046	9201	0920111	025.1x11.5x.5-6	WASHER	
305	13050006	11305002-06001	CLICK PAWL SPRING		9201	0920283	025.1x8x0.5-6	WASHER	
311	13110020	11311004-06001	SIDE PLATE COVER		9201-1	0920162	028x10x0.5-6	WASHER	