



C-30 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004310	Main body	700	27000318	Drive gear
105	21050012	Pinion bearing fixed plate	702	27020909	Pinion gear
105-1	21056571	Pinion bearing fixed bushing	705	27050099	Transmission gear
105-2	21056591	Pinion bearing fixed bushing	708	27080096	Oscillating slider
108	21081419	Cap	716	27160008	Oscillation slider plate
200	22004410	Side plate	718	27180703	Main shaft
201	22010284	Main body decoration	719	27190025	Click gear
201-1	22010285	Side plate decoration	722	27220009	Click gear washer
201-2	22010650	Main body decoration	800	28000333	Anti-reverse/anti-re lever
201-3	22010651	Side plate decoration	800-1	28000324	Anti-reverse/anti-re lever
300	23004969	Rotor	801	28010024	Anti-re lever spring
301	23012038	Bail arm	0910632	0910632	Ball bearing
304	23042696	Bail arm cover	0910041	0910041	Ball bearing
305	23050206	Kick lever	0910051	0910051	Ball bearing
307	23071746	Bail holder	0910093	0910093	Ball bearing
309	23090051	Bail arm support pin	0910335	0910335	Ball bearing
310	23100079	Compression spring	0920319	0920319	Washer
313	23131695	Bail wire assy.	0920376	0920376	Washer
315	23150029	Line roller	0920154	0920154	Washer
317	23170026	Line rollerwasher	0930438	0930438	Screw
317-1	23170024	Line roller washer	0930541	0930541	Screw
318	23180005	Rotor nut	0930471	0930471	Screw
400	240015091	Spool assy	0930209	0930209	Screw
405	24050042	Drag washer retainer	09301375	09301375	Screw
407	24070009	Extension spring	09301462	09301462	Screw
500	25006423	Handle assy.	09301379	09301379	Screw
504	25040004	Handle screw cap washer	0930794	0930794	Screw
513	25130585	Handle cap	09301378	09301378	Screw
600	26003730	Drag knob assy.	09301374	09301374	Screw
610	26100011	Drag washer	0930673	0930673	Screw
611	26110005	Eared washer	0930433	0930433	Screw
612	26120007	Key washer			

209OKA09315301