



CXT-10 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004239	Main body	700	27000420	Drive gear
105	21056602	Pinion bearing fixed bushing	702	27020448	Pinion gear
105	21056616	Pinion bearing fixed bushing	705	27050153	Transmission gear
108	21081443	Cap	705	27050155	Transmission gear
118	21180030	Main body ramp	708	27080130	Oscillating slider
200	22004477	Side plate	716	27160026	Oscillation slider plate
201	22010379	Main body decoration	718	27180726	Main shaft
201	22010380	Side plate decoration	719	27190025	Click gear
201	22010626	Main body decoration	722	27220009	Click gear washer
201	22010627	Side plate decoration	722	27220037	Click gear washer
300	23005036	Rotor	725	27250028	Transmission gear bushing
301	23012074	Bail arm	800	28000333	Anti-reverse/anti-re lever
304	23042752	Bail arm cover	800	28000402	Anti-reverse/anti-re lever
305	23050214	Kick lever	801	28010024	Anti-re lever spring
307	23071787	Bail holder	0910618	0910618	One way assy.
309	23090051	Bail arm support pin	0910215	0910215	Ball bearing
310	23100085	Compression spring	0910051	0910051	Ball bearing
313	23134325	Bail wire assy.	0910039	0910039	Ball bearing
315	23150029	Line roller	0910335	0910335	Ball bearing
317	23170013	Line rollerwasher	0920136	0920136	Washer
317	23170024	Line roller washer	0920373	0920373	Washer
318	23180019	Rotor nut	0920600	0920600	Washer
400	240015299	Spool assy.	0930541	0930541	Screw
400	240015763	Spool assy.	09301326	09301326	Screw
405	24050042	Drag washer retainer	09301427	09301427	Screw
407	24070009	Extension spring	0930928	0930928	Screw
500	25006364	Handle assy.	09301376	09301376	Screw
504	25040007	Handle screw cap washer	0930438	0930438	Screw
513	25130467	Handle cap	09301327	09301327	Screw
600	26003769	Drag knob assy.	09301379	09301379	Screw
610	26100011	Drag washer	09301450	09301450	Screw
612	26120006	Key washer	09301378	09301378	Screw
612	26120054	Key washer	09301426	09301426	Screw