



CN - 45L Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	1100882	1110001601831	MAIN BODY ASSY.		707	17070004	11707003-01	TRANSMISSION GEAR	
105	11050006	11105003-01	WORM SHAFT BUSHING		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
117	11170012	11117007-03001	NUT		710	17100032	1171001406917	LINE GUIDE ASSY.	
200	1200835	11200052-01A06C	HANDLE SIDE PLATE		712	17120021	11712011-03907	WORM SHAFT	
201	12010001	11201001-06	ANTI-REVERSE PAWL		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
207	12070048	11207012-03001	HOLDED PLATE		715	17150004	11715003-06001	LINE GUIDE PAWL	
211	12110008	11211002-03001	ANTI-RE PAWL PIN		720	17200002	11720002-06001	DRIVE GEAR SHAFT BUSHING	
215	12150015	11215011-03001	HOLD PLATE BUSHING		800	18000005	11800002-02002	CLUTCH CAM	3031
216	12160001	11216001-06	ANTI-RE PAWL SPRING		800	18000008	11800002-12002	CLUTCH CAM	
221	12210001	11221001-07	"O"RING		801	18010001	11801001-06	CLUTCH SPRING	
224	12240004	11224001-02905	ONE WAY BEARING CAP	3109	802	18020021	11802004-0183	CLUTCH BAR	
224	12240017	0	ONE WAY BEARING CAP		804	18040001	11804001-06	CLUTCH CAM SLIDER	
300	13000157	11300026-0183	SIDE PLATE		805	18050001	11805001-06	PINION GEAR YOKE	
302	13020014	11302002-06001	WASHER		806	18060001	11806001-06	YOKE SPRING	
303	13030005	11303004-03907	CLICK BUTTON		9103	0910163	01101612-62	BALL BEARING	3101
304	13040001	11304003-06	CLICK PAWL		9103	0910170	01101612-63	BALL BEARING	
305	13050007	11305001-01003	CLICK PAWL SPRING		9106	0910227	01041104-61	BALL BEARING	
311	13110023	11311005-06001	SIDE PLATE COVERS		9107	0910248	01061335-61	BALL BEARING	
400	14000456	1140003414005	SPOOL ASSY.		9201	0920283	025.1x8x0.5-6	WASHER	
401	14010026	1140101101	CLICK GEAR		9202	0920114	025.1x9.5x0.2-6	WASHER	
418	14180003	11418003-01001	SPOOL BEARING FIXED PLATE		9204	0920291	025.9x10x0.2-6	WASHER	
500	15000135	1150000606002	HANDLE ASSY.		9205	0920327	028.1x18x1-1	WASHER	3036
516	15160001	115160001-01	HANDLE NUT RETAINER	3052	9205	0920339	028x15x1-1	WASHER	
516	15160002	11516001-011	HANDLE NUT RETAINER		9206	0920085	024.05x10x0.2-8	WASHER	
600	16000038	11600014-03001	CAST CONTROL CAP		9207	0920066	022x4.9x0.2-3	WASHER	
609	46090001	14609001-05907	WASHER	3022	9209	0920117	025x6.2x0.2-6	WASHER	
609	46090002	14609001-06001	WASHER		9210	0920108	025.1x10.5x.5-6	WASHER	
610	16100010	11610004-006	DRAG WASHER		9301	0930799	03423x12.5-61	SCREW	
610-1	16100032	11610013-000	DRAG WASHER		9302	0930219	03327.52.6x6-61	SCREW	
611	16110005	11611005-06	EARED WASHER		9307	0930226	03412.6x4-61	SCREW	
612	16120027	11612007-06001	KEY WASHER		9311	0930588	03223x12-61	SCREW	
612-1	46120002	14612001-06001	KEY WASHER		9311-1	0930448	03123x10-61	SCREW	
614	16140001	11614001-06	SPRING WASHER		9312	0930651	03327.52.67.561	SCREW	
615	16150049	11615007-04002C	STAR DRAG KNOB		9314	0930501	03212x5-617	SCREW	
617	16170002	11617005-03	DRIVE GEAR SHAFT BUSHING		9316	0930732	03414x5-617	SCREW	
700	17000199	1170000603002	DRIVE GEAR		9319	0930196	03312x5-61	SCREW	
701	17010094	1170102113001	DRIVE GEAR SHAFT		9321	0930202	03319.4x3x7-61	SCREW	
702	17020023	11702005-061	PINION GEAR		9323	0930171	03222.6x4.5-61	SCREW	
703	17030005	11703006-03907	WORM SHAFT GUARD		9326	0930673	03327x2.6x4-61	SCREW	
704	17040007	11704004-03907	WORM GUIDE SUPPORT BAR		9404	29000001	12900001-06	E RETAINER	
705	17050013	11705008-06	TRANSMISSION GEAR		9406	29000006	12900006-06001	C RETAINER	
706	17060006	11706003-06	TRANSMISSION GEAR		9504	19010001	11901001-06	C RETAINER	