



CN - 45D Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000882	1110001601831	MAIN BODY ASSY.		707	17070004	11707003-01	TRANSMISSION GEAR	
105	11050006	11105003-01	WORM SHAFT BUSHING		708	17080003	11708003-11	TRANSMISSION GEAR	
117	11170012	11117007-03001	NUT		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
200	12000952	11200057-01A06C	HANDLE SIDE PLATE		710	17100032	1171001406917	LINE GUIDE ASSY.	
201	12010001	11201001-06	ANTI-REVERSE PAWL		712	17120031	11712022-03907	WORM SHAFT	
207	12070044	11207003-06001	HOLDED PLATE		715	17150004	11715003-06001	LINE GUIDE PAWL	
211	12110008	11211002-03001	ANTI-RE PAWL PIN		720	17200002	11720002-06001	DRIVE GEAR SHAFT BUSHING	
212	12120019	112120010183	COUNTER COVER ASSY		800	18000005	11800002-02002	CLUTCH CAM	3031
215	12150015	11215011-03001	HOLD PLATE BUSHING		800	18000008	11800002-12002	CLUTCH CAM	
216	12160001	11216001-06	ANTI-RE PAWL SPRING		801	18010001	11801001-06	CLUTCH SPRING	
219	12190021	11219018-03001	SIDE PLATE BUSHING		802	18020060	11802006-0183	CLUTCH BAR	
221	12210001	11221001-07	"O"RING		804	18040001	11804001-06	CLUTCH CAM SLIDER	
224	12240004	11224001-02905	ONE WAY BEARING CAP	3109	805	18050006	0	PINION GEAR YOKE	
224	12240017	0	ONE WAY BEARING CAP		806	18060001	11806001-06	YOKE SPRING	
300	13000157	11300026-0183	SIDE PLATE		910	19100007	11910002-01003	DEPTH COUNTER	
301	13040001	11304003-06	CLICK PAWL		9103	0910163	01101612-62	BALL BEARING	
302	13020014	11302002-06001	WASHER		9103	0910170	01101612-63	BALL BEARING	
302	13020015	11302002-06002	WASHER		9106	0910227	01041104-61	BALL BEARING	2937
303	13030005	11303004-03907	CLICK BUTTON		9107	0910248	01061335-61	BALL BEARING	
305	13050007	11305001-01003	CLICK PAWL SPRING		9201	0920283	025.1x8x0.5-6	WASHER	
311	13110023	11311005-06001	SIDE PLATE COVERS		9202	0920114	025.1x9.5x0.2-6	WASHER	
400	14000433	1140003404005B	SPOOL ASSY.		9204	0920291	025.9x10x0.2-6	WASHER	
401	14010026	1140101101	CLICK GEAR		9205	0920327	028.1x18x1-1	WASHER	3031
418	14180003	11418003-01001	SPOOL BEARING FIXED PLATE		9205	0920339	028x15x1-1	WASHER	
500	15000135	1150000606002	HANDLE ASSY.		9206	0920085	024.05x10x0.2-8	WASHER	
516	15160001	115160001-01	HANDLE NUT RETAINER	3052	9207	0920066	022x4.9x0.2-3	WASHER	
516	15160002	11516001-011	HANDLE NUT RETAINER		9209	0920282	025.1x8x0.2-6	WASHER	
600	16000038	11600014-03001	CAST CONTROL CAP		9210	0920108	025.1x10.5x.5-6	WASHER	
609	46090001	14609001-05907	WASHER	3022	9301	0930799	03423x12.5-61	SCREW	
609	46090002	14609001-06001	WASHER		9302	0930219	03327.52.6x6-61	SCREW	
610	16100010	11610004-006	DRAG WASHER		9307	0930226	03412.6x4-61	SCREW	
610-1	16100032	11610013-000	DRAG WASHER		9311	0930588	03223x12-61	SCREW	
611	16110005	11611005-06	EARED WASHER		9311-1	0930448	03123x10-61	SCREW	
612	16120027	11612007-06001	KEY WASHER		9312	0930651	03327.52.67.561	SCREW	
612-1	46120002	14612001-06001	KEY WASHER		9314	0930501	03212x5-617	SCREW	
614	16140001	11614001-06	SPRING WASHER		9316	0930732	03414x5-617	SCREW	
615	16150049	11615007-04002C	STAR DRAG KNOB		9319	0930196	03312x5-61	SCREW	
617	16170009	11617007-03	DRIVE GEAR SHAFT BUSHING		9320	0930426	03122x26-61	SCREW	
700	17000199	1170000603002	DRIVE GEAR		9320-1	0930062	03122x8-62	SCREW	
701	17010096	1170102113001A	DRIVE GEAR SHAFT		9321	0930202	03319.4x3x7-61	SCREW	
702	17020237	11702037-06001	PINION GEAR	3107	9323	0930171	03222.6x4.5-61	SCREW	
702	17020322	0	PINION GEAR		9326	0930673	03327x2.6x4-61	SCREW	
703	17030005	11703006-03907	WORM SHAFT GUARD		9404	29000001	12900001-06	E RETAINER	
704	17040007	11704004-03907	WORM GUIDE SUPPORT BAR		9404-1	19000002	11900002-06	E RETAINER	
705	17050013	11705008-06	TRANSMISSION GEAR		9406	29000006	12900006-06001	C RETAINER	
706	17060006	11706003-06	TRANSMISSION GEAR		9504	19010001	11901001-06	C RETAINER	