



CV - 20L Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11001193	1110007101001	MAIN BODY ASSY.		703	17030008	11703009-03	WORM SHAFT GUARD	
105	11050006	11105003-01	WORM SHAFT BUSHING		704	17040012	11704008-03	LINE GUIDE SUPPORT BAR	
105-1	11050007	11105004-01	WORM SHAFT BUSHING		705	17050011	11705006-06	TRANSMISSION GEAR	
117	11170017		NUT		706	17060003	11706002-06	TRANSMISSION GEAR	
200	12001014	11200071-01006C	MAIN SIDE PLATE		707	17070009	11707008-11	TRANSMISSION GEAR	
201	12010020	11201014-06001	ANTI-RE PAWL		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
204	12040016	11204007-06	OMPRESSON SPRING (AUTO TRIP)		710	17100044	1171001206917	LINE GUIDE ASSY.	
207	12070060	11207025-06001	HOLDED PLATE		712	17120026	11712019-03	WORM SHAFT	
208	12080034	11208015-06002	SIDE PLATE COVERS		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
211	12110006	11211005-03001	ANTI-RE PAWL PIN		715	17150008	11715003-06001C	LINE GUIDE PAWL	
215	12150015	11215011-03001	HOLD PLATE BUSHING		720	17200002	11720002-06001	DRIVE GEAR SHAFT BUSHING	
216	12160002	11216001-06001	ANTI-RE PAWL SPRING	3046	800	18000012	11800004-02002	CLUTCH CAM	3031
216	12160004	11216001-06002	ANTI-RE PAWL SPRING		800	18000014	11800004-12002	CLUTCH CAM	
221	12110002	11211002-03	ANTI-RE PAWL PIN		801	18010008	11801006-06001	CLUTCH SPRING	
221	12210001	11221001-07	"O"RING		802	18020001	11802003-01	CLUTCH BAR	
224	12240004	11224001-02905	ONE WAY BEARING CAP		804	18040009	11804009-06001	CLUTCH SLIDER	
300	13000444	11300030-01001	VICE SIDE PLATE		805	18050005	11805005-06001	PINION GEAR YOKE	
302	13020014	11302002-06001	WASHER		806	18060001	11806001-06	YOKE SPRING	
302-3	13020025	1130201301	SPOOL SHAFT BUSHING		807	18070002	11807001-06002	YOKE BRAKED PLATE (AUTO TRIP)	
303	13030045	11303010-03907	CLICK BUTTON		9103	0910170	01101612-63	BALL BEARING	
304	13040001	11304003-06	CLICK PAWL	3046	9106	0910227	01041104-61	BALL BEARING	
304	13040015	11304011-16001	CLICK PAWL		9107	0910248	01061335-61	BALL BEARING	
305	13050003	11305001-01002	CLICK PAWL SPRING	3046	912	19120013		COVER BOARD	
305	13050006	11305002-06001	CLICK PAWL SPRING		9201	0920111	025.1x11.5x.5-6	WASHER	
311	13110029	11311007-06002	SIDE PLATE COVER		9201-1	0920162	028x10x0.5-6	WASHER	
400	14000345	1140003214003	SPOOL ASSY.		9202	0920284	025.1x9.5x0.2-6	WASHER	
401	14010026	1140101101	CLICK GEAR		9204	0920133	026x13x0.4-8	WASHER	
418	14180001	11418001-01001	SPOOL BEARING FIXED PLATE		9205	0920343	028x25x1-1	WASHER	
500	15000238	1150002404005A	HANDLE ASSY.		9206	0920085	024.05x10x0.2-8	WASHER	
515	15150001	11515001-03907	HANDLE NUT SCREW		9207	0920066	022x4.9x0.2-3	WASHER	
600	16000053	11600016-03001	CAST CONTROL CAP		9209	0920282	025.1x8x0.2-6	WASHER	
609	16090003	11609003-06001	DRAG SPRING WASHER	3030	9301	0930550	03222.6x12-64	SCREW	
609	16090004	11609003-06001	DRAG SPRING WASHER		9302	0930651	03327.52.67.561	SCREW	
609	16090003	11609003-06001	DRAG SPRING WASHER	3033	9302-1	0930176	03222.6x9.5-61	SCREW	
610	16100027	11610011-01001	DRAG WASHER		9312	0930210	03325.2x2x4.561	SCREW	
610-1	16100028	11610012-01001	DRAG WASHER		9313	0930219	03327.52.6x6-61	SCREW	
611	16110041	11611019-06001	EARED WASHER		9314	0930501	03212x5-617	SCREW	
612	16120043	11612023-06001	KEY WASHER		9316	0930732	03414x5-617	SCREW	
612-1	16120044	11612024-06001	KEY WASHER		9317	0930194	03312x3.5-61	SCREW	
614	16140001	11614001-06	WASHER		9319	0930196	03312x5-61	SCREW	
615	16150019	14615002-04004C	STAR DRAG		9321	0930202	03319.4x3x7-61	SCREW	
618	16180002	11618001-01	WASHER		9323	0930171	03222.6x4.5-61	SCREW	
700	17000261	1170003106002	DRIVE GEAR		9326	0930673	03327x2.6x4-61	SCREW	
701	17010187	1170104516001	DRIVE GEAR SHAFT		9404	29000001	12900001-06	E RETAINER	
702	17020298	1170203506002	PINION GEAR		9406	29000006	12900006-06001	E RETAINER	