



DMG - 25 Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000666	11100053-04004	MAIN BODY		706	17060006	11706003-06	TRANSMISSION GEAR	
102	11020046	11102010-06002	BODY FOOT		707	17070004	11707003-01	TRANSMISSION GEAR	
105	11050006	11105003-01	WORM SHAFT BUSHING		708	17080003	11708003-11	TRANSMISSION GEAR	
105-1	11050007	11105004-01	WORM SHAFT BUSHING		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
117	11170012	11117007-03001	NUT		710	17100036	1171000506917	LINE GUIDE	
200	12000861	11200053-A001C	MAIN SIDE PLATE		712	17120033	11712024-03001	WORM SHAFT	
201	12010001	11201001-06	ANTI-RE PAWL		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
207	12070046	11207011-03001	HOLDED PLATE		715	17150004	11715003-06001	LINE GUIDE PAWL	
211	12110008	11211002-03001	ANTI-RE PAWL PIN		720	17200002	11720002-06001	DRIVE GEAR SHAFT BUSHING	
212	12120009	1121200101	COUNTER COVER		800	18000008	11800002-12002	CLUTCH CAM	
215	12150015	11215011-03001	HOLD PLATE BUSHING		801	18010001	11801001-06	CLUTCH SPRING	
216	12160001	11216001-06	ANTI-RE PAWL SPRING		802	18020038	11802005-01	CLUTCH BAR	
219	12190014	11219012-03	SIDE PLATE BUSHING		804	18040005	11804005-06	CLUTCH SLIDER	
219-1	12190020	11219017-03001	SIDE PLATE BUSHING		805	18050006	11805006-06001	PINION GEAR	
221	12210001	11221001-07	"O"RING		806	18060001	11806001-06	YOKE SPRING	
224	12240004	11224001-02905	ONE WAY BEARING CAP		910	19100004	11910001-01003	DEPTH COUNTER	
300	13000425	11300025-A001	VICE SIDE PLATE		9103	0910170	01101612-63	BALL BEARING	
302	13020014	11302002-06001	WASHER		9106	0910227	01041104-61	BALL BEARING	
302-2	13020021	11302009-13	BUSHING		9107	0910248	01061335-61	BALL BEARING	
302-3	13020015	11302002-06002	WASHER		9201	0920283	025.1x8x0.5-6	WASHER	
303	13030041	11303004-03929	CLICK BUTTON		9202	920291	025.9x10x0.2-6	WASHER	
304	13040001	11304003-06	CLICK PAWL		9204	0920284	025.1x9.5x0.2-6	WASHER	
305	13050007	11305001-01003	CLICK PAWL SPRING		9205	0920339	028x15x1-1	WASHER	
311	13110021	11311004-06002	SIDE PLATE COVER		9206	0920085	024.05x10x0.2-8	WASHER	
400	14000558	11400045-04006A	SPOOL		9207	920066	022x4.9x0.2-3	WASHER	
401	14010026	1140101101	CLICK GEAR		9209	0920282	025.1x8x0.2-6	WASHER	
418	14180001	11418001-01001	SPOOL BEARING FIXED PLATE		9210	0920108	025.1x10.5x.5-6	WASHER	
500	15000111	1150000604002	HANDLE ASSY.		9301	0930515	03213x10.5-647	SCREW	
500-1	15000103	1150000504902	HANDLE ASSY.		9302	0930219	03327.52.6x6-61	SCREW	
516	15160002	11516001-011	HANDLE NUT RETAINER		9307	0930696	03412.6x4-64	SCREW	
600	16000040	11600014-03002	CAST CONTROL CAP		9310	0930872	03213x9.1-61002	SCREW	
609	46090002	14609001-06001	WASHER		9311	0930370	03112.6x8-647	SCREW	
610	16100010	11610004-006	DRAG WASHER		9312	0930651	03327.52.67.561	SCREW	
610-1	16100032	11610013-000	DRAG WASHER		9314	0930501	03212x5-617	SCREW	
611	16110005	11611005-06	EARED WASHER		9316	0930734	03414x5-647	SCREW	
612	16120027	11612007-06001	KEY WASHER		9319	0930196	03312x5-61	SCREW	
612-1	46120002	14612001-06001	KEY WASHER		9320	0930427	03122x26-64	SCREW	
614	16140001	11614001-06	WASHER		9320-1	0930439	03122x8-64	SCREW	
615	16150053	11615007-04003C	STAR DRAG KNOB		9321	0930202	03319.4x3x7-61	SCREW	
617	16170009	11617007-03	DRIVE GEAR SHAFT BUSHING		9323	0930171	03222.6x4.5-61	SCREW	
700	17000199	1170000603002	DRIVE GEAR		9326	0930605	03312.6x6-617	SCREW	
701	17010096	1170102113001A	DRIVE GEAR SHAFT		9404	29000001	12900001-06	E RETAINER	
702	17020237	11702037-06001	PINION GEAR		9404-1	19000002	11900002-06	E RETAINER	
703	17030012	11703012-03001	WORM SHAFT GUARD		9406	29000006	12900006-06001	E RETAINER	
704	17040027	11704018-03001	LINE GUIDE SUPPORT BAR		9504	19010001	11901001-06	C RETAINER	
705	17050013	11705008-06	TRANSMISSION GEAR						