



DZ - 20L Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	1100938	11100027111	MAIN BODY ASSY		703	17030008	11703009-03	WORM SHAFT GUARD	
105	11050006	11105003-01	WORM SHAFT BUSHING		704	17040012	11704008-03	LINE GUIDE SUPPORT BAR	
105-1	11050007	11105004-01	WORM SHAFT BUSHING		705	17050011	11705006-06	TRANSMISSION GEAR	
117	11170012	11117007-03001	NUT		706	17060003	11706002-06	TRANSMISSION GEAR	
200	12000714	11200035-01001C	HANDLE SIDE PLATE		707	17070009	11707008-11	TRANSMISSION GEAR	
201	12010011	11201008-06	ANTI-RE PAWL		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
207	12070052	11207017-03001	HOLDED PLATE		710	17100040	1171000906	LINE GUIDE ASSY.	
211	12110009	11211003-03001	ANTI-RE PAWL PIN		712	17120026	11712019-03	WORM SHAFT	
215	12150015	11215011-03001	HOLD PLATE BUSHING		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
216	12160001	11216001-06	ANTI-RE PAWL SPRING		715	17150004	11715003-06001	LINE GUIDE PAWL	
216-1	12160003	11216002-06	ANTI-RE PAWL SPRING		800	18000005	11800002-02002	CLUTCH CAM	3031
221	12210001	11221001-07	"O"RING		800	18000008	11800002-12002	CLUTCH CAM	
300	13000444	11300030-01001	SIDE PLATE		801	18010001	11801001-06	CLUTCH SPRING	
302	13020014	11302002-06001	WASHER		802	18020001	11802003-01	CLUTCH BAR	
302-1	13020005	11302005-03	BUSHING		804	18040004	11804004-06	CLUTCH CAM SLIDER	
302-3	13020017	11302006-03	WASHER	3024	805	18050002	11805002-01	PINION GEAR YOKE	
303	13030042	11303007-03907	CLICK BUTTON		806	18060001	11806001-06	YOKE SPRING	
304	13040001	11304003-06	CLICK PAWL		9102	0910099	01081605-61	BALL BEARING	
305	13050007	11305001-01003	CLICK PAWL SPRING		9201	0920283	025.1x8x0.5-6	WASHER	
400	14000309	11400029-01001C	SPOOL		9201-1	0920162	028x10x0.5-6	WASHER	
401	14010026	1140101101	CLICK GEAR		9202	0920114	025.1x9.5x0.2-6	WASHER	
500	15000173	1150001304907A	HANDLE ASSY.		9205	0920328	028.1x22x1-1	WASHER	
516	15160001	115160001-01	HANDLE NUT RETAINER	3052	9206	0920085	024.05x10x0.2-8	WASHER	
516	15160002	11516001-011	HANDLE NUT RETAINER		9207	0920066	022x4.9x0.2-3	WASHER	
600	16000038	11600014-03001	CAST CONTROL CAP		9209	0920282	025.1x8x0.2-6	WASHER	
609	16090003	11609003-06001	DRAG SPRING WASHER		9301	0930298	03422.6x13-61	SCREW	
610	16100017	11610004-000	DRAG WASHER		9302	0930219	03327.52.6x6-61	SCREW	
610-1	16100030	11610013-000	DRAG WASHER		9307	0930226	03412.6x4-61	SCREW	
611	16110005	11611005-06	EARED WASHER		9311	0930058	03122.6x8-61	SCREW	
612	16120027	11612007-06001	KEY WASHER		9312	0930210	03325.2x2x4.561	SCREW	
614	16140001	11614001-06	SPRING WASHER		9314	0930575	03222x4.5-61	SCREW	
615	16150009	11615003-01001	STAR DRAG KNOB		9316	0930732	03414x5-617	SCREW	
617	16170002	11617005-03	DRIVE GEAR SHAFT BUSHING		9319	0930196	03312x5-61	SCREW	
700	17000205	1170000803003	DRIVE GEAR		9321	0930202	03319.4x3x7-61	SCREW	
701	17010068	1170100913001	DRIVE GEAR SHAFT		9404	29000001	12900001-06	E RETAINER	
702	17020310	1170203603002	PINION GEAR						